

## **OPTONICA LED Built-In Module Square User Manual**

Home » OPTONICA » OPTONICA LED Built-In Module Square User Manual



Built-In Module Square USER MANUAL


#### **Contents**


- 1 Mounting instructions
- 2 INSTALLATION


**INSTRUCTIONS** 

- 3 Documents / Resources
- **4 Related Posts**

**Mounting instructions** 







### **INSTALLATION INSTRUCTIONS**


The installation of the luminaire must be performed by a qualified technician. Supply voltage of the light: 230V/50Hz

- 1. Before you begin the installation, make sure the power is off.
- 2. Connect the terminals of the input voltage of the power supply to the power cord from the mains.
- 3. Insulate connections to prevent short circuits
  Prima Group 2004 Ltd. is not responsible for damage caused by improper installation. This product complies with the following EU Directives:
  - LVD 2014/35/EU
  - EMC 2014/30/EU

IMPORTER: Prima Group 2004 LTD, Bulgaria, 1784 Sofia, Mladost 1, bl. 144, Ground Floor; Phone: +359 2 988 45 72;



#### **Documents / Resources**



# OPTONICA LED Built-In Module Square [pdf] User Manual LED Built-In Module, LED Module Square

Manuals+,