

**ORACLE**  
LIGHTING

ORACLE  
LIGHTING 3018  
TRIGGER Remote  
Momentary  
Switch Kit



# ORACLE LIGHTING 3018 TRIGGER Remote Momentary Switch Kit Installation Guide

[Home](#) » [ORACLE LIGHTING](#) » ORACLE LIGHTING 3018 TRIGGER Remote Momentary Switch Kit Installation Guide 

## Contents

- [1 ORACLE LIGHTING 3018 TRIGGER Remote Momentary Switch Kit](#)
- [2 Installation Steps](#)
- [3 Specifications](#)
- [4 FAQ](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)

**ORACLE**  
LIGHTING

## ORACLE LIGHTING 3018 TRIGGER Remote Momentary Switch Kit



## Oracle Lighting

### Oracle Part 3018

#### Trigger Momentary Switch Installation Guide

##### Tools Needed

- Flat Head Screwdriver

##### Installation Steps

1. Use a flat-head screwdriver to depress the tab on the side of the switch that you wish to change/replace.
2. Remove the switch.



3. Place the included spring over the post on the new switch.
4. Press the new switch back into your remote.



## Specifications

<b>Company</b>	Oracle Lighting
<b>Website</b>	<a href="http://www.oraclelights.com">www.oraclelights.com</a>
<b>Address</b>	4401 Division St. Metairie, LA 70002
<b>Technical Support</b>	1(800)407-5776

## FAQ

- **What tools are required for installation?**

A flat head screwdriver is required.

- **Where can I find technical support?**

You can call 1(800)407-5776 for additional technical support.

- **What is the first step in replacing the switch?**

Use a flat-head screwdriver to depress the tab on the side of the switch you wish to change or replace.

## Documents / Resources

	<a href="#">ORACLE LIGHTING 3018 TRIGGER Remote Momentary Switch Kit</a> [pdf] Installation Guide 3018 TRIGGER Remote Momentary Switch Kit, 3018, TRIGGER Remote Momentary Switch Kit , Remote Momentary Switch Kit, Momentary Switch Kit, Switch Kit
--	---

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.