

Orbegozo Air 46 Cooler 3 In 1 3 Levels Timer Switch



# Orbegozo Air 46 Cooler 3 In 1 3 Levels Timer Switch Instruction Manual

[Home](#) » [Orbegozo](#) » Orbegozo Air 46 Cooler 3 In 1 3 Levels Timer Switch Instruction Manual 

## Contents

- [1 Orbegozo Air 46 Cooler 3 In 1 3 Levels Timer Switch](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 SAFETY INSTRUCTIONS](#)
- [5 FUNCTIONS](#)
- [6 ASSEMBLING](#)
- [7 OPERATION](#)
- [8 THE USE OF ICE BOX](#)
- [9 CLEANING AND MAINTENANCE](#)
- [10 MALFUNCTION AND MAINTENANCE](#)
- [11 GUARANTEE](#)
- [12 TECHNICAL SPECIFICATION](#)
- [13 Contact Information](#)
- [14 Documents / Resources](#)
  - [14.1 References](#)
- [15 Related Posts](#)



Orbegozo Air 46 Cooler 3 In 1 3 Levels Timer Switch



## Product Information

### Specifications

- **Model:** AIR 39
- **Functions:** Refrigeration / Humidification, Adjustable speed, Swing function
- **Usage:** Household use only
- **Age Recommendation:** 8 years and above
- **Website for Manual:** [www.orbegozo.com](http://www.orbegozo.com)

## Product Usage Instructions

### Safety Instructions

- Do not handle the appliance with wet hands.
- Never immerse the appliance in water or any other liquid.
- Make sure the appliance has been unplugged before cleaning.
- This appliance must be installed following the national regulations for electrical installations.
- Never insert fingers, pencils, or any other object through the grille when the fan is running.
- Keep all objects at least 1.5 meters away from the appliance.
- Do not operate in areas where gasoline, paint, or other flammable liquids are used or stored.

### Functions

- **Refrigeration/Humidification:** This appliance can be used as a humidifier. When used with the ice tray, it can

refresh the ambiance.

- **Adjustable Speed:** Three-speed settings – low, medium, high.
- **Swing Function:** The slats swing automatically, delivering wind at a wide angle flatly.

### **Cleaning and Maintenance**

Disconnect the plug before moving the appliance or removing protective grilles for cleaning. Avoid covering or restricting airflow to prevent overheating. Regularly clean the appliance to ensure efficient operation.

### **Operating Instructions**

Read the operating instructions carefully before using the appliance. Ensure the appliance is on a stable, even surface to prevent overturning. Do not use the fan in a window or near flammable materials to avoid hazards.

### **Frequently Asked Questions (FAQ)**

- **Where can I find a copy of the instruction manual?**

You can find a copy of the instruction manual on [www.orbegozo.com](http://www.orbegozo.com).

- **What should I do if the appliance is not working?**

If the appliance is not functioning properly, ensure it is plugged in correctly and that all safety precautions have been followed. If issues persist, contact customer support for assistance.

Read this manual carefully before running this appliance and save it for reference to obtain the best results and ensure safe use.

Dear Customer, If you follow the recommendations contained in this Instruction Manual, our appliance will give you constant high performance and will remain efficient for many years to come. Read the operating instructions carefully before putting the appliance into operation and keep the instructions including the warranty, the receipt, and, if possible, the box with the internal packing. If you give this device to other people, please also pass on the operating instructions.

### **SAFETY INSTRUCTIONS**

1. This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children must never play with the appliance. Cleaning and user maintenance must never be carried out by children without supervision.
2. Children should be supervised to ensure that they do not play with the appliance.
3. Keep the appliance and the cable cord out of the reach of children less than 8 years old.
4. **WARNING:** To ensure your children's safety, please keep all packaging (plastic bags, boxes, polystyrene, etc.) out of their reach.
5. If the supply cord is damaged it must be repaired by the Authorized Service Agent.
6. Never pull on the cord when unplugging.
7. Do not use the unit with a damaged cord or plug, or if it is not working properly.
8. Do not handle the appliance with wet hands.
9. Never immerse the appliance in water or any other liquid.
10. Make sure the appliance has been unplugged before cleaning.
11. This appliance must be installed following the national regulations for electrical installations.

12. This appliance is for household use only.
13. In case you need a copy of the instruction manual, you can find it at [www.orbegozo.com](http://www.orbegozo.com).
14. **WARNING:** In case of misuse, there is a risk of possible injury.
  - Never insert fingers, pencils, or any other object through the grille when the fan is running.
  - Disconnect the plug when moving from one location to another.
  - Disconnect the plug when removing guards for cleaning.
  - Be sure the fan is on a stable, even surface when operating to avoid overturning.
  - DO NOT USE a fan in the window. Rain may create an electrical hazard. Do not leave the fan operating adjacent to an area where water has been collected to avoid the potential for electrical hazards.
  - Do not operate this product near an open fire, it may ignite and cause fire, resulting in body injury or property damage.
  - Do not operate in areas where gasoline, paint, or other flammable liquids are used or stored.
  - Never attempt to disassemble or alter the product in any way not instructed by this manual. Shock, fire, or bodily injury may occur.
  - Do not cover or restrict airflow to the inlet or exhaust grills in any manner as the appliance may overheat and become a fire risk.
  - Keep all objects at least 1.5 meters from the front, sides, and rear of the appliance.

## FUNCTIONS

1. **Refrigeration/Humidification:** This appliance can be used as a humidifier, used with the ice tray, and this appliance can refresh the ambiance.
2. **Adjustable speed:** has three speeds, low, medium, and high.
3. **Swing function:** the slats swing automatically, delivering wind at a wide angle flatly. Also swing the slats transversely by your hands, choosing the wind direction up and down.
4. **Removable air filter and cooling pad:** easy to clean, can use soft brush and detergent.

## ASSEMBLING

1. Open the package and take out the air cooler.
2. Draw out the water tank 1/2, and pour clean water into the tank.
  1. Please pay attention to the water lever.
  2. Pour into the water over min level "3" but no more than max Level "8".
  3. To have the cooling effect, you can put the ice box into the tank, previously frozen.

### Attention:

Cut the power when you pour the water into the tank. You should change the water in the tank every 15 days.

## OPERATION

### Plug the device into the mains

1. **Speed Buttons:** Press the speed you want 1, 2, or 3.
2. **Swing button:** press the "SWING" button, and the air direction swings horizontally. Pressing it again stops this function.

You can also rotate the blades crosswise with your hands, and choose the air stream up and down.

- Humidification button: press the "COOL" button to make it start to work. If you add the cold packs, the temperature of the air outlet vent can drop up to 3°C below the ambient temperature after a few minutes. If you press the button again, this function stops.
- Off button: if you are not going to use the appliance, press the "0" button.

## THE USE OF ICE BOX

The ice crystal has a particular feature of keeping cool; it can absorb heat from water and let the water temperature in the water tank below environmental temperature, so the air will be much cooler.

### Using methods:

- Turn the flange and remove the water tank. Add water to the ICE BOX under not full situation and put it into the refrigerating chamber of the refrigerator to make sure that it icing absolutely.
- Ice Crystal put the ICE BOX in the water tank.
- There are two ICE BOX, that can be used circularly. Place the water tank and turn the flange to fix the water tank in its place.

## CLEANING AND MAINTENANCE

### 1. Clean the air filter screen

Unplug the power plug, push the flanges of the air filter screen up, and remove it from the appliance. Clean the air filter screen with neutral detergent and banister brush. Then clean it with clear water and reinstall to appliance.

### 2. Clean the wetted pad

Unplug the power plug, take down the air filter screen, and then draw the wetted pad from support. Clean the wetted pad with neutral detergent and banister brush. Then clean it with clear water and reinstall the appliance.

**Attention:** the wetted pad must be installed flatly, to avoid leaking.

### 3. Clean the water tank

Unplug the power plug, turn the flange, and draw out of 1/2 the tank. To remove completely, turn the two flanges that hold the water pump, and you can remove they. Clean it with neutral detergent and rinse with water. Once dry, place it again, putting the water pump as it was.

**Note:** if you need to clean the tank completely, you should unscrew the screw under the base, and also should unscrew the screw of the water pump inside the tank.

### 4. Clean the shell

Clean with neutral detergent and soft cloth.

- Attention:** unplug the power plug when cleaning the appliance, since there is high pressure in the body. Do not leave any water on the control panel.
- Attention:** Must unplug the power plug when cleaning. Don't put the water into the control panel.

## MALFUNCTION AND MAINTENANCE

Malfunction	Possible reasons	Solution
No action	Power off or poor connection	· Plug the power cord and make sure it connects well.
The poor result of dedusting	<ul style="list-style-type: none"> <li>· Block the air filter screen with dust.</li> <li>· Block the air inlet with corpus alien.</li> </ul>	<ul style="list-style-type: none"> <li>· Remove and clean the air filter screen.</li> <li>· Remove corpus alien from the air inlet.</li> </ul>

## DISPOSAL OF OLD ELECTRICAL APPLIANCES

The European directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal unsorted municipal waste stream. Old appliances must be collected separately to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment. The crossed-out “wheeled bin” symbol on the product reminds you of your obligation, that when you dispose of the appliance, it must be separately collected.

Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliances.

symbol on the product reminds you of your obligation, that when you dispose of the appliance, it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliances.

## DECLARATION OF CONFORMITY:

This device complies with the requirements of the Low Voltage Directive 2014/35/EU and the requirements of the EMC Directive 2014/30/EU.

## GUARANTEE

This appliance is covered and is entitled to the legal guarantee by the legislation in force from the date of purchase. Keep the purchase receipt to be able to claim your right to the guarantee. To find the closest service to your location, contact us through the following web link: <https://orbegozo.com/asistencia-tecnica/>. For any type of query, doubt, or incident, you can contact us through our email shown on the main page of this manual or through our technical assistance service at <https://orbegozo.com/contacto/>. Orbegozo is not responsible for components and accessories that are subject to wear and tear due to use, as well as perishable compounds or those that have deteriorated due to improper use. Nor will it be held responsible if the owner has technically modified the device. Check the legal conditions on our website.

## TECHNICAL SPECIFICATION

## ERP TECHNICAL SPECIFICATION REGULATION (EU) 206/2012 AND (EU) 2016/2282

### DIRECTIVE 2009/125/EC

Description	Symbol	Value	Unit
Maximum fan flow rate	F	3.6	M <sup>3</sup> /min
Fan power input	P	60,3	W
Service value	SV	0,06	(M <sup>3</sup> /min)/W
Standby power consumption	PSB	0,3	W
Fan sound power level	LWA	56,6	dB (A)
Maximum air velocity	C	5,6	meters/sec
Measurement standard for service value	IEC 60879:2019		
Contact details for obtaining more information	Sonifer S.A. Avda Santiago 86, 30007, Murcia, Spain.		


## Contact Information

### Sonifer, S.A.

- Avenida de Santiago, 86 30007 Murcia España
- Email: [sonifer@sonifer.es](mailto:sonifer@sonifer.es)
- Página web [www.orbegozo.com](http://www.orbegozo.com).

Made in P.R.C.

## Documents / Resources

	<p><a href="#">Orbegozo Air 46 Cooler 3 In 1 3 Levels Timer Switch</a> [pdf] Instruction Manual</p> <p>Air 46 Cooler 3 In 1 3 Levels Timer Switch, Air 46, Cooler 3 In 1 3 Levels Timer Switch, Levels T imer Switch, Timer Switch</p>
---	--

## References

- [User Manual](#)