

ORIGIN EFFECTS V2 Revival Drive Footswitch User Guide

Home » ORIGIN EFFECTS » ORIGIN EFFECTS V2 Revival Drive Footswitch User Guide 1

Contents

- 1 ORIGIN EFFECTS V2 Revival Drive Footswitch
- 2 Safety Notices:
- 3 Symbols and signal words:
- **4 Safety Instructions:**
- **5 Connecting the Footswitch**
- **6 Using the Footswitch**
- 7 Appendix A Physical Specification
- 8 Appendix B Environmental information
- 9 Appendix C Warranty
- 10 Product Specifications:
- 11 Frequently Asked Questions (FAQ):
 - 11.1 Q: Can I use the RevivalDRIVE Footswitch with other pedals?
 - 11.2 Q: How do I clean the footswitch?
 - 11.3 Q: What should I do if the footswitch is damaged?
- 12 Documents / Resources
 - 12.1 References
- 13 Related Posts

ORIGIN EFFECTS V2 Revival Drive Footswitch

USER GUIDE

www.origineffects.com

ORIGIN EFFECTS is a trademark of Origin Effects Limited and is a registered trademark in the United States, United Kingdom, China and the EU.

The ORIGIN EFFECTS Totem Device is a trade mark of Origin Effects Limited and is a registered trademark in the United States, China and United Kingdom.

All other product names and trademarks are the property of their respective owners and are hereby acknowledged.

No part of this publication may be reproduced in any form or by any means, whether mechanical or electronic, without the written permission of Origin Effects Limited.

Origin Effects Limited reserves the right to change the features and specifications described herein without notice

or obligation.

Origin Effects Limited cannot be held responsible for any loss or damage arising directly or indirectly from any error or omission in this manual.

© Origin Effects Limited 2024

Origin Effects LTD

Unit 4, Top Angel, Buckingham, Buckinghamshire, MK18 1TH United Kingdom

Safety Notices:

General Information:

This document contains important information for the safe operation of the product. Read and follow the safety instructions and all other guidance. Our products and documentation are subject to a process of continuous development. They are therefore subject to change. Please refer to the latest version of the documentation, which is available on our website https://origineff ects.com/manuals/

Keep these instructions and heed all warnings. Do not use this apparatus near water. Clean only with a dry cloth. Do not install near any heat sources such as radiators, stoves or other apparatus (including amplifiers) that produce heat. Refer all servicing to qualified service personnel.



NOTICE!

Damage may be caused to the device should it be tampered with!

No user-serviceable parts inside. In the event of damage to the unit, service or repair must be done by qualified service personnel only.

Symbols and signal words:

Signal Word	Meaning		
DANGER!	This combination of symbol and signal word indicates a dangerous situation th at could result in serious injury or even death if it is not avoided.		
WARNING!	This combination of symbol and signal word indicates a potentially dangerous situation that could result in serious injury or even death if it is not avoided.		
NOTICE!	This combination of symbol and signal word indicates a potentially dangerous situation that could result in material and/or environmental damage if it is not a voided.		

Warning Symbol	Meaning		
<u>!</u>	Warning – dangerous situation		

Safety Instructions:

Intended use:

This device is intended for use as an external controller for the Origin Effects RevivalDrive pedal. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

Safety:



DANGER!

Risk of injury and choking hazard for children!

Children can suffocate on packaging material and small parts. Never allow children to play with packaging material or the device. Always store packaging material out of the reach of babies and small children. Always dispose of packaging material properly when it is not in use. Never allow children to use the device without supervision. Keep small parts away from children and make sure that the device does not shed any small parts (such as knobs, rubber feet) that children could play with.



NOTICE!

Possible staining due from rubber feet!

The plasticiser used in the manufacture of the rubber feet on this product may react with floor coatings and result in permanent dark stains after some time. If necessary, use a suitable mat to prevent direct contact between the device's rubber feet and the floor.

Connecting the Footswitch

Using the TRS jack cable supplied, connect TRS socket on the Footswitch to the F/SWITCH socket on the RevivalDRIVE pedal.



Note: Any standard TRS jack cable can be used in place of the supplied cable.

The RevivalDRIVE Footswitch is compatible with RevivalDRIVE, RevivalDRIVE Custom, RevivalDRIVE Hot Rod and RevivalDRIVE Hot Rod Custom pedals.

Using the Footswitch

The RevivalDRIVE Footswitch allows additional control of the RevivalDRIVE's mid-boost and dry blend functions.

MID-ENGAGE

Setting the MID ASSIGN switch on the RevivalDRIVE to F/SWITCH, allows you to apply the adjustable mid-boost to whichever channel is currently selected.

The mid-boost is applied to both the DRY and O.D. signals mixed by the BLEND control.

The mid-boost function is not active when the pedal is in bypass mode.



BLEND OVERRIDE

This footswitch "overrides" each channel's BLEND control from the signal path. With the BLEND knob set for a mix of DRY and O.D. signals, engaging BLEND OVERRIDE effectively removes the DRY component and reverts to a 100% O.D. signal. This offers additional flexibility akin to having another channel on your amp.

For example, with the channel controls set for medium gain and the BLEND knob at 12 o'clock, engaging the BLEND OVERRIDE footswitch lets you go from an organic clean tone with a little grit to a fully overdriven sound for aggressive rhythm playing. By carefully adjusting the DRY GAIN trimmer, you can control the change in volume

- up, down or unity gain - that occurs when engaging BLEND OVERRIDE.

As an alternative to the above example, you could set up your core drive tone with BLEND OVERRIDE engaged, then transition to a cleaner "edgy" solo tone of greater volume by disengaging BLEND OVERRIDE and turning the DRY GAIN control up.

Appendix A - Physical Specification

	BOXED		UNBOXED	
WEIGHT	400 g	0.88 lb	314 g	0.69 lb
LENGTH	165 mm	6.4 inch	115 mm	4.52 inch
WIDTH	100 mm	3.93 inch	47 mm	1.85 inch
HEIGHT	80 mm	3.14 inch	55 mm	2.16 inch

Appendix B – Environmental information



The crossed out wheely bin symbol indicates this product is classified as Waste Electrical and Electronic Equipment (WEEE) in the European Union and should not be discarded with household waste. Other territories may vary. Contact your local authority or Origin Effects for more information.



The packing materials for this product are recyclable. Do not dispose of these materials with your normal household waste. Please refer to the symbols on the packaging for recycling information. Contact your local authority for further guidance on recycle in your region.



Packaging materials are recyclable



Collection points on <u>www.quefairemesdechet.fr</u> Prefer repairing or donating your device!

Appendix C - Warranty

This product is covered by a 2-year manufacturer's warranty from the date of purchase. This applies only to original purchasers who have bought their product from an authorised Origin Effects dealer or directly from Origin Effects.

All returns or servicing should be arranged through the original dealer. Proof of original ownership may be required in the form of a purchase receipt.

For full warranty details visit www.origineffects.com/warranty

Product Specifications:

Product Name: RevivalDRIVE Footswitch

· Version: V2

· Manufacturer: Origin Effects Limited

• Trademark: ORIGIN EFFECTS

• Intended Use: External controller for the Origin Effects

RevivalDrive pedal

• Available Manuals: Origineffects.com

Manuals

Frequently Asked Questions (FAQ):

Q: Can I use the RevivalDRIVE Footswitch with other pedals?

A: The footswitch is designed to work specifically with the Origin Effects RevivalDrive pedal. Using it with other pedals may not provide the intended functionality.

Q: How do I clean the footswitch?

A: Use a dry cloth to clean the footswitch. Avoid using any liquids or cleaning agents as they may damage the device.

Q: What should I do if the footswitch is damaged?

A: In case of damage, do not attempt to repair it yourself. Seek assistance from qualified service personnel to avoid further issues.

Documents / Resources



ORIGIN EFFECTS V2 Revival Drive Footswitch [pdf] User Guide V2 Revival Drive Footswitch, V2, Revival Drive Footswitch, Drive Footswitch, Footswitch

References

- ***** Destin Title Company | Emerald Coast Title Services
- Origin Effects The world's finest guitar effects
- WARRANTY Origin Effects
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.