

OUTLOOK TFP-15A Small Portable Space Heater with 3D Flame



OUTLOOK TFP-15A Small Portable Space Heater with 3D Flame Instruction Manual

[Home](#) » [outlook](#) » **OUTLOOK TFP-15A Small Portable Space Heater with 3D Flame Instruction Manual** 

Contents

- [1 OUTLOOK TFP-15A Small Portable Space Heater with 3D Flame](#)
- [2 INTRODUCTION](#)
- [3 IMPORTANT INSTRUCTIONS](#)
- [4 SPECIFICATION](#)
- [5 SAFETY FEATURES](#)
- [6 IN THE BOX](#)
- [7 PRODUCT DIAGRAM](#)
- [8 MAINTENANCE](#)
- [9 TROUBLESHOOTING](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)

OUTLOOK

OUTLOOK TFP-15A Small Portable Space Heater with 3D Flame



INTRODUCTION

- PLEASE SAVE THESE INSTRUCTIONS
- **WARNING:** READ THIS OWNER'S MANUAL CAREFULLY BEFORE USE.
- Thank you for choosing our Electric Fireplace. This owner's manual will provide you with valuable information necessary for the proper care and maintenance of your new product.
- Please take a few moments to thoroughly read the instructions and familiarize yourself with all the operational aspects of your new heater.
- For after-sales inquiries, technical support, or general assistance, please contact our dedicated customer service team at alpaca-cs@outlook.com. We are here to help

IMPORTANT INSTRUCTIONS

When using this electric unit, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read ALL instructions before using this unit.
2. **CAUTION:** Risk of Electric Shock. DO NOT open or try to repair the heater yourself.
3. This heater may get hot when in use. To avoid burns, DO NOT let bare skin touch hot surfaces.
4. Keep combustible materials, such as furniture, pillows, bedding, paper, clothes, and curtains at least 3 ft from the front of the heater and keep them away from the sides, top, and rear. DO NOT place towels or other objects on the heater.
5. Extreme caution is necessary when any heater is used by or near children or the disabled, or when the heater

is left operating and unattended.

6. DO NOT operate any heater with a damaged cord or after the heater malfunctions, has been dropped or damaged in any manner. Return the heater to an authorized service facility for examination, electrical or mechanical adjustment, or repair.
7. This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. NEVER locate a heater where it may fall into a bathtub or other water container. To protect against electrical hazards, DO NOT immerse in water or other liquids.
8. DO NOT touch the control panel or plug with a wet hand.
9. DO NOT run a cord under the carpeting. DO NOT cover the cord with throw rugs, runners, or similar coverings. Arrange the cord away from the traffic area so that it will not be tripped over.
10. DO NOT insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
11. To prevent a possible fire, DO NOT block the air intakes or exhaust in any manner. DO NOT use on soft surfaces, like a bed, where openings may become blocked.
12. A heater has hot and arcing or sparking parts inside. DO NOT use in areas where gasoline, paint, explosive and/or flammable liquids are used or stored. Keep the unit away from heated surfaces and open flames.
13. Always plug heaters directly into a wall outlet/receptacle Never use with an extension cord or relocatable power tap(outlet/power strip)
14. To avoid fire or shock hazards, plug the unit directly into a 120 V AC electrical outlet.
15. To disconnect the heater, turn the controls to OFF, then remove the plug from the outlet. Pull firmly on the plug, DO NOT unplug by pulling on the cord.
16. Always unplug the unit before moving or cleaning, or whenever the heater is not in use.
17. Use only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended or sold by unauthorized dealers may cause hazards.
18. Always use on a dry, level surface. Use on the floor only.
19. DO NOT use outdoors.
20. **WARNING:** To reduce the risk of fire or electric shock, DO NOT use this unit with any solid-state speed control device.
21. DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user-serviceable parts. Qualified personnel should perform all servicing only.

SPECIFICATION

Voltage Rating	120 V (60Hz)
Power Consumption	1500W
Unit Size	8.78 in. (W) x 5.67in. (D) x 9.45 in. (H)
Unit Weight	1.55KG

SAFETY FEATURES

Overheat Safety Feature

- This heater is equipped with an overheat safety feature.
- When the heater's internal components reach a certain temperature that could cause overheating or possible fire, the heater will automatically shut off.


Tip Over Switch features

- This heater is equipped with a safety tip-over switch, when the item falls or leaves the table/floor, the machine will automatically shut off.
- **WARNING:** It is normal for the power cord to feel warm to the touch; however, a loose fit between the outlet and the plug may cause overheating of the plug.
- If this occurs, try inserting the plug into a different outlet. Contact a qualified electrician to inspect the original outlet for damage.


IN THE BOX

- Electrical fireplace stove with heater
- Instruction manual


PRODUCT DIAGRAM




Control Panel



CONTROL PANEL



OPERATION ON CONTROL PANEL

- For Flame Effect Only- Slide the main power ON/FF  switch to the ON position to have the flame effect without any heater functions.
- For Low Heat-Slide (750W) main power ON/OFF switch to the ON position and the Slide switch "I" to the ON position. and sie-Sie polio in power ON/OFF switch to ON position and slide both switch

SETTING THERMOSTAT:

- After the heater has been turned on and the room has reached the desired temperature, slowly slide the thermostat wheel to the left direction until the heater shuts off (you should hear a faint "click") By leaving the thermostat at the setting it will automatically maintain this temperature. To lower the temperature, slide the thermostat wheel to left direction. To raise the temperature, slide the thermostat wheel to the right direction.

PREPARATION

Place the heater on a firm, level surface and plug it into a 120V 60Hz power outlet.

MAINTENANCE

1. Turn off the heater of the power switch.

2. Unplug the unit and let it cool completely.
3. To keep the release, the utensil may be cleaned with a soft, damp cloth. Do not let the liquid enter the heater.
4. DO NOT use alcohol, gasoline, abrasive powders, furniture polish, or rough brushes to clean the heater. This may cause damage or deterioration to the surface of the heater.
5. DO NOT immerse the heater in water.
6. Wait until the unit is completely dry before use.

STORAGE

- Store the heater in a cool, dry location when not in use.
- To prevent dust and dirt build-up, use the original packaging to repack the unit.

TROUBLESHOOTING

If the heater will not operate, please check the following before seeking repair advice:

1. Check if the power cord is plugged into an electrical outlet, if not, plug it in.
2. Check if the electricity to the main power switch (in the back) is working.
3. Check the power switch is on

Documents / Resources



[OUTLOOK TFP-15A Small Portable Space Heater with 3D Flame](#) [pdf] Instruction Manual
TFP-15A Small Portable Space Heater with 3D Flame, TFP-15A, Small Portable Space Heater with 3D Flame, Portable Space Heater with 3D Flame, Heater with 3D Flame, Flame

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.