



Outwell 111401 Fallcrest Side Panel Set Instruction Manual

Home » Outwell » Outwell 111401 Fallcrest Side Panel Set Instruction Manual



Contents

- 1 Outwell 111401 Fallcrest Side Panel
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 PITCHING**
- 5 Cleaning and maintenance tips
- 6 Documents / Resources **6.1 References**
- **7 Related Posts**



Outwell 111401 Fallcrest Side Panel Set



Product Information

Specifications:

Product Name: Fallcrest Side Panel Set

Manufacturer: OutwellIntended Use: Camping

• Recommended Usage: 2-5 weeks per year

Product Usage Instructions

Pitching Instructions:

To pitch your tent, follow these steps:

- 1. Select a level campsite free of rocks and sharp objects.
- 2. Spread out the awning with the door facing your desired direction.
- 3. Avoid placing the awning directly under trees and consider wind direction.
- 4. Practice pitching the awning before traveling to familiarize yourself with the process.
- 5. Ensure the flysheet is not in contact with the interior in wet weather to prevent leaks.
- 6. Use storm pegs in case of strong winds and avoid pulling pegs out using guy ropes.

Cleaning and Maintenance:

Proper cleaning and maintenance tips:

- Wipe down metal poles with acid-free oil after each use to prevent moisture damage.
- Remove dirt with a soft sponge and clean water; do not use chemical cleaners.
- Avoid washing in a machine; store in a dry place when not in use.
- If seams tape comes loose, repair using seam sealer and waterproofing spray.

Additional Tips:


- · Avoid spraying insecticide inside or on the awning.
- Do not pull on the mud valance to straighten the awning.
- Ensure the awning is completely dry before packing to prevent moisture damage.


FAQ

- · Q: How often should I use the tent?
 - A: The tent is designed for 2-5 weeks of usage per year for camping purposes. Avoid permanent usage.
- Q: Can I wash the tent in a washing machine?
 - A: No, never wash the tent in a washing machine. Use a soft sponge and clean water for cleaning.
- Q: What should I do if the seams tape comes loose?
 - A: Repair the awning by removing the loose tape and using a seam sealer and waterproofing spray to re-seal

PITCHING

PITCHING VERSION 1+2












PITCHING VERSION 3+4











HOW TO PITCH YOUR TENT?

HOW TO CLEAN AND MAINTAIN YOUR TENT?

www.outwell.com/maintenance

Cleaning and maintenance tips

Congratulations on your innovative new Outwell® vehicle awning, designed and developed to accompany you out into the great outdoors. Open the carrybag, and note how the awning has been packed as you take it out. This will help you when it is time to pack up the awning. When selecting your campsite, the ideal place is an area which is as level and as free of rocks, branches and other sharp objects as possible. Spread out the awning and position it with the door facing the desired direction. Avoid placing the awning directly under trees and consider the wind direction. We recommend that you practice pitching your awning before travelling, to familiarise yourself with it. Under certain weather conditions, condensation can form on the inside of your vehicle awning. To prevent this as far as possible, it is important that wet clothes etc. are removed from the awning. Also make sure to air out the awning, or pitch the awning on an Outwell® groundsheet.

Condensation is not the same as a leak in the awning.

The flysheet is made of waterproof material. You should therefore avoid the interior or anything else coming into contact with the inner side of the flysheet in wet weather, to avoid leaks. Never fully tighten the guy ropes, as this leaves the awning with no leeway to adapt to wind and weather.

If strong winds are expected, replace the pegs with special storm pegs. Do not pull the pegs out of the ground using the guy ropes. For stony or hard soil, we recommend stronger u-shaped pegs.

Insecticide should not be sprayed inside or on the awning.

When taking down and packing away the awning, please note that it must be completely dry to avoid moisture damage. We recommend that you wipe down all metal poles using acid-free oil after use. Remove dirt on the awning using a soft sponge and clean water. Never wash the vehicle awning in a washing machine and never use chemical cleaners. Store the awning in a dry place. Please note that the tape at the seams may come loose after repeated use. If this happens, repair the awning by removing the loose tape and using a seam sealer and waterproofing spray to re-seal the seams. Instructions are available at www.outwell.com/FAQ

If a minor water leak is found from taping this can easily be re-sealed using a seam sealer – the leak can happen from single thread uncovered by tape a simple fold in the covering tape or similar by human made workflows. We recommend using Outwell Waterguard on regular intervals on the flysheet material to increase the life span. Note that the sun's ultraviolet rays may cause damage to the awning flysheet if it is exposed to direct sunlight for an extended period. The Outtex® material used for Outwell vehicle awnings extends the awning's lifetime. Outwell Product are made for camping use which is normally 2-5 weeks usage a year. They are not designed for permanent usage and should only be used as camping products. Camping near the sea or lake can further enhance the effect of UV radiation. The same applies to poles and metal parts. If your awning has a mud valance, you must never pull on this to straighten the awning. The mud valance on the vehicle awning is only designed to keep out wind and water, and cannot handle being pulled on.

Taking down your tent

When detachable take out the groundsheet and clean it if necessary with a sponge and water. Clean dirty floors the same way. (Allow it to dry before packing the tent). If the inner tent is wet or dirty, take it out and clean it, the tent can be packed down with or without the inner tent inside. Then start to unpeg the tent and the guylines. Gently remove the poles from the pins and then gently push the poles through the sleeves. Do not pull the poles through! You are now ready to fold the tent. Try to fold it so you have all metal pins/rings at one side (to prevent them from making holes in the flysheet). When you have folded the tent, measure it with the carrybag to make sure it is not too wide. You should now be able to roll the tent round the poles in their pole bag and fit it into the Outwell carrybag.

Best regards,

THE OUTWELL TEAM

Outwell Wind Stabilizer System

* Testing and determination of Outwell Wind Stabilizer System (OWS System) performance and matching Beaufort ratings is based on the knowledge and technique available to Outwell at the time of testing. Outwell is not responsible if a subsequent development may show that Outwell's knowledge and technique is flawed or incorrect. The ratings to this tent are obtained by erecting and testing similar tents at the facilities of Oase Outdoors ApS. The ratings are therefore no guarantee for the properties of this tent. Factors such as varying ground conditions, inadequate pegs, sun, rain, temperature, other weather conditions, defective or incorrect erection of the tent and normal wear and tear can lead to a performance of the tent that differs from the specified ratings.

For more info on tips and maintenance please visit <u>outwell.com</u> Please direct product claims and problems to your supplying Outwell dealer.

Documents / Resources



Outwell 111401 Fallcrest Side Panel Set [pdf] Instruction Manual 111401 Fallcrest Side Panel Set, 111401, Fallcrest Side Panel Set, Side Panel Set, Panel Set, Set

References

- Outwell Innovative Family Camping buy online here
- Outwell Innovatives Familien Camping hier online kaufen
- Outwell Innovative Family Camping buy online here
- Outwell Innovative Family Camping acheter en ligne
- Outwell Innovative Family Camping koop hier online
- Outwell Innovative Family Camping buy online here
- Coutwell Innovative Family Camping buy online here
- Outwell Innovative Family Camping buy online here
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.