

OVERFUN
Electric Web
Launcher



OVERFUN Electric Web Launcher User Manual

[Home](#) » [OVERFUN](#) » OVERFUN Electric Web Launcher User Manual 

Contents

- [1 OVERFUN Electric Web Launcher](#)
- [2 INTRODUCTION](#)
- [3 SPECIFICATIONS](#)
- [4 WHAT'S IN THE BOX](#)
- [5 FEATURES](#)
- [6 SETUP GUIDE](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PROS & CONS](#)
- [10 WARRANTY](#)
- [11 FREQUENTLY ASKED QUESTIONS](#)
- [12 References](#)

OVERFUN

OVERFUN Electric Web Launcher



INTRODUCTION

For those who enjoy role-playing games and superheroes, the OVERFUN Electric Web Launcher is an essential device. With its electric reel-in mechanism and true silk-like web string, this web shooter, which is suitable for both children and adults, stimulates imaginative play. This entertaining and inventive device, which costs **\$25.99**, allows users to blast a retractable string up to eight feet with a single button click. It is easy to use and transport because to its lightweight and small design (2.9 x 6.7 x 1.7 inches, 6.4 ounces), which is manufactured by OVERFUN. This web launcher is a fantastic option whether you're searching for a fun toy for youngsters or a cool souvenir for fans of superheroes!

SPECIFICATIONS


Product Name	Web Launcher Spider String Shooter Toy
Price	\$25.99
Product Dimensions	2.9 x 6.7 x 1.7 inches
Item Weight	6.4 ounces
Manufacturer	OVERFUN
Recommended Age	Suitable for kids and adults (great for superhero role-play)
Functionality	Electric reel-in mechanism for retracting the string
How to Use	1. Reel in the string by holding the switch until fully retracted
	2. Load the head into the launcher
	3. Press the reel-in switch to maximize range
	4. Press the launch switch with the ring/middle finger to fire
Firing Range	Shoots up to 8 feet
Design	Compact, lightweight, easy to use for superhero role-play
Ideal for	Kids, cosplay enthusiasts, and fans of superhero gadgets
Gift Suitability	Fun gadget for birthdays, cosplay events, and superhero fans

WHAT’S IN THE BOX

- Web Launcher
- Screwdriver
- User Manual

FEATURES


- For speedy reloads, the electric reel-in mechanism instantly retracts the string.



- For a genuine superhero web-shooting experience, use real silk string.
- **Measuring:** just 6.4 ounces, this design is lightweight and compact for effortless handling.
- Launching and retracting are made easy with a one-handed operation.
- Playing at the 8-Foot Shooting Range is thrilling.
- **Realistic:** action with a ring or middle finger press-to-launch system
- Long-lasting performance is guaranteed by a sturdy construction.
- The ergonomic design makes the wrist feel comfortable.
- Superhero role-playing games are entertaining for both children and adults.
- For variable power consumption, rechargeable battery.

Rechargeable Battery

Full charge can be used for about 10 days



- **Reloading:** is easy using a straightforward head-loading procedure.
- A soft projectile system makes it safe for both inside and outdoor use.
- Its sleek design gives it a contemporary, futuristic appearance.
- Fantastic Present Idea for Fans of Superheroes and Technology
- Resistance to wear and tear is ensured by high-quality materials.



SETUP GUIDE

- Make sure all the parts are included when you open the electric web launcher.

- Use the adjustable strap to fasten the launcher to your wrist.
- If the device is equipped with a rechargeable battery, charge it.



- Securely fasten the web string to the launcher head.
- For ease of use, hold the launcher in your hand comfortably.
- Holding down the reel-in switch will fully retract the string.
- To avoid tangling, don't pause while retracting.
- Before launching, make sure the head is correctly loaded.
- Before trying to shoot, be sure the string is completely retracted.
- To increase the shooting range before launching, press the reel-in switch.
- Press the launch switch with the ring or middle finger.
- Before launching, keep a safe distance from people or objects.
- To familiarize yourself with the launch mechanisms, test fire in an open area.
- Keep spare strings on hand in case you need to replace them.
- For correct usage, adhere to the manufacturer's safety recommendations.

CARE & MAINTENANCE

- Frequently wipe the web launcher down with a dry towel to get rid of dust.
- To prevent damage, keep the gadget in a cool, dry location.
- Keep the launcher dry because moisture can interfere with its functionality.
- Before each use, look for any obstructions in the reel-in mechanism.
- Avoid going above the web string's allotted length.
- Keep extra strings on hand in case the originals wear out. To avoid internal damage, don't drop the launcher.
- If necessary, fully charge the battery; do not overcharge it.

- Periodically check the launch button to make sure it operates smoothly.
- Avoid keeping the launcher in extremely hot or cold temperatures.
- To avoid unintentional usage, keep the launcher away from younger children.
- For maintenance, only use replacement components that have been approved by the manufacturer.
- Do not tug the string too hard as this could damage it.
- Before attempting again, reset the reel-in procedure if the launcher jams.
- To save battery life, turn off or deactivate the gadget while not in use.

TROUBLESHOOTING

Issue	Possible Cause	Solution
String not retracting	Low battery or jammed mechanism	Recharge or replace battery, check for obstructions
Web not launching	String not properly loaded	Ensure correct head loading before firing
Short shooting range	Weak retraction power	Fully retract the string before launching
Button unresponsive	Loose connection or battery issue	Check battery and internal wiring
String tangles frequently	Improper reel-in technique	Hold the reel-in switch continuously without pausing
Device not turning on	Dead battery	Replace or recharge battery
Launch power inconsistent	Dust or debris in mechanism	Clean the internal components gently
Web launcher overheating	Extended continuous use	Allow device to cool down before reuse
String frays easily	Frequent rough use	Use gentle handling and store properly
Web head gets stuck	Misalignment in loading process	Ensure head is correctly positioned before launching

PROS & CONS

Pros:

1. Realistic web-shooting experience with electric reel-in function.
2. Compact and lightweight design for easy handling.
3. Great for superhero role-play and imaginative fun.
4. Electric retractable string for a seamless shooting experience.
5. Safe and kid-friendly design with soft web material.

Cons:

1. Battery-operated, requiring frequent recharging or replacements.
2. Limited shooting range (max 8 feet).

3. String may tangle if not retracted properly.
4. Requires careful handling to avoid mechanical issues.
5. May not be suitable for rough outdoor play.

WARRANTY

The **OVERFUN** Electric Web Launcher comes with a manufacturer's warranty, ensuring replacement or repair for any defects in materials or workmanship. Buyers should check the seller's warranty policy for specific terms and conditions.

FREQUENTLY ASKED QUESTIONS

What is the OVERFUN Electric Web Launcher?

The OVERFUN Electric Web Launcher is a superhero role-play gadget that lets users shoot and retract a string, simulating web-slinging action. Its a fun and engaging toy for kids and adults.

What age group is the OVERFUN Electric Web Launcher suitable for?

The toy is designed for both kids and adults, making it a great gift for superhero fans of all ages.

How far can the OVERFUN Electric Web Launcher shoot the web?

The launcher can shoot the web approximately 8 feet, creating an immersive superhero experience.

Why is the string getting shorter on the OVERFUN Electric Web Launcher?

The string might be knotted inside the reel, reducing its length. Follow the troubleshooting steps to untangle it.

Can I replace the string in the OVERFUN Electric Web Launcher?

The product does not specify replaceable strings, but proper maintenance should keep it functional.

What are the dimensions of the OVERFUN Electric Web Launcher?

The toy measures 2.9 x 6.7 x 1.7 inches and weighs 6.4 ounces, making it lightweight and easy to handle.

Where can I purchase the OVERFUN Electric Web Launcher?

It is available online for \$25.99, making it an affordable and fun gift option.

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.