



# OZARK Lightweight Floor Lamp Instruction Manual

[Home](#) » [OZARK](#) » OZARK Lightweight Floor Lamp Instruction Manual 

## Contents

- [1 OZARK Lightweight Floor Lamp](#)
- [2 INSTRUCTION MANUAL](#)
- [3 Assembly Inventory](#)
- [4 Remote Control Instructions](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)
- [6 Related Posts](#)

# OZARKÉ

**OZARK Lightweight Floor Lamp**



## Specifications

- Power Supply: AC100-240V, 50Hz/60Hz
- Usage: Indoor
- Components: LED Lamp, Lamp Base, Remote Control

## Installation

1. Ensure power supply is within the specified range.
2. Avoid scratching lamp's surface and wires during installation.
3. Do not install lamp outdoors.
4. Keep lamp away from corrosive chemicals or gases.
5. Clean lamp with a soft cloth, do not wash with water.

## Assembly Inventory Check

Please verify the assembly inventory. If anything is missing, contact customer service.

## Remote Control Instructions

1. Install two AAA batteries in the remote control.
2. Point the remote at the light fixture and press the On button to turn on the light.
3. To connect the remote to the lamp, press the On button within 3 seconds after powering the fixture on until it flashes.
4. Use the + and – buttons to adjust brightness, and k+ and k- buttons to adjust color temperature.

## **FAQ**

### **How do I adjust the brightness and color temperature?**

Use the + and – buttons on the remote to adjust brightness. Use k+ and k- buttons to adjust color temperature.

## **INSTRUCTION MANUAL**

Thank you for shopping with Ozarké, we really appreciate your business. Our goal is to provide excellent customer service before, during and after delivery. We've included a guide on how to install this light, should you require additional assistance please feel free to email us at [info@ozarke.com](mailto:info@ozarke.com) and one of our customer service reps will reach out to assist you.


### **Before you get started**

- Ensure that the power supply remains within the specified range of AC100-240V, 50Hz/60Hz.
- Avoid scratching the lamp's surface and wires during installation.
- Do not install the lamp outdoors.
- Keep the lamp away from corrosive chemicals or gases. It should not be washed with water but can be wiped clean with a soft cloth.

### **Assembly Inventory**


Please check the assembly inventory. If you find anything missing reach out to our customer] service team

- 1 x LED Lamp
- 1 x Lamp Base
- 1 x Remote Control



## Remote Control Instructions

1. Please Install two AAA batteries. Once you have installed the batteries, point the remote at the light fixture and press the "On" button the light will come on. The remote should connect automatically once the batteries are installed (If the remote does not connect see step 2)
2. To connect the remote to the lamp, it must be done within the first 3 seconds after you power the fixture on, press the "on" button until the fixture flashes.
3. Once the light is on, use the "+" and "-" buttons on the remote to adjust the brightness. Pressing "+" will increase the brightness, while "-" will decrease it.
4. Once the light is on, use the "k+" and "k-" buttons on the remote to adjust the color temperature. Pressing "k+" will increase the temperature while "k-" will decrease it. Increasing the temperature will make the emitting color cold and decreasing the temperature will make the emitting color warm.



### Helpful information

1. ON: Turns the light on/ Connects to lamp/ Clears code
2. Off: Turns the light off
3. Wheel buttons: Adjusts temperature and brightness
4. 30%: 30% brightness
5. 80%: 80% brightness
6. Moon Button: 10% brightness
7. C: Cold White
8. W: Warm light

---

### Documents / Resources



## [OZARK Lightweight Floor Lamp](#) [pdf] Instruction Manual

Lightweight Floor Lamp, Lightweight, Floor Lamp, Lamp

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.