



OZOCOZY TSA007 Password Locks Instructions

[Home](#) » [OZOCOZY](#) » OZOCOZY TSA007 Password Locks Instructions 

Contents

1

OZOCOZY TSA007 Password Locks

2

Instructions

3

Features

4

Documents / Resources

4.1

References

5


Related Posts



OZOCOZY TSA007 Password Locks



Instructions



We kindly request that you read this information carefully before starting to use the product. Keep this manual safe!

1. Set the number buttons to the original code 0-0-0
 2. Press the reset button A with a screwdriver until you hear a “click” sound
 3. Create your personal number combination by turning the number buttons B, for example 7-7-7
 4. Press button C in the direction of the arrow. The reset button A is back when you hear the “click” sound again
- You have now set your personal code. Don't forget this code. This is not covered by the warranty. You also need this code to change your personal combination again. Repeat the steps above to reset the number.

Warning: If the TSA007 cylinder has been opened, be sure to relock it. You do this by turning the TSA007 cylinder to the red dot in the direction of the arrow (any object that can be inserted into it is suitable for this). Ozocozy BV cannot be held responsible for any damage caused by improper, incorrect or unwise use. Read and understand this manual completely.

Features

- **Outer material:** ABS, sturdy material for hard protective cases, easy to clean, with 4 pcs of corner protection, fixed by rivets
- **Lining:** 210D Oxford fabric easy to clean, water resistant, tearproof, durable and resistant to abrasion
- **Color:** grey with elastic straps
- **Telescopic handle:** material: aluminium alloy, inside steel
- **Carry handle** on the side of each suitcase
- **Design:** cross stripes
- **Wheels:** 4 twin wheels made of TPU with PU coating, color: black /white size: ø60mm, 360° rotatable.
- **TSA zipper lock** – basic

Please note: don't tie a luggage girth too tight to prevent bumps or broken parts.

Documents / Resources



[OZOCOZY TSA007 Password Locks](#) [pdf] Instructions
TSA007 Password Locks, TSA007, Password Locks, Locks

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.