

Pablo Contour LED Floor Lamp Instruction Manual

Home » Pablo » Pablo Contour LED Floor Lamp Instruction Manual

Contents

- 1 Pablo Contour LED Floor Lamp
- **2 CONTOUR MODELS**
- **3 CONTOUR TABLE MODELS**
- **4 SWITCH FUNCTION AND USB**

CHARGING

- **5 CARE INSTRUCTIONS**
- **6 CONTOUR FLOOR MODEL**
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**

Pablo[®]


Pablo Contour LED Floor Lamp



CONTOUR MODELS



CONTOUR TABLE MODELS




NOTE: CONTOUR TABLE USES 14.4W POWER SUPPLY

- A. N AMERICA
- **B.** UK
- **C**. EU
- **D**. AU

NOTE: CONTACT MANUFACTURER FOR ADDITIONAL PLUG TYPE REQUIREMENTS

SWITCH FUNCTION AND USB CHARGING



SWITCH FUNCTION

PRESS SWITCH BRIEFLY TO CYCLE THROUGH HIGH, LOW AND OFF. PRESS AND HOLD SWITCH TO ACTIVATE FULL RANGE DIM CONTROL. RELEASE FINGER FROM SWITCH WHEN DESIRED LIGHT LEVEL IS REACHED.

USB SPECIFICATIONS

SINGLE 5.0V USB OUTPUT SUPPORTS CHARGING FOR SMARTPHONES, TABLETS AND OTHER MOBILE DEVICES. USB 2.0 OR 1.1 STANDARD CORD REQUIRED (CORD NOT INCLUDED)

• OUTPUT VOLTAGE: 5VDC + - 5%


• **OUTPUT CURRENT:** 1A MAX

NOTE CONTOUR WILL CONTINUE TO CHARGE YOUR MOBILE DEVICE EVEN WHEN LAMP IS IN THE "OFF" POSITION. PLEASE REFER TO YOUR MOBILE DEVICE'S USER MANUAL FOR COMPATIBILITY AND CHARGING TIME. PLEASE REFRAIN FROM LEAVING YOUR DEVICE PLUGGED IN FOR LONGER THAN THE RECOMMENDED TIME, OTHERWISE IT MAY RESULT IN OVER CHARGING.

CARE INSTRUCTIONS

WIPE CLEAN WITH A SOFT DAMP CLOTH. AVOID AMMONIA-BASED CLEANERS. CONTOURS HARDWOOD INTERIORS ARE FINISHED WITH A NEUTRAL PASTE WAX, WE RECOMMEND REFINISHING ONCE A YEAR WITH HOWARD CITRUS-SHIELD. WAX FINISH WILL WEAR WITH USE, TOUCH UP FINISH AS NEEDED. TO REAPPLY WAX FOLLOW THE INSTRUCTIONS ON WAX FINISH CONTAINER. CONTACT US WITH REFINISHING QUESTIONS.

CONTOUR FLOOR MODEL



NOTE: CONTOUR FLOOR USES 24W POWER SUPPLY

- A. N AMERICA
- **B.** UK
- C. EU
- **D.** AU

NOTE: CONTACT THE MANUFACTURER FOR ADDITIONAL PLUG TYPE REQUIREMENTS.

DIMMER FUNCTION

PRESS DIMMER BRIEFLY TO CYCLE THROUGH HIGH, LOW AND OFF. PRESS AND HOLD DIMMER TO ACTIVATE FULL RANGE DIM CONTROL. RELEASE THE DIMMER WHEN DESIRED LIGHT LEVEL IS REACHED.

CARE INSTRUCTIONS


WIPE CLEAN WITH A SOFT DAMP CLOTH. AVOID AMMONIA-BASED CLEANERS.

INFO@PABLODESIGNS.COM

888 MARIN STREET SAN FRANCISCO, CA 94124

PABLODESIGNS.COM

Documents / Resources



<u>Pablo Contour LED Floor Lamp</u> [pdf] Instruction Manual Contour LED Floor Lamp, LED Floor Lamp, Floor Lamp, Lamp

References

• P Pablo

Manuals+,