

**PALIO**  
Double Torch  
Jet Lighter



## Palio Double Torch Jet Lighter Instructions

[Home](#) » [Palio](#) » Palio Double Torch Jet Lighter Instructions 

### Contents

- [1 Palio Double Torch Jet Lighter](#)
- [2 CARING FOR YOUR LIGHTER](#)
- [3 Documents / Resources](#)
  - [3.1 References](#)

**PALIO**

### Palio Double Torch Jet Lighter



Palio PRO™ is designed to be the best choice for your everyday accessory. The modern styling of the Palio

PRO™ line is sure to be the envy of all your friends. Each accessory is developed and designed to deliver the highest quality performance at an affordable price for all.

## **LIMITED LIFETIME WARRANTY**

Warranty covers manufacturing defects, but does not cover wear and tear from normal use. Do not disassemble your accessory in an attempt to repair it yourself, as this will void the warranty coverage. For more information regarding your warranty or to file a claim, please contact (888) 795-4839. Please note that a processing fee will apply to all claims.

- Palio PRO™ 3350 Enterprise Ave., #120, Weston, FL 33331 USA
- [www.paliolighter.com](http://www.paliolighter.com)

## **ADJUSTING FLAME LEVEL**

Turn the fuel adjustment wheel on the bottom of the lighter towards the (+) mark to increase the flame and turn the wheel towards the (-) to decrease the flame to achieve the desired height.

## **CARING FOR YOUR LIGHTER**

### **Lighters not in use/Lighters in Storage**

Before storing lighters, empty all fuel. If your lighter has not been used for a long period and it appears to be no longer working, empty all fuel from the lighter by following step 1 in the fueling/refueling instructions, then refuel and adjust the flame level. This should correct any problems.

## **CLEANING YOUR LIGHTER**

Occasionally ash, dust, and/or lint can clog the burner, causing the lighter to malfunction. To clear obstructions such as these, blow a burst of air into the burner.

### **Everyday Storage of your Lighter**

To prevent scratches and dings to your lighter, handle it with care. Do not drop on hard surfaces.

## **SCAN HERE**



## **TO FOLLOW US**

## **LIGHTER OPERATING INSTRUCTIONS FILLING AND REFILLING**

### **WARNING:**

PLEASE READ BEFORE OPERATING YOUR PALIO PRO™ LIGHTER!

### **KEEP OUT OF REACH OF CHILDREN & AWAY FROM ALL OPEN FLAME SOURCES**

### **DANGER**

When filled, the lighter will contain flammable fluid and/or gas under pressure. Handle carefully. Ensure that the flame is extinguished before attempting to fill. Never attempt to ignite the lighter while refilling. Read butane canister warning labels. Only refill the lighter in a well-ventilated area. Hold lighter away from face and clothing while filling. Never fill lighter around any heat source, sparks, or flame. Never puncture or put in fire. Never expose to heat above 50°C (120° F) or to prolonged sunlight. XIKAR® Premium Butane is highly recommended, and a lower-quality butane has been known to clog lighters. Release all tank pressure by pressing on the inlet valve with a small screwdriver or a XIKAR® Tune-Up Tool. Repeat several times until all fuel/gas pressure is released. Use care to avoid damage to the fill valve. Set flame adjustment to lowest setting (-). Hold the lighter in an upside-down position and insert the butane tank tip directly on the fuel valve. Ensure proper docking between the can tip and the refill valve. Press down firmly for about 5 seconds. Before igniting the lighter, wait 3-4 minutes to allow excess butane to evaporate and gas inside the lighter to reach room temperature. Set the flame level to desired height by turning the flame adjustment wheel. Turn toward the(+) mark to increase flame and turn the wheel towards the(-) mark to decrease. Do not keep lit for more than 10 seconds.

### **FILLING & REFILLING LIGHTER (continued)**

Release all tank pressure on the inlet valve with a small screwdriver or a XIKAR® Tune-Up Tool. Hold the lighter vertically while bleeding valve. Repeat this several times until all fuel/gas pressure is released. Set flame adjustment to lowest setting(-). Turn the lighter in an upside-down position and insert the butane tank tip directly on the fuel valve. Press down firmly for about 5 seconds. Before igniting the lighter, wait 3-4 minutes. This allows excess butane to evaporate & gas inside to reach room temperature. Set the flame level to the desired height by turning the flame adjuster wheel.

### **IGNITING THE LIGHTER**

A simple push on the ignition switch ignites a powerful flame over 2,000 degrees. This flame can be nearly invisible in bright light, so proper care is recommended.

### **TAKE CARE NOT TO TOUCH THE LIGHTER TOP AFTER IGNITION**

To avoid heat buildup, do not use it in any situation that would require a continuous flame for more than 10 seconds. The lighter may become too hot and cause harm to the lighter and/ or the user.

### **EXTINGUISHING THE FLAME**

Releasing pressure from the ignition button of the lighter immediately extinguishes the flame by stopping fuel flow. If the flame continues, the flame level is set too high and should be adjusted by turning the adjustment wheel on the bottom of the lighter towards the(-) position. Be sure the flame is out after use.

### **Documents / Resources**



[Palio Double Torch Jet Lighter](#) [pdf] Instructions  
Antares Jet Zilver, Polaris Jet Silver, Double Torch Jet Lighter, Torch Jet Lighter, Jet Lighter, Ligh  
ter

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.