



Home » Support » PARTPHONER PAFP087AB1 Boho Floor Lamp User Guide 📆

### Contents [ hide ]

- 1 PARTPHONER PAFP087AB1 Boho Floor Lamp
- 2 INTRODUCTION
- 3 SPECIFICATIONS
- 4 FEATURES
- **5 SETUP GUIDE**
- **6 CARE & MAINTENANCE**
- 7 TROUBLESHOOTING
- 8 PROS & CONS
- 9 WARRANTY
- 10 FREQUENTLY ASKED QUESTIONS
- 11 VIDEO PRODUCT OVERVIEW
- 12 References



PARTPHONER PAFP087AB1 Boho Floor Lamp



### INTRODUCTION

The PARTPHONER PAFP087AB1 Boho Floor Lamp is a chic and useful lighting option that combines contemporary functionality with bohemian flare. This floor lamp, which was introduced by PARTPHONER in early 2024, is a great option for customers who are concerned about their decor because it is reasonably priced at \$35.99. With its rattan base, powder-coated finish, and two lampshade options (woven rattan and linen fabric), this 67-inch tall lamp gives you complete control over the atmosphere of your space. The pull chain makes it simple to choose between the three color temperatures (2700K, 4000K, and 6000K) that the accompanying 9W LED bulb delivers. Additionally, the bulb has a memory function that saves the previous setting you choose. This lamp's compact shape allows it to be easily placed in offices, children's rooms, bedrooms, or nooks. Its integrated design and tool-free assembly make it easy to use, and its aesthetic appeal complements both bohemian and minimalist environments. It combines cost, usefulness, and charm in a stylish way.

# **SPECIFICATIONS**

Product Name	PARTPHONER PAFP087AB1 Boho Floor Lamp		
Price	\$35.99		
Finish Type	Powder Coated		
Base Material	Rattan		
Bulb Base	E26		
Dimensions	8.66" D x 8.66" W x 67" H		
Lamp Type	Floor Lamp		
Power Source	Corded Electric		
Connectivity	USB		
Light Sources	1		
Included Compone nts	Shade, LED Bulb, Manual		
Bulb Included	Yes, 9W LED bulb		
Color Temperature	2700K / 4000K / 6000K (3CCT)		
Light Control	Pull Chain Switch (double pull within 10 seconds to change te mp)		
Memory Function	Yes – Remembers last color setting		
Lampshade Style	Double-shade: Handwoven rattan & linen (boho and minimalist mix)		
Assembly	Tool-free, under 10 minutes		

Design Benefits	Space-saving, blends with various décor styles
Ideal Placement	Living Room, Bedroom, Office, Kids Room, next to sofa/couch/ side table
Warranty/Support	12-month quality service with replacement or refund options



# **FEATURES**

- **Double Shade Design:** Combine minimalist or bohemian styles with the two rattan and linen drum lampshades for visual versatility.
- Three Lighting Modes: To accommodate any mood or space, this 9W LED bulb has three color temperatures that can be adjusted: 2700K, 4000K, and 6000K.

# 3 Color Temperature Floor Lamp (Bulb Included)



- **Pull Chain Control:** Two pushes in ten seconds can quickly switch between light modes thanks to an easy-to-use pull chain.
- Memory Function: Saves time and effort by automatically remembering the color temperature you last used.
- Integrated Lampshade Assembly: The lampshade's one-piece design makes assembly easy and tidy by doing away with the need for tools.
- **Powder-Coated Finish:** This long-lasting finish offers a sleek, contemporary appearance while preventing scratches.
- Space-Saving Footprint: Its 8.66" base makes it ideal for nooks, little spaces, or beside couches and armchairs.
- Adaptable Location: Looks great in home offices, reading nooks, bedrooms, living rooms, and children's rooms.
- **E26 Bulb Base Compatibility:** Enables standard-sized bulbs to be used in future bulb replacements.
- **Sturdy Base:** Made to stand solidly with less wobbling, this base is safe for families with kids or pets.

- **High Profile:** Standing 67" tall, it offers sufficient light coverage without being obtrusive.
- **Boho-Chic Style:** Enhances earthy, warm décor themes by fusing clean fabric pieces with the natural texture of rattan.
- **Corded Electric:** Provides consistent power without requiring battery changes or recharging.
- Energy-Efficient Lighting: A 9W LED bulb produces brilliant, efficient lighting while using less energy.
- **Customer Support Guarantee:** Supported by a quality assurance service that includes refunds and replacements for a period of 12 months.



#### **SETUP GUIDE**

- **Unpack Components:** Gently take out of the packing the LED bulb, power wire, shades, pole segments, and lamp base.
- Examine the contents: Make sure the base, pole sections, fabric and rattan shades,

LED bulb, and instruction booklet are all included.

- To put the pole together: Screw its sections together firmly until it is completely upright.
- Secure the Base: To stop the pole from swaying, insert the completely completed pole into the base and tighten as directed.
- Attach Lampshade: Gently slide the built-in lampshade over the light socket.
- Select Your Shade Style: Depending on your particular décor preferences, choose between using the rattan, linen, or both tones.
- LED Bulb Insertion: Gently screw the 9W LED bulb into the E26 base.
- Connector the Cord in: Attach the power connector to a wall outlet close by.
- First Test: To turn on the light, pull the chain once.
- **Set Color Temperature:** To choose between 2700K (warm), 4000K (neutral), or 6000K (cool white), pull the chain twice in ten seconds.
- Allow Memory Function: To activate the memory, select your favorite lighting tone and leave it on for a short while.
- The light should be positioned: Where it fits snugly, such as next to furniture or in a corner.
- Hide Cables: To keep your area tidy and secure, tuck or tape down any exposed cords.
- Before using: Make sure the lamp is securely erect and the base is level.
- Savor Your Lighting: After everything is put together, take pleasure in a chic and useful lighting solution that is tailored to your space.

# **CARE & MAINTENANCE**

- Dust Frequently: Every week, dust the base and shades with a soft microfiber cloth or duster.
- Steer clear of harsh cleaners: Avoid using bleach or other abrasive substances on the cloth or rattan shade.
- Vacuum Gently: To clean in between rattan weaves without causing any damage to the material, use a handheld vacuum with a low power.
- Clean Fabric Shade: Use a gentle towel to pat dry after spot cleaning with a little soap and water if necessary.
- Verify Bulb Fit: Make sure the LED bulb is never flickering and is always firmly in

place.

- If the original bulb burns out: Replace it with a normal E26 base bulb, preferably an LED one.
- Avoid Overloading Outlet: To prevent electrical risks, plug the lamp into an outlet without overloading power strips.
- Keep Dry: Avoid placing the lamp in damp areas, such as bathrooms, or expose it to moisture.
- Examine Cord: Continually look for wear or damage on the power cord. If frayed or cracked, replace.
- **Don't Tilt:** To avoid tilting or breaking the construction, keep the lamp upright.
- Store Properly: If disassembling for storage, pack components gently and don't put too much pressure on items that are shaded or made of rattan.
- **Tighten Occasionally:** To guarantee stability, periodically inspect and tighten the base connection and pole segments.
- Avoid Direct Sunlight: Extended exposure to the sun can deteriorate natural rattan or fade fabrics.
- **Unplug When Not in Use:** To prolong the life of the lightbulb and avoid electrical problems, unplug the lamp if it will be stored or not used for weeks.
- Contact Help If You Need It: For any replacement or defect issues, use the 12-month service guarantee through a buyer-seller correspondence.

# **TROUBLESHOOTING**

Issue	Possible Cause	Recommended Solution	
Lamp doesn't turn on	Loose plug or disconnected cord	Ensure plug is secure in outlet	
Bulb not lighting	Faulty or unseated bulb	Reinsert or replace bulb	
Pull chain unresponsi ve	Internal switch issue	Gently pull, check for mechanic al failure	
Color temperature no t changing	Chain not pulled twice within 10 seconds	Pull chain twice quickly to toggl	

Issue	Possible Cause	Recommended Solution	
Flickering light	Loose bulb or unstable volt age	Tighten bulb or try a different o	
Shade appears unev	Improper installation or ben	Adjust the lampshade carefully by hand	
Weak lighting	Room too large or bright set ting	Use in smaller room or add add itional lighting	
Lamp leans or wobbl	Base not fully tightened	Check and stabilize base	
Rattan shade fraying	Manufacturing defect or han dling issue	Contact support for replaceme nt	
Memory function not working	Power interruption or defective bulb	Reset lamp and test bulb again	

### **PROS & CONS**

#### **PROS**

- Includes dual rattan and fabric shades for versatile styling
- Comes with a 3-color temperature LED bulb
- Space-saving and fits easily into small corners
- Pull-chain switch with memory function
- Tool-free, 10-minute assembly

#### **CONS**

- Only one light source included
- Limited brightness adjustment beyond 3 presets
- Rattan material may not suit all decor themes
- Pull chain can feel slightly fragile with frequent use
- No smart connectivity or app support

#### WARRANTY

The PARTPHONER Boho Floor Lamp comes with a **12-month** limited warranty. This warranty covers manufacturing defects in materials or workmanship under normal residential use. It does not cover damage due to accidents, misuse, unauthorized modifications, or improper installation. For replacements or support, customers should contact PARTPHONER through the buyer-seller messaging system, providing proof of purchase and details of the issue.

## FREQUENTLY ASKED QUESTIONS

Does the PARTPHONER PAFP087AB1 Boho Floor Lamp come with a bulb?

It includes a 9W LED bulb with 3 color temperature settings: 2700K, 4000K, and 6000K.

How do I change the color temperature on the PARTPHONER PAFP087AB1 lamp?

Pull the chain switch twice within 10 seconds to cycle through the three color temperatures.

What is the height of the PARTPHONER PAFP087AB1 Boho Floor Lamp?

The lamp stands 67 inches tall, making it ideal for reading and ambient lighting in various spaces.

Is the PARTPHONER PAFP087AB1 lamp compatible with smart bulbs?

It has a standard E26 bulb base, so it is compatible with most E26 smart bulbs, though it comes with its own LED bulb.

What should I do if the PARTPHONER PAFP087AB1 does not turn on?

Ensure the plug is secure, the pull chain is functioning, and the bulb is properly seated. Try another E26 bulb to rule out a faulty bulb.

How do I know the PARTPHONER PAFP087AB1 LED bulb needs replacing?

If the light flickers, wont turn on, or the color won't change with the pull chain, the bulb might be faulty and should be replaced.

Can I replace the shade on the PARTPHONER PAFP087AB1 lamp?

The included rattan and fabric shades are integrated but removable, so you can swap them for compatible shades if desired.

## **VIDEO – PRODUCT OVERVIEW**

https://manuals.plus/wp-

content/uploads/2025/06/PARTPHONER-PAFP087AB1-Boho-

Floor-Lamp-User-Guide.mp4

#### References

- User Manual
- PARTPHONER
- B0CRN6LYVM, Boho Floor Lamp, PAFP087AB1, PARTPHONER, PARTPHONER PAFP087AB1, user guide

# Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name		
Email		
<u> </u>		
Website		
☐ Save my name, email, and website in this browser for the next time I com	ment.	
Post Comment		
Search:		
e.g. whirlpool wrf535swhz	Search	

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.