



Party ASTRO6 LED Light Effect Astro User Manual

[Home](#) » [Party](#) » Party ASTRO6 LED Light Effect Astro User Manual 

Contents

- [1 Party ASTRO6 LED Light Effect Astro](#)
- [2 BEFORE YOU BEGIN](#)
- [3 Safety Instructions](#)
- [4 OPERATION](#)
- [5 Specifications](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



Party ASTRO6 LED Light Effect Astro



Ref.: PARTY-ASTRO6 (15-1439PLS)

IMPORTANT NOTE: Electric products must not be put into household waste. Please bring them to a recycling center. Ask your local authorities or your dealer about the way to proceed.
Imported from China by: LOTRONIC SA Avenue Zénobe Gramme 9 1480 Saintes Belgium

BEFORE YOU BEGIN

Unpacking Instructions

Immediately upon receiving a fixture, carefully unpack the carton, check the contents to ensure that all parts are present and have been received in good condition. Notify immediately your dealer and retain packing material for inspection if any parts appear to be damaged from shipping or the carton itself shows signs of mishandling. Keep the carton and all packing materials. In the event that a fixture must be returned for repair, it is important that the fixture be returned in the original box and packing.

Safety Instructions

Please read these instructions carefully, they include important information about the installation, usage and maintenance of this product.

- Please keep this User Guide for future reference. If you sell the unit to another user, be sure that he also receives this instruction booklet.
- Always make sure that you are connecting to the proper voltage, and that the line voltage you are connecting to is not higher than that stated on the bottom of the fixture.
- This product is intended for indoor use only!
- To prevent risk of fire or shock, do not expose fixture to rain or moisture. Make sure there are no flammable materials close to the unit while operating.
- The unit must be installed in a location with adequate ventilation, at least 20in (50cm) from adjacent surfaces. Be sure that no ventilation slots are blocked.
- Always disconnect from power source before servicing or replacing fuse and be sure to replace with same fuse size and type.
- Maximum ambient temperature (Ta) is 104° F (40°C). Do not operate the fixture at temperatures higher than

this.

- In the event of a serious operating problem, stop using the unit immediately. Never try to repair the unit by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. Always use the same type of spare parts.
- Don't connect the device to a dimmer pack.
- Make sure the power cord is never crimped or damaged.
- Never disconnect the power cord by pulling or tugging on the cord.
- Avoid direct eye exposure to the light source while it is on.

DISCONNECT DEVICE

Where the MAINS plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.

OPERATION


Plug the unit into an appropriate wall outlet and it starts working. Unplug the unit to switch it off.

Specifications

- Voltage:90-240V / 50-60Hz
- Light source: 6pc of 1W LED RGBWAV
- Rotation angle 180°
- Max. Ta.....40°C
- Dimensions.....185 (L) × 185 (W) × 150 (H)mm
- N.W:500g

©Copyright LOTRONIC 2017

Documents / Resources

	<p>Party ASTRO6 LED Light Effect Astro [pdf] User Manual ASTRO6, LED Light Effect Astro</p>
---	---