



partyrent com 1767 Ice Cube Maker User Manual

[Home](#) » [partyrent.com](#) » partyrent com 1767 Ice Cube Maker User Manual 



partyrent.com

we create atmosphere

User manual

1767 Ice cube maker ca 2.5 kg per hour

Contents

- [1 Safety instructions:](#)
- [2 Switch on:](#)
- [3 Switch off:](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

Safety instructions:

- Do not place the device in the immediate vicinity of flammable objects.
- Place the device on a flat and horizontal surface.
- Never cover the entire device or the ventilation openings during use.
- Never leave the powered device turned on unattended.
- Make sure that the mains plug and all electrical components (if not designed for this purpose) do not come into contact with water.
- Always have electrical installations commissioned by a specialist.
- Local regulations and standards must be observed during installation.

- Do not use devices with a damaged power cord.
- Never disconnect the mains connection by pulling the cable. So always grab the plug to disconnect the mains connection.
- Some parts of the device may become hot during use.
- Only transport the device when it is switched off.

Switch on:

1. Connect the device to the power source (16A, 230V).
2. Connect water supply and drainage
3. Pour approximately 1 – 1.5 L of water behind the slats
4. Switch on the device


Switch off:

1. Disconnect the device from the power source, and from water supply and drainage
2. Empty the device completely



Berlin | Bocholt | Bremen | Dortmund | Frankfurt | Friborg | Hamburg | Hanover |
Kassel | Leipzig | Stuttgart | Basel | Arnhem | Luxembourg | Oslo | Malmo | Stockholm

Documents / Resources

	<p>partyrent.com 1767 Ice Cube Maker [pdf] User Manual 1767, 1767 Ice Cube Maker, Ice Cube Maker, Cube Maker, Maker</p>
---	---