



partyrent com 1817 Cool Display Case with 2 Flaps User Manual

[Home](#) » [partyrent.com](#) » partyrent com 1817 Cool Display Case with 2 Flaps User Manual 



User manual 1817 Cool display case with 2 flaps
L120*W47*H52 cm

Contents

- 1 Safety instructions:
- 2 Switch on:
- 3 Switch off:
- 4 Documents / Resources

Safety instructions:

- Do not place the device in the immediate vicinity of flammable objects.
- Place the device on a flat and horizontal surface.
- Never cover the entire device or the ventilation openings during use.
- Never leave the powered device turned on unattended.
- Make sure that the mains plug and all electrical components (if not designed for this purpose) do not come into contact with water.
- Always have electrical installations commissioned by a specialist.
- Local regulations and standards must be observed during installation.
- Do not use devices with a damaged power cord.
- Never disconnect the mains connection by pulling the cable. So always grab the plug to disconnect the mains connection.

- Some parts of the device may become hot during use.
- Only transport the device when it is switched off.

Switch on:

1. Connect the device to the power source (16A, 230V).
2. Switch on cooling (select temperature with SET key and arrow keys)
3. Device is ready for use after a pre-cooling time of 5 – 15 minutes

Switch off:

1. Switch off the device and disconnect it from the power source

Berlin

Documents / Resources

	<p>partyrent.com 1817 Cool Display Case with 2 Flaps [pdf] User Manual 1817 Cool Display Case with 2 Flaps, 1817, Cool Display Case with 2 Flaps, Cool Display Case , Display Case, Case</p>
--	--