



[Home](#) » [Patiojoy](#) » **PATIOJOY HW70915 Wicker Side Table Installation Guide** 

Contents [[hide](#)]

- [1 PATIOJOY HW70915 Wicker Side Table](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 PRODUCT OVERVIEW](#)
- [5 HARDWARE TOOLS](#)
- [6 ASSEMBLY INSTRUCTION](#)
- [7 Return / Damage Claim Instructions](#)
- [8 FAQs](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)

PATIOJOY

PATIOJOY HW70915 Wicker Side Table



Specifications

- A x2
- B x2
- C x1
- Table top / Plateau de table (D x1)
- Support bar of table / Barre de support de la table
- 1 x8 M6x15mm
- 2 x8 M6x30mm
- 3 x16 M16x1mm

Product Usage Instructions

Assembly:

1. Identify all components listed in the specifications. Place the table top on a flat surface.
2. Attach the support bar of the table to the underside of the table top using the provided screws.
3. Ensure not to fasten the screws completely during assembly to avoid misalignment issues.
4. Once all parts are assembled, tighten all screws securely.


Maintenance:

Regularly check the tightness of screws and connections to ensure stability and safety of the table set.




Cleaning:

Use a damp cloth and mild detergent to clean the table top. Avoid using harsh chemicals that may damage the surface.

PRODUCT OVERVIEW



HARDWARE TOOLS



(A) x2


Side frame of table
/Cadre latéral de table

(B) x2

Side frame of table
/Cadre latéral de la table

(C) x1

Table top
/Plateau de table



(D) x1

Support bar of table
/Barre de support de la table

(1) x8

M6x15mm

(2) x8

M6x30mm




(3) x16

M16x1mm

(4) x1


Allen key
/Clé Allen

ASSEMBLY INSTRUCTION





Please don't fasten the screw completely during assembly process. It will be likely to




lead to an assembling problem that screw hole position is not aligned. You can fasten completely when all parts have been assembled.




2



3





Return / Damage Claim Instructions

- DO NOT discard the box j original packaging. In case a return is required, the item must be returned in original box. Without this your return will not be accepted.
- Take a photo of the box markings.
- A photo of the markings (text) on the side of the box is required in case a part is needed for replacement. This helps our staff identify your number to ensure you receive the correct parts.
- Take a photo of the damaged part (if applicable).
- A photo of the damage is always required to file a claim and get your replacement or refund processed quickly- Please make sure you have the box even if it is damaged.
- Send us an email with the images requested. Email us directly from marketplace where your item was purchased with the attached images and a description of your claim-

FAQs

Q: What should I do if I encounter misalignment issues during assembly?

A: If you find that the screw hole positions are not aligned, do not fully fasten the screws. Adjust the parts gently until they align properly before tightening the screws securely.

Q: Can I disassemble the table set for storage or transportation?

A: Yes, you can disassemble the table set by following the assembly instructions in reverse. Store components in a dry and secure place to prevent damage.

Documents / Resources



- [PATIOJOY HW70915 Wicker Side Table \[pdf\]](#) Installation Guide
HW70915, HW70915 Wicker Side Table, HW70915, Wicker Side Table, Side Table, Table

References

- [User Manual](#)

📎 HW70915, HW70915 Wicker Side Table, Patiojoy, SIDE TABLE, table, Wicker Side

📁 Patiojoy Table



Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.