



[Home](#) » [PCE Instruments](#) » **PCE INSTRUMENTS PCE-LM 4 Lux Meter User Manual** 

Contents [[hide](#)]

- [1 PCE INSTRUMENTS PCE-LM 4 Lux Meter](#)
- [2 SAFETY](#)
- [3 FEATURES](#)
- [4 SPECIFICATIONS](#)
- [5 METER DESCRIPTION](#)
- [6 LCD DISPLAY DESCRIPTION](#)
- [7 OPERATION INSTRUCTION](#)
- [8 ACCESSORIES](#)
- [9 DISPOSAL](#)
- [10 CONTACT INFORMATION](#)
- [11 FAQs](#)
- [12 Documents / Resources](#)
 - [12.1 References](#)



PCE INSTRUMENTS PCE-LM 4 Lux Meter



SAFETY

Read the following safety information carefully before attempting to operate or service the meter. Use the meter only as specified in this manual; otherwise, the protection provided by the meter may be impaired.

Environmental conditions:

- **RH≤90%** (Non-Condensation)
- **Operating Temperature:** -20°C ... 60°C
- **Storage Temperature:** -20°C ... 60°C

Maintenance

- Repairs or servicing not covered in this manual should only be performed by qualified personnel.
- Wipe the unit with a dry soft cloth. Do not use abrasives or solvents on this instrument.

Safety Symbol



APPLICATION

- This Light Meter is designed to meet the measurement requirements of safety Engineers, Health, Industrial safety offices and light quality control in various environments like factory, school, construction, etc.

FEATURES


- High accuracy and fast response time
- HD color LCD display
- Ambient temperature measurement, °C/°F unit selectable
- MAX/MIN/HOLD
- Selectable measurement units LUX/FCREC
- Memory for 12 readings
- Magnet support

SPECIFICATIONS

Display	4 digits color LCD display
Measuring range	0 Lux~200K Lux, 0Fc~20KFc
Resolution	<1000 (0.1), >1000(1.0)
Accuracy	±3% rdg±8 dgts (<10,000Lux), ±4% rdg±10 dgts (>10,000Lux)
Temperature Range	-20°C ... 70°C /-4°F ... 158°F
Temperature Accuracy	±1.5°C /2.7°F
Data update	500ms

Over range indication	LCD displays „-OL-“
Units	LUX/FC
REC	Memory for 12 readings
HOLD/MAX/MIN	√
Magnet support	√
Battery Life	60 hours
Auto power off	With cover open, the meter shuts off automatically after 15 minutes inactivity
	With cover shut, the meter shuts off automatically after 1 minutes inactivity
Power supply	2*1.5V “AAA” batterie
Operating Conditions	-20°C ... 60°C / -4°F ... 140°F, 10% RH ...90% RH
Storage Conditions	-20°C ... 60°C / -4°F ...140°F, 10% RH ... 75%RH
Dimension(L*W*H)	174.5 × 80 × 31 mm
Weight	31g

METER DESCRIPTION



1. Sensor protective cover
2. Sensor
3. HOLD/MAX/MIN selection key
4. LCD display
5. Power ON/OFF key & REC key
6. Temperature sensor hole
7. Battery cover/magnetic area

LCD DISPLAY DESCRIPTION



1. Temperature display area
2. REC symbol
3. HOLD/MAX/MIN symbol
4. Illumination reading area

5. Illumination unit
6. Low battery symbol
7. Temperature unit symbol

OPERATION INSTRUCTION

Power ON/OFF function

1. Install the battery and open the protective cover, the meter will automatically turn on to measure the light intensity.
2. In the OFF mode while protective cover's removed, short press „E“ key to manually turn on the meter. Press and hold the „E“ key for 3 seconds to turn off the instrument manually.
3. The meter shuts off automatically after 15 minutes inactivity.

HOLD/MAX/MIN function

1. In measuring mode, short press the „H“ key, the „HOLD“ symbol is displayed on the top of the screen, which indicates the data is freezed.
2. Press the „H“ key again, the „MAX“ symbol will be displayed at the top of the screen, the captured maximum light reading will be displayed on the LCD
3. Press the „H“ key again, the „MIN“ symbol will be displayed at the top of the screen, and the captured minimum light reading will be displayed on the LCD
4. Press the „H“ key again, the meter will exit the hold/max/min mode and return to normal measurement mode.
5. Press and hold the „H“ key for 3 seconds, the instrument will clear the record MAX/MIN value and recapture the MAX/MIN value.

REC memory function


1. In the ON mode, short press „E“ key, the instrument enters into REC mode, and the „REC“ symbol is displayed on the top left of the screen. Press „H“ key to view the record 1 to 12 measurement values in turn.
2. In the measurement mode, press „E“ and „H“ at the same time to store the desired values, which can be stored in 12 groups in cyclic memory.

°C / °F. Conversion function

- In the ON mode, open the battery cover, short press „S“ key to convert the temperature unit °C / °F.

Lux/Fc conversion function

- In the ON mode, open the battery cover, long press the „S“ key to convert the illuminance unit Lux/Fc



NOTES

1. The instrument has been calibrated before delivery. Please do not modify the calibration parameters without professional equipment and personnel.
2. [Note] This instrument has been well calibrated before delivery, the recommended calibration interval is one year.
3. Repair or maintenance should be done by professionals, not by manuals alone.
4. Wipe the case with a cloth regularly, do not use solvents or detergents to clean the meter
5. Please take out the battery when not using for a long time to avoid the battery liquid leaking out and corroding the meter.
6. When the battery power is low, LCD will show „“, symbol, then you must replace the new battery to avoid affecting the measurement accuracy.
7. Please do not use it in high temperature and high humidity place.

ACCESSORIES

1. User's manual
2. 2* 1.5V "AAA" batteries
3. Carrying pouch

DISPOSAL

For the disposal of batteries in the EU, the (EU) 2023/1542 directive of the European Parliament applies. Due to the contained pollutants, batteries must not be disposed of as household waste. They must be given to collection points designed for that purpose. In order to comply with the EU directive 2012/19/EU we take our devices back. We either re-use them or give them to a recycling company which disposes of the devices in line with law. For countries outside the EU, batteries and devices should be disposed of in accordance with your local waste regulations. If you have any questions, please contact PCE Instruments.

CONTACT INFORMATION

PCE INSTRUMENTS CONTACT INFORMATION

- **Germany**

- PCE Deutschland GmbH
- Im Langel 26
- D-59872 Meschede

- **Deutschland**

- **Tel.:** +49 (0) 2903 976 99 0
- **Fax:** +49 (0) 2903 976 99 29
- info@pce-instruments.com
- www.pce-instruments.com/deutsch

- **United Kingdom**

- PCE Instruments UK Ltd
- Trafford House
- Chester Rd, Old Trafford Manchester M32 0RS

- **United Kingdom**

- **Tel:** +44 (0) 161 464902 0
- **Fax:** +44 (0) 161 464902 9
- info@pce-instruments.co.uk
- www.pce-instruments.com/english

- **The Netherlands**

- PCE Brookhuis B.V.
- Twentepoort West 17
- 7609 RD Almelo

- **Nederland**

- **Telefoon:** +31 (0)53 737 01 92
- info@pcebenelux.nl
- www.pce-instruments.com/dutch.

- **France**

- PCE Instruments France EURL
- 23, rue de Strasbourg
- 67250 Soultz-Sous-Forets France
- **Téléphone:** +33 (0) 972 3537 17
- **Numéro de fax:** +33 (0) 972 3537 18
- info@pce-france.fr
- www.pce-instruments.com/french

- **Italy**

- PCE Italia s.r.l.
- Via Pesciatina 878 / B-Interno 6 55010 Loc. Gragnano
- Capannori (Lucca)

- **Italia**

- **Telefono:** +39 0583 975 114
- **Fax:** +39 0583 974 824
- info@pce-italia.it
- www.pce-instruments.com/italiano

- **United States of America**

- PCE Americas Inc.
- 1201 Jupiter Park Drive, Suite 8 Jupiter / Palm Beach
- 33458 FL

- **USA**

- **Tel:** +1 [561-320-9162](tel:561-320-9162)
- **Fax:** +1 [561-320-9176](tel:561-320-9176)
- info@pce-americas.com
- www.pce-instruments.com/us

Subject to change without notice

User manuals in various languages (français, italiano, español, português, nederlands, türk, polski) can be found via our product search on: www.pce-instruments.com.



FAQs

- **Q: Can I modify the calibration parameters of the instrument?**
 - **A:** It is advised not to modify the calibration parameters without professional equipment and personnel as the instrument has been calibrated before delivery.

Documents / Resources

	PCE INSTRUMENTS PCE-LM 4 Lux Meter [pdf] User Manual PCE-LM 4, PCE-LM 4 Lux Meter, Lux Meter, Meter
---	---

References

- [User Manual](#)

🔍 Lux Meter, Meter, PCE Instruments, PCE-LM 4, PCE-LM 4 Lux

📁 PCE Instruments Meter

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.