



pdk RMW Red Module Wireless Kit Installation Guide

[Home](#) » [pdk](#) » pdk RMW Red Module Wireless Kit Installation Guide 




wireless kit installation
PN: RMW

Contents


- [1 RMW Red Module Wireless Kit](#)
- [2 Documents / Resources](#)

RMW Red Module Wireless Kit

1. Plug the wireless module into the Red 2 board as shown in the image.
Ensure that the wireless module's 20 pins align with the corresponding holes on the Red 2 board. Gently & carefully press the module into the board.



2. Push the threaded end of the antenna wire (connected to the module) through the hole at the top of the Red 2 metal can.
3. Connect the antenna to the antenna wire to the top of the enclosure.
The antenna should point straight up.



Got a question or need help?

801.317.8802 option #2 support@prodatakey.com

REV 05202021

Documents / Resources

	pdk RMW Red Module Wireless Kit [pdf] Installation Guide PDK-RDC-EXP-WIFI, XLR Security, RMW, Red Module Wireless Kit, RMW Red Module Wireless Kit, Module Wireless Kit, Wireless Kit
--	---