

PENTAIR 523317 Intelliconnect Control and Monitoring System **User Manual**

Home » Pentair » PENTAIR 523317 Intelliconnect Control and Monitoring System User Manual





INTELLICONNECT CONTROL® AND MONITORING SYSTEM **User Manual**

Contents

- 1 523317 Intelliconnect Control and Monitoring **System**
- 2 Before you begin
- 3 Let's get started
- **4 Pentair Home App**
- 5 Migration to the Pentair Home App
- 6 Documents / Resources
- **6.1 References**
- **7 Related Posts**

523317 Intelliconnect Control and Monitoring System

Downloading Pentair Home and setting up your IntelliConnect

Before you begin

To start this process, you will need to power down your IntelliConnect. To begin the process, follow these steps:

- 1. Power down at the breaker.
- 2. Verify the green lights on the control panel are turned off. Wait 30 seconds.
- 3. When the machine is turned off, write down the PIF (13 characters) number located on the control panel.
- 4. Turn the control panel on and wait for the LINK light to turn solid green.

5. Make sure the unit is in auto mode.



CAUTION: Failure to follow the next steps exactly may result in equipment damage that will not be covered under the terms and condition of the Limited Warranty. If you require additional assistance in setting up your system, please contact the Technical Support team at (800) 831-7133

Power Down, wait 30 seconds and return power

Let's get started

The following steps will take approximately 10 minutes. Scan the appropriate QR code below so you can download the Pentair Home App on your device or go to your app store and search "Pentair Home."






http://www.in

Download the app

Pentair Home App





Download the Pentair Home App from the App Store (iOS) or Google Play Store (Android).

Once downloaded, open the app and select Skip.

Please enter the email address you are CURRENTLY using to log into your Link2O app.

Chouse featu







Choose Reset. We will send a code to your email.

Enter the Code and set a new p assword which meets the password criteria. Choose Submit


Choose Log In

Login again using email and newly c

h

a

Si




Verify your account informat ion and Save

Set Notifications Preferences

If you allowed SMS texts you will need to Opt-In.

You will then receive Respond with a Y



Review and agree to our ter ms of service

Review and agree to our Privacy Policy


Choose Continue since your I ntelliConnect is already connected.

If an update is ava perform it now. Pla power off your Inta during the update The number must fter the dash. See

Zip code or state information not matching?

Try surrounding zip codes in your surrounding area. This can be fixed later.

Migration to the Pentair Home App



You will be asked if you would like to request remote monitoring. Until this is completely implemented, the user will select SKIP.

You can view equipment which has been added on Devices Tab. If you choose IntelliConnect you will move to a page where you can add equipment if needed. Select CONTINUE.

You can view the eis on your IntelliCor equipment on this s



©2020 Pentair. All Rights Reserved. Confidential property of Pentair. Do not reproduce or distribute without express permission of Pentair.

I indicated Pentair trademarks and logos are property of Pentair. Third party registered and unregistered trademarks and logos are the

property of their respective owners.

©2020 Pentair. All Rights Reserved. Pentair.com

Documents / Resources



<u>PENTAIR 523317 Intelliconnect Control and Monitoring System</u> [pdf] User Manual 523317, Intelliconnect Control and Monitoring System, 523317 Intelliconnect Control and Monitoring System

References

• Pentair

Manuals+,