




92705
SLEEP
N' OINK
PLUSH



Peppa Pig 92705 Sleep N' Oink Plush User Manual

[Home](#) » [Peppa Pig](#) » Peppa Pig 92705 Sleep N' Oink Plush User Manual 

Contents

- 1 [Peppa Pig 92705 Sleep N' Oink Plush](#)
- 2 [INTRODUCTION](#)
- 3 [SPECIFICATIONS](#)
- 4 [WHAT'S IN THE BOX](#)
- 5 [FEATURES](#)
- 6 [SETUP GUIDE](#)
- 7 [CARE & MAINTENANCE](#)
- 8 [TROUBLESHOOTING](#)
- 9 [PROS & CONS](#)
- 10 [WARRANTY](#)
- 11 [FREQUENTLY ASKED QUESTIONS](#)
- 12 [References](#)
- 13 [Related Posts](#)



Peppa Pig 92705 Sleep N' Oink Plush



INTRODUCTION

The Peppa Pig 92705 Sleep N' Oink Plush is a cute and cuddly interactive toy that is meant to help little kids fall asleep with soothing sounds and songs. This plush toy costs \$56.00 and is great for kids 18 months and up. It has dynamic sound that plays relaxing sounds when you squeeze it. This makes going to bed fun and relaxing. This soft and cuddly Peppa Pig plush is 12 inches tall, which is just the right size for little arms to hold during naps or sleep. Because it only weighs 27.22 grams and is powered by 3 AAA batteries, this toy is light and portable, making it easy to take on trips. For kids who love Peppa Pig and need a comfortable nighttime friend to help them sleep, the Slumber N' Oink model is a great choice.

SPECIFICATIONS

Brand Name	Peppa Pig
Price	\$56.00
Model Name	Slumber N' Oink
Model Number	92705
Number of Batteries	3 AAA batteries required
Are Batteries Required	Yes
Special Features	Interactive Audio
Manufacturer Minimum Age (Months)	18 Months
Item Weight	27.22 g
Size	12 inches
Item Dimensions (L x W x H)	6 L x 5 W x 12 H Inches
Unit Count	1.0 Count

WHAT'S IN THE BOX

- Sleep N' Oink Plush
- battery
- Manual



FEATURES

- **When you press on Peppa's belly:** Different sounds play, such as sleep phrases, oinks, snores, and a soothing lullaby.
- **Bedtime Theme:** Peppa is wearing soft pink pajamas, which makes her a good friend for bedtime practices.
- **Included Teddy:** Peppa takes her favorite stuffed animal, Teddy, with her. This gives the kids a sense of comfort and familiarity.
- **Comforting Phrases:** Peppa says things like "Good night" and "It's time for bed!" that make kids feel safe and at ease.
- **Gentle Snores:** The sounds of soft snoring make sleeping more enjoyable and make it easier to fall asleep.
- **Official Merchandise:** This plush toy is fully licensed Peppa Pig merchandise, so you can be sure it is of high quality and real.
- **Age-Friendly:** It's good for kids 18 months and up, so it's a great gift for toddlers.
- **Size:** It's 12 inches tall, which is just the right size for hugging and cuddling.



- **It only weighs 27.22 g:** Which makes it easy for little hands to hold and move around.
- **Battery-Powered:** For music features, it needs 3 AA batteries (demo batteries are included), which lets you play for a longer time.
- **Durable Construction:** It's made from high-quality materials that are made to last through normal play.
- **Encourages Imaginative Play:** It gets kids to tell stories and make situations, which helps them become more creative.
- **Easy to Use:** The toy is easy for young children to play with on their own because it has a simple button function.
- **Great Choice for a Gift:** It's a great gift for birthdays, holidays, or other special events, and costs \$56.00.
- **Encourages Good Sleep Habits:** It helps kids set a routine for going to bed, which makes them feel safe and comfortable at night.

SETUP GUIDE

- **Unbox the Toy:** Carefully take the Sleep N' Oink toy out of its box, making sure not to damage it in the process.
- **How to Find the Battery Compartment:** The battery compartment is usually on the back or bottom of Peppa.
- **Install Batteries:** Put three AA batteries into the compartment, making sure they are facing the right way according to the marks for polarity.
- **Secure the Compartment:** Once the batteries are in, close the battery compartment firmly.

- **Turn on the Toy:** If there is one, use the power button, which is usually near the battery box, to turn Peppa on.
- **Test the Sound Features:** Press Peppa's stomach to make sure the sound features are working right and making the sounds you want.
- **Show How to Use:** To get kids to connect with Peppa, show them how to make the sounds happen by pressing the button.
- **Make a Comfortable Sleeping Area:** Give Peppa a comfortable place to sleep next to the child at bedtime.
- **Include in Bedtime Practice:** To help kids get ready for sleep at night, use Peppa as part of their regular bedtime practice.
- **Encourage Cuddling:** To help kids feel safe and comfortable at night, encourage them to cuddle with Peppa.
- **Storytelling:** Use Peppa to read bedtime stories, and include her in the story to keep kids interested.
- **Watch Kids Play:** Keep an eye on kids while they play to make sure they can safely use the soft toy and all of its parts.
- **Talk to Your Students:** About how important bedtime is and how Peppa helps them know it's time to sleep.
- **Switch Between Using Peppa for Different Things :** Use her for both fun and to help you sleep, so she can be used for a lot of different things.
- **Celebrate Success:** Use Peppa as a prize for doing things right at bedtime, which will encourage good behavior.

CARE & MAINTENANCE

- **Dusting:** Wipe Peppa down with a soft, dry cloth every so often to keep her clean and nice-looking.
- **Keep the Soft Toy Out of Water:** And other damp places to protect the electronics and fabric.
- **Check for Damage:** Take a look at any loose parts or signs of wear every so often, focusing on joints and sound parts.
- **Replace Batteries Right Away:** If the sounds start to fade, you should replace the batteries right away to get them working again.
- **How to Store It:** When not in use, keep Peppa in a cool, dry place to keep her safe from dust and damage.
- **Handling Carefully:** Teach kids to be careful when they play with Peppa so they don't damage the engaging parts.
- **Spot Cleaning Only:** If the plush gets dirty, use a wet cloth to wipe it off instead of putting it in water.
- **Secure Loose Parts:** Make sure that any parts or accessories that can be taken off are securely connected so that they don't get lost.
- **Keep an Eye Out for Allergens:** Keep the area where Peppa is presented clean to keep allergens and dust from building up.
- **Teach About Proper Use:** Teach kids how to use the sound features properly and make sure they know how to turn them off when they're not using them.
- **Change Peppa's Display Location:** Move her around every so often to keep her looking new and to keep her out of the sun.
- **Check for Wear:** Check the soft material often for signs of wear and replace her if needed.
- **To Encourage Creative Play:** Let kids make up stories with Peppa to help them think of new ideas.
- **Encourage Responsible Play:** Remind kids to play with the toy in a safe and responsible way, especially when they are with younger brothers.
- **Use Playtime with Peppa to Teach:** Use playtime with Peppa to teach kids how to take care of their toys and

treat their things with respect.

TROUBLESHOOTING

Issue	Possible Cause	Solution
No sound when pressing the plush	Dead or incorrectly installed batteries	Replace the AAA batteries or check battery placement
Sound cutting off mid-play	Weak or low battery power	Replace the batteries with fresh ones
Buttons unresponsive	Button area may be jammed or dirty	Clean the button area and press firmly
Plush not turning on	Power switch off or dead batteries	Ensure the power switch is on and the batteries are working
Sound too quiet	No volume control feature, low battery power	Replace batteries for louder sound
Plush not responding to touch	Internal sensor issue	Reset by turning the toy off and on again
Sound distorted	Weak battery charge	Install new batteries to restore sound quality
Buttons hard to press	Dirt or debris under the buttons	Clean around the buttons to improve responsiveness
Plush randomly turns off	Battery-saving mode triggered	Press buttons again to reactivate or replace batteries
Buttons playing incorrect sound	Internal programming glitch	Reset the plush by turning it off and on again
Sound skipping	Low battery power	Replace with fresh batteries
Plush not playing any sound	Batteries dead or incorrectly inserted	Check and replace the batteries
Sound too repetitive	Limited sound variety	Engage in interactive play to break up repetition
Plush stops working	Internal mechanism failure	Contact customer support for replacement
Battery compartment difficult to open	Misaligned or stuck battery cover	Gently realign and open the compartment

PROS & CONS

PROS

1. Interactive audio feature provides soothing sounds for sleep.
2. Soft, huggable material, perfect for toddlers.
3. Lightweight and portable, great for travel or bedtime use.
4. Encourages children to develop a bedtime routine.
5. Batteries last long with moderate use.

CONS

1. Requires 3 AAA batteries, which are not included.
2. Limited sound options may become repetitive.
3. No volume control feature for adjusting sound levels.
4. Sound feature may not appeal to older children.
5. Slightly higher price for a plush toy.

WARRANTY

The **Peppa Pig 92705 Sleep N' Oink Plush** comes with a **90-day limited warranty**. This warranty covers any defects in materials or workmanship, including issues with the interactive audio feature. If the product malfunctions within the warranty period, customers can contact the manufacturer for repair or replacement.

FREQUENTLY ASKED QUESTIONS

What is the Peppa Pig 92705 Sleep N' Oink Plush?

The Peppa Pig 92705 Sleep N' Oink Plush is an interactive plush toy designed for young children, featuring Peppa Pig and designed to provide comfort and entertainment during sleep.

What is the price of the Peppa Pig 92705?

The Peppa Pig 92705 Sleep N' Oink Plush is priced at \$56.00, reflecting its interactive features and quality design.

What are the dimensions of the Peppa Pig 92705?

The dimensions of the Peppa Pig 92705 are 6 inches in length, 5 inches in width, and 12 inches in height.

How much does the Peppa Pig 92705 weigh?

The Peppa Pig 92705 weighs 27.22 grams, making it lightweight and easy for young children to handle.

What is the minimum age recommendation for the Peppa Pig 92705?

The manufacturer recommends the Peppa Pig 92705 for children aged 18 months (1.5 years) and older.

What type of batteries does the Peppa Pig 92705 require?

The Peppa Pig 92705 requires 3 AAA batteries to operate its interactive audio features.

Are batteries included with the Peppa Pig 92705?

Typically, the batteries are not included with the Peppa Pig 92705, so you will need to purchase 3 AAA batteries separately.

What special features does the Peppa Pig 92705 have?

The Peppa Pig 92705 features interactive audio, allowing it to make sounds and phrases related to bedtime and the Peppa Pig series.

Is the Peppa Pig 92705 suitable for outdoor play?

While it can be used outdoors, it's best to keep the Peppa Pig 92705 away from moisture and dirt to maintain its quality and functionality.

How does the interactive audio work on the Peppa Pig 92705?

The interactive audio feature activates when the toy is hugged or pressed, prompting it to respond with comforting sounds and phrases.

What makes the Peppa Pig 92705 a great gift for children?

The combination of its interactive features, soft plush design, and beloved character makes the Peppa Pig 92705 an exciting and comforting gift for young fans.

How does the Peppa Pig 92705 enhance bedtime routines for children?

The engaging sounds and comfort of the Peppa Pig 92705 help create a soothing bedtime environment, making it easier for children to relax and fall asleep.

What themes does the Peppa Pig 92705 represent?

The Peppa Pig 92705 represents themes of friendship, comfort, and bedtime routines, allowing children to engage with the familiar world of Peppa Pig.

What educational benefits does the Peppa Pig 92705 provide?

The Peppa Pig 92705 helps develop listening skills and provides comfort, encouraging a positive bedtime experience for young children.

Why is my Peppa Pig 92705 Sleep N' Oink Plush not turning on?

Ensure that the batteries are properly installed and fully charged. If the plush still doesn't turn on, try replacing the batteries and confirm that the power switch is in the on position.

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.