

**perixx**  
**PERIBOARD-615 3**  
**in 1 Multi Device**  
**Keyboard**



# perixx PERIBOARD-615 3 in 1 Multi Device Keyboard User Manual

[Home](#) » [Perixx](#) » perixx PERIBOARD-615 3 in 1 Multi Device Keyboard User Manual 

## Contents


- [1 Teri xx PERIBOARD-615 3-in-1 Multi-Device Keyboard](#)
- [2 Product Illustration](#)
- [3 Keyboard Indicators](#)
- [4 How do you charge PERIBOARD-615?](#)
- [5 FCC Warning](#)
- [6 Specification](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)










**Teri xx PERIBOARD-615 3-in-1 Multi-Device Keyboard**















## Product Illustration



## Keyboard Indicators

		
 		
Fn Lock on      Low Battery Indicator	Number Lock on	Caps Lock on




<b>Bluetooth channel/Pairing indicator</b> 		<b>On/Off switch</b> Bluetooth   OFF   Wired 			<b>Charging port</b> 	
 Bluetooth Channel 1	 Bluetooth Channel 2	 Bluetooth	 OFF	 Wired	 Charging	 Fully charged
 Long press for pairing						


How do you charge PERIBOARD-615?



1. Plug PERIBOARD-615 into a computer




2. Switch to Wired




## Wireless Connection


**1. Switch to Bluetooth**




**2. Press the button to choose one Bluetooth channel that you want to connect**




**3. Long press the button for 10 seconds**




**4. Start -> Settings -> Devices -> Bluetooth & other devices**




**5.**



If there's no PERIBOARD-615 on the list, please press the Bluetooth pairing button again for 10 seconds.



## Mac Bluetooth



## FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### NOTE 1

This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by

### One or more of the following measures

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### NOTE 2

Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Caution

- The manufacturer and re-resellers are not responsible for any technical malfunctions, damage, or personal injury incurred by:
- Any attempt to dismantle, change, or modify the product in any manner
- Malfunction or damage is due to misuse or improper alteration or repair.
- Malfunctions or damage caused by external influences such as falling
- Malfunction or damage caused by fire, salt, gas, earthquake, lightning, wind, water, or other natural calamities, or abnormal voltage.
- Malfunctions or damage is caused by other devices connected to the products.
- Malfunction or damage is caused by high temperature, humid, greasy, dusty, and hazardous environments.
- You are cautioned that changes or modifications not expressly approved by Perixx Computer GmbH could avoid your authority to operate the equipment.
- All brand names, trademarks, and logos are the properties of their respective owners.
- Please Note: Long-term repetitive use of any keyboard and mouse could cause injury to the user. Perixx recommends users avoid excessive use of this or any keyboard and mouse.

### Important Safety Instructions

- Avoid dropping
- Do not disassemble.
- This product is suitable for moderate climates only.
- The maximum ambient temperature during the use of this product must not exceed 40 degrees
- Open flame sources, such as candles, must not be placed on this product.
- Only use a dry cloth or brush to clean this product.
- Perixx offers a one-year limited warranty with an optional one-year extension.

### Specification

Interface	USB Type-A/BT5.1	Number of keys	96 keys
Size	362*117*17mm	Type of keyboard	Scissor-switch
Weight	425±5g	Actuation distance	1.2±0.2mm
Cable length	1800mm	Total travel distance	1.6±0.2mm
Material	ABS	Durability	3 million keypresses
Operating system requirements	Win 7 or later		

### Power and Battery

Battery Type	USB-C rechargeable Li-Po (780mAh) battery	Charging Current	≤ 200mA
Battery Life	Up to 5 days of typical device usage	Charging Time	6 hours

### Sleen mode/Backlight screen mode




	Sleep mode	Backlight sleep mode
Y/N	Yes, after 30 minutes	Yes, after 1 minutes
How to wake the keyboard	Move or click	Move or click

Multimedia keys













Please press “Fn + Fn Lock” before using multimedia keys.


Multimedia keys

\*\*\*Please press “Fn + Fn Lock” before using multimedia keys.\*\*\* 



Fn Lock is on


	Previous Track		Volume down		Print Screen
	Play/Pause		Volume up		Scroll Lock
	Next Track		Fn Lock		Insert
	Mute		Backlit (50%-100%-0%)		Pause



Fn Lock is off

Perixx Computer GmbH  
+49-211-569488-00  
Heerdter Landstraße 189e, 40549 Düsseldorf, Germany  
<https://eu.perixx.com/>

Documents / Resources

	<p><a href="#">perixx PERIBOARD-615 3 in 1 Multi Device Keyboard</a> [pdf] User Manual  PERIBOARD-615 3 in 1 Multi Device Keyboard, PERIBOARD-615, 3 in 1 Multi Device Keyboard , Multi Device Keyboard, Keyboard</p>
---	---

References

- [User Manual](#)

**Manuals+, Privacy Policy**

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.