



permobil MX2 Speed Control Dial SmartDrive User Guide

[Home](#) » [permobil](#) » permobil MX2 Speed Control Dial SmartDrive User Guide

permobil

MX2 Speed Control Dial SmartDrive
User Guide

Contents [[hide](#)]

[1 MX2 Speed Control Dial SmartDrive](#)

[2 Documents / Resources](#)

[3 Related Posts](#)

MX2 Speed Control Dial SmartDrive

1. Rotate dial to its "STOP" limit.




2. Press against face of SpeedControl until LED turns on.



3. Rotate dial forward until you reach desired speed. Adjust your speed by rotating the dial forward or backward.



4. To stop, rotate back to “STOP” limit and hold your handrims. Press against face of the SpeedControl to turn power assist off.



Documents / Resources



[permobil MX2 Speed Control Dial SmartDrive](#) [pdf] User Guide
MX2 Speed Control Dial SmartDrive, MX2, Speed Control Dial SmartDrive, SmartDrive