




PETKIT 15722 Fresh Element Gemini User Manual

[Home](#) » [PETKIT](#) » PETKIT 15722 Fresh Element Gemini User Manual 

PETKIT 15722 Fresh Element Gemini






Please read the User Manual carefully before using the product and keep it properly.

Contents


- 1 Product Summary
- 2 Scan QR code to watch instructional videos
- 3 Quick Start Guide (Device Setup)
- 4 Quick Start Guide (Opening the Lid and Adding Food)
- 5 How to Use
- 6 Indicator Light
- 7 How to Clean
- 8 A Message to Our Valued Customers
- 9 User Safety Guide
- 10 Basic Specifications
- 11 Warranty Conditions
- 12 EU Declaration of Conformity
- 13 CUSTOMER SUPPORT
- 14 Documents / Resources
 - 14.1 References
- 15 Related Posts

Product Summary






- Power adapter x 1
- Desiccant x 1




Note: In order to provide a better user experience, we will be implementing periodic product enhancements. Product images shown for illustration purpose only. Actual product may vary from the image shown on the box. For any discrepancies, please refer to the actual product.


Button of the main unit



Interior of the food storage container



Interior of the lid



Scan QR code to watch instructional videos

Set up and use



Scan to watch an instructional video on how to set up and use your device.

Scan to download “PETKIT” App.



Please download the “PETKIT” App from the Apple Store or the Android App Market. Enter the “Home” page and click “+” to add your device. Follow the prompts to bind your device.

Cleaning and maintenance

Scan to watch an instructional video on how to clean your device.



Quick Start Guide (Device Setup)


When installing your device, make sure there is no food already in the food storage container.)

Install the main unit

1. Place the main unit on a level surface.
2. Press and hold the PUSH buttons and place the circular notches on both sides of the food storage container downward toward the PUSH buttons until the PUSH buttons are fully stuck into the circular notches. (As shown in the figure below)
3. Take the stainless-steel food bowl and place it in the food bowl stand.

Connect the power adapter

Take out the power adapter cord and attach it to the power adapter port on the bottom of the main device.



Install the backup batteries


Choose whether to install the battery according to your actual use (If you want to install batteries, you will need to buy the batteries separately).

Before installing batteries, make sure there is no food in the food storage container.)

1. Take out the screw and remove the battery cover.
2. Take 4 No. 1 batteries and place them in the battery compartment. (Pay attention to the orientation of the positive and negative ends)
3. Put the battery cover back on and tighten down the screw.

We strongly recommend checking and replacing the batteries before leaving the device unattended for an extended period of time. Always replace batteries that have a low charge. (Only use alkaline batteries)


Bottom



Quick Start Guide (Opening the Lid and Adding Food)

Open the lid

Use your thumb to press down on the lid release button and slide the lid in the OPEN direction as indicated in the illustration below, lift the lid at the same time.



Insert desiccant

Open the desiccant compartment, take the desiccant packet, and lay it down evenly in the compartment. Then close the desiccant compartment.



Add pet food


1. Add pet food. (Do not exceed the MAX line)
2. Close the lid: Notch the back of the lid into the two holes located at the top of the food storage container, then press the front of the lid down.

It is suggested that the size of dry pet food should be no bigger than 12mm.



Self-Check Chart:

Size of Pet Food Pellets



How to Use

Connect the App


Please download the “PETKIT” App from the Apple Store or the Android App Market. Enter the “Home” page and click “+” to add your device. Follow the prompts to bind your device.

Using the App to remotely control food dispensing

Using the App, you can set a feeding schedule. The pet feeder will automatically dispense food each day based on your settings. When your pet has eaten, you will receive a notification. This can help you better control when your pet eats and how much they eat each time.

Manual feeding


According to the actual use, select the food dispense button of hopper 01 or hopper 02. Hold down on the manual food dispense button to dispense food. Release the button to stop dispensing food.,



Indicator Light


Wi-Fi Indicator Light	Status
Blinking slowly	Device is offline, there is no internet connection
Blinking quickly	Device is connecting to the Wi-Fi
On (constant)	Device is connected to the internet
Off	Indicates the wi-fi indicator light has been turned off

Wi-Fi Indicator light




How to Clean

1. Place the feeder on a level surface. Press down on the PUSH button on one side, and at the same time lean the container toward the other side and slide it off.
2. Wipe the main unit with a wet paper towel. (Do not immerse or soak the main unit in water)
3. Open the lid and remove the desiccant packet.



4. Pull out the partition vertically upward.
5. Pull out the food dispense paddles in the food storage container.
6. Rotate clockwise to remove the food dispense module. (The food dispense paddles must be removed first, and then the food dispense module can be removed.)
7. Clean each component one at a time, starting with the food storage container (including the food dispenser module inside), the lid, the partition, and the stainless-steel food bowl. We recommend using an appropriate amount of soap when cleaning, then rinsing and drying the components after you are done.
8. After cleaning and drying, reinstall each component one by one. (Please ensure that all parts are completely dry).



A Message to Our Valued Customers

- Thank you for choosing PETKIT FRESHELEMNT GEMINI. We at PETKIT have done our best to make life easier for you and your pets with technology.
- Please carefully read the User Manual before using the product. By setting up and using this product, you are acknowledged that you have already read and accepted the safety guidelines listed below.
- We are not liable and will not accept responsibility for any accidents or injuries that result from improper use of this product.
- PETKIT reserves the rights of interpretation and revision.


User Safety Guide

Failure to follow the safety guides outlines below can result in product malfunction or other unforeseen mishaps.

- Please install and use the product as instructed in the User Manual.
- For pets older than 3 months.
- For indoor use only. Do not expose the product directly to sunlight for extended periods of time. Do not place it near an open flame.
- The device is using low voltages. However, pets can still damage the power cord if they chew on it. Please keep your pets away from the Cord.
- Make sure the device is placed on a level surface. Do not overturn the device, or it may not function properly.
- Do not drop all items except dry pet food into the storage container, or the device will not function properly, and it may even endanger the safety of the pet.
- In order to prevent your pet from overturning this device, we recommend placing it in a corner or against a wall.

- To prevent the device from falling down and injuring your pet or damaging property, please do not place this device in an elevated location.
- Please keep the main unit dry.
- If you want to stop using the device, make sure to remove the battery and unplug the power adapter, and please clean and dry the device before storing.
- Please turn off the power before moving the device.
- Children should use this product under the guidance of adults.
- Repairs should be done under the guidance of a professional to avoid safety hazards.
- If you need to go out, please check the battery in the battery compartment to make sure the battery has sufficient charge (this device only uses an alkaline battery).

Basic Specifications

Product Name	PETLIT FRESHELEMTN GEMINI
Product Code	P590
Product Dimensions	362 x 293 x 247.5mm
Recommended for	Cars and small breed dogs
Product Materials	ABS, 304 stainless steel
Product Wight	≈2.3kg
Wireless Connection	Wi-Fi
Rated Voltage	6V 
Rated Power	3W
Product Capacity	5L (01 hopper 2L, 02 hopper 3L)

Warranty Conditions

A new product purchased in the Alza.cz sales network is guaranteed for 2 years. If you need repair or other services during the warranty period, contact the product seller directly, you must provide the original proof of purchase with the date of purchase.

The following are considered to be a conflict with the warranty conditions, for which the claimed claim may not be recognized:

- Using the product for any purpose other than that for which the product is intended or failing to follow the instructions for maintenance, operation, and service of the product.
- Damage to the product by a natural disaster, the intervention of an unauthorized person or mechanically through the fault of the buyer (e.g., during transport, cleaning by inappropriate means, etc.).
- Natural wear and aging of consumables or components during use (such as batteries, etc.).
- Exposure to adverse external influences, such as sunlight and other radiation or electromagnetic fields, fluid intrusion, object intrusion, mains overvoltage, electrostatic discharge voltage (including lightning), faulty supply or input voltage and inappropriate polarity of this voltage, chemical processes such as used power supplies, etc.

- If anyone has made modifications, modifications, alterations to the design or adaptation to change or extend the functions of the product compared to the purchased design or use of non-original components.

EU Declaration of Conformity



This equipment is in compliance with the essential requirements and other relevant provisions of EU directives.

WEEE



— This product must not be disposed of as normal household waste in accordance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE – 2012/19 / EU). Instead, it shall be returned to the place of purchase or handed over to a public collection point for the recyclable waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. Contact your local authority or the nearest collection point for further details. Improper disposal of this type of waste may result in fines in accordance with national regulations.

CUSTOMER SUPPORT



Reedog, sro
Sedmidomky 459/8 101 00
Praha 10

Telefon: +36 21 300 7514

E-mail: info@elektro-nyakorvek.hu

PETKIT

Documents / Resources

  <small>Fresh Element Gemini Fresh Element Gemini Fresh Element Gemini</small>	<p>PETKIT 15722 Fresh Element Gemini [pdf] User Manual 15722 Fresh Element Gemini, 15722, Fresh Element Gemini, Element Gemini, Gemini</p>
---	--

References

- nyakorvek.nyakorvek.hu - nyakorvek.hu információ, képek, hirek.
- [â...â† Elektromos nyakÃ¶rv, Elektromos kutya nyakÃ¶rvek â†â... - Elektro-nyakÃ¶rvek.hu](#)
- [User Manual](#)