

PHANTEKS ECLIPSE P200A Instruction Manual

Home » PHANTEKS » PHANTEKS ECLIPSE P200A Instruction Manual


ECLIPSE PZ00A V1.0

Contents

- 1 INSTRUCTION MANUAL V1.0
 - 1.1 INSTRUCTION MANUAL
 - 1.2 INTRODUCTION
 - 1.3 PRODUCT OVERVIEW
 - 1.4 FRONT I/O FEATURES
 - 1.5 STEP 1. REMOVING CHASSIS PANELS
 - 1.6 STEP 2. MOTHERBOARD INSTALLATION
 - 1.7 STEP 3. POWER SUPPLY INSTALLATION
 - 1.8 STEP 4. STORAGE INSTALLATION Dedicated 2.5" SSD Bracket
 - 1.9 STEP 5. STORAGE INSTALLATION 2.5" SSD Covers
 - 1.10 STEP 5. MOTHERBOARD CONNECTIONS
 - 1.11 STEP 6. D-RGB LIGHTING P200ATG_D MODEL ONLY
- **2 OPTIONAL UPGRADES**
 - 2.1 STEP 7. VERTICAL GPU MOUNT OPTIONAL (RISER CABLE SOLD SEPERATELY. PH-CBRS_FL15)
 - 2.2 STEP 8. STORAGE INSTALLATION 3.5" HDD (STACKABLE HDD BRACKET SOLD SEPERATELY. PH-HDDKT 03)
- 3 Documents / Resources
- **4 Related Posts**

INSTRUCTION MANUAL V1.0

INSTRUCTION MANUAL



INTRODUCTION

Thank you for choosing Phanteks. Please take a moment to carefully go through the manual. Phanteks will not take responsibility for any damages incurred due to incorrect installation or usage of this product.

This manual supports the following models:


PH-EC200AC_BK (2x 120 mm Black Fans) PH-EC200ATG_DBK (2x 120 mm D-RGB Fans)

PRODUCT OVERVIEW

CLEARANCE

CPU Cooler Height 165 mm
GPU Clearance 355 mm
GPU Thickness 3-slot, 65mm

FRONT



SIDE









BOTTOM





120 FAN

REAR



120 FAN





P200A PRE-INSTALLED ACCESSORIES:

2x 120 mm Black or 2x 120 mm D-RGB 2x SSD Cover





P200A INCLUDED ACCESSORIES:

6x Zip Ties

21x Motherboard + SSD Screw





4x PSU Screw


3x Case Screw





1x Thumb Screw

1x Vertical GPU Mount




FRONT I/O FEATURES




- 1. Power Button
- Reset Button (P200AC Only)
- D-RGB Mode (P200ATG-D Only)
- D-RGB Color (P200ATG-D Only)
- 5. Headphone / Microphone
- 6. USB-C Gen 2 (P200ATG-D only)
- 7. USB 3.0

ECLIPSE P200A Performance (PH-EC200AC_BK)




ECLIPSE P200A DIGITAL-RGB (PH-EC200ATG_DBK)



DIGITAL-RGB CONTROLS (P200ATG_D MODEL)










PRESS AND HOLD THE MODE BUTTON TO TURN OFF LEDS PRESS AGAIN TO TURN ON

2 SEC STEP 1. REMOVING CHASSIS PANELS


a. PULL THE SIDE PANEL, THEN LIFT THE PANEL UP TO REMOVE IT



b. REMOVE FRONT PANEL BY PULLING ON THE PANEL FROM BELOW



c. REMOVE THE BOTTOM DUST FILTER FROM THE FRONT




STEP 2. MOTHERBOARD INSTALLATION

INSTALL THE ITX MOTHERBOARD WITH 4x MOTHERBOARD SCREWS

INSTALL:

4x





STEP 3. POWER SUPPLY INSTALLATION

THE POWER SUPPLY IS INSTALLED THROUGH THE REAR OF THE CHASSIS. LOOSEN THUMBSCREWS TO REMOVE PSU BRACKET. INSTALL PSU TO BRACKET WITH 4x PSU SCREWS.

LOOSEN:

2x




INSTALL:






Plug in all cables you need for your build into the power supply first before installing it for easier installation





The right-side panel can be secured with a screw if cables are pushing against it.




STEP 4. STORAGE INSTALLATION - Dedicated 2.5" SSD Bracket

INSTALL THE SSD(s) WITH 4x SSD SCREWS ON THE DEDICATED SSD BRACKET AND MOUNT IT BACK INTO THE CHASSIS.

INSTALL:







STEP 5. STORAGE INSTALLATION - 2.5" SSD Covers

INSTALL THE SSD DRIVE WITH 4x SSD SCREWS ON THE SSD COVER AND MOUNT BACK INTO THE CHASSIS.

INSTALL:








STEP 5. MOTHERBOARD CONNECTIONS

a. CONNECT THE HD-AUDIO & USB 3.0 CABLES



P200ATG_D MODEL ONLY:




b. CONNECT THE FRONT I/O CABLES TO THE FRONT I/O HEADER ON THE MOTHERBOARD (**SEE FRONT I/O HEADER DIAGRAM FOR GENERAL REFERENCE**)


ALL MODELS:



P200AC MODEL ONLY:



MOTHERBOARD FRONT I/O HEADER DIAGRAM



- 1. POWER LED
- 2. POWER SWITCH
- 3. NOT USED
- 4. RESET SWITCH
- 5. HDD LED



For a more accurate overview, please consult the motherboards' manual.

*On the P200ATG_D model, the D-RGB lighting functions as a power LED.

STEP 6. D-RGB LIGHTING – P200ATG_D MODEL ONLY

a. CONNECT THE SATA CABLE TO THE POWER SUPPLY



CONNECT MORE D-RGB PRODUCTS

b. CONNECT D-RGB CONNECT OR TO D-RGB PRODUCTS

To DIGITAL-RGB Products



SYNC YOUR CASE LIGHTING TO THE MOTHERBOARD (OPTIONAL)

c. CONNECT MOTHERBOARD D-RGB ADAPTER TO THE MOTHERBOARD

To D-RGB Motherboard (optional)




Compatible with:







ADDRESSABLE ADDRESSABLE RAINBOW





Lighting must be controlled through the motherboard software when connected to the motherboard. The Color and Mode buttons do not work when synced to motherboard.


OPTIONAL UPGRADES


STEP 7. VERTICAL GPU MOUNT - OPTIONAL (RISER CABLE SOLD SEPERATELY. PH-CBRS_FL15)

a. Release the GPU brackets by removing 3 screws.

RELEASE:


Зх





INSTALL:






b. Secure the GPU brackets as shown with the same 3 screws.



The rear fan position cannot be used with a vertical GPU.

c. Secure the GPU Mount to the bottom of the chassis with the 2 thumb screws. Secure the Riser Cable to the GPU Mount.





The GPU Mount has two mounting positions. Position A allows for better air cooling and 3-slot GPU cards.


STEP 8. STORAGE INSTALLATION - 3.5" HDD (STACKABLE HDD BRACKET SOLD SEPERATELY. PH-HDDKT_03)

Up to 4 Stackable HDD Brackets can be installed in the side fan locations. These are available separately.


a. NSTALL THE HDD DRIVE INTO THE STACKABLE 3.5" HDD BRACKET.

INSTALL:





b. STACK TWO BRACKETS WHEN INSTALLING MORE HDDs. IF NOT, SKIP THIS STEP.




TO REMOVE A BRACKET, PRESS AND PULL TO RELEASE.

d. MOUNT THE BRACKETS INTO THE CHASSIS AND SECURE EACH HDD WITH 2 THUMBSCREWS

INSTALL:







Documents / Resources



PHANTEKS ECLIPSE P200A [pdf] Instruction Manual PHANTEKS, ECLIPSE, P200A, PH-EC200AC, PH-EC200ATG

Manuals+,