



PHEANOO P28 Soundbar with Subwoofer 2.1CH with 3D Surround Sound User Guide

[Home](#) » [PHEANOO](#) » PHEANOO P28 Soundbar with Subwoofer 2.1CH with 3D Surround Sound User Guide 

PHEANOO P28 Soundbar with Subwoofer 2.1CH with 3D Surround Sound User Guide




Please read this guide carefully before connecting and using your soundbar and keep it for future reference.

Contents


- 1 Soundbar & accessories
- 2 HDMI(ARC) Cable Connection
- 3 Power on the Soundbar
- 4 Turning on the Soundbar
- 5 Soundbar Sound Input Setting
- 6 Turning on the TV
- 7 TV Sound/Audio Output Setting
- 8 Notice
- 9 Other Connection Methods
- 10 Audio Cable Connecting
- 11 Documents / Resources
 - 11.1 References
- 12 Related Posts

Soundbar & accessories


Soundbar (1)



Subwoofer (1)




Remote control (1)




HDMI (ARC) cable (1)




Screw bag (1)




Optical cable (1)



Audio cable (1)




HDMI(ARC) Cable Connection




Please only use Pheanoo's ORIGINAL CABLES in the packages.

Power on the Soundbar




Turning on the Soundbar




- For shipping safety, the batteries for the remote control are not Included. The remote control takes two AAA batteries (triple A).

Soundbar Sound Input Setting




- Hd** HDMI mode
- AU** AUX mode
- OP** Optical mode
- bt** Bluetooth Pairing mode

Turning on the TV



TV Sound/Audio Output Setting



You can browse “bit.ly/P27TVST” to find more detail about TV Sound/Audio Output Settings.

Video of “TV Sound/Audio Output Setting”



The Sound settings of different brands of TV may be different, Please refer to the TV manual.

Notice

1. **Make Sure** that the TVs Audio output selected is the same one selected on the soundbar.

TV Audio Output Settings	To	Soundbar Audio Input Settings	
HDMI		HDMI	
Optical		Optical	
Bluetooth		Bluetooth	
Aux		Aux	

2. When connecting a TV using the HDMI connection modes, most TVs will automatically switch to PCM sound

output mode which is compatible with the soundbar. If there is an incompatibility issue, please manually set the TV's audio (sound) to PCM output mode. You can browse "bitly/P27TVPCM" to find more details about the PCM settings on your TV.

Video of "KM Setting on TV"




3. When you use apps such as NETFLIX, HULU, or AMAZON PRIME on your smart TV, please turn off DOLBY and / or DTS function in the app sound settings or choose STEREO output to ensure that the soundbar will be compatible with your TV. Please refer to the user's manual for specific settings or browse 'bit.ly/P27APP' to find more details about app sound output settings

- Do not place magnetic objects in, on, or around the soundbar as this may damage your soundbar.

Other Connection Methods

For other steps refer to the instructions.




Take off the caps from the Optical cable plugs before plug in.

Please Only use Pheanoo's ORIGINAL CABLES in the package.

Audio Cable Connecting


For other steps refer to the instructions.






Some TVs have Audio In Only, can't deliver sound to soundbar.

Please only use Pheanoo's ORIGINAL CABLES in the package,

Documents / Resources

	PHEANOO P28 Soundbar with Subwoofer 2.1CH with 3D Surround Sound [pdf] User Guide P28, Soundbar with Subwoofer 2.1CH with 3D Surround Sound
---	--

References

-  [YouTube](#)
-  [YouTube](#)
-  [YouTube](#)

Manuals+.