

[Skip to content](#)

## Manuals+

User Manuals Simplified.



# PHILIPS Hue Smart Button Bridge Instructions

[Home](#) » [Philips](#) » PHILIPS Hue Smart Button Bridge Instructions

Contents [hide](#)

[1 PHILIPS Hue Smart Button Bridge](#)

[2 Connect your Inner Smart Button to Philips Hue](#)

[3 Documents / Resources](#)

[4 Related Posts](#)




## PHILIPS Hue Smart Button Bridge

### Connect your Inner Smart Button to Philips Hue

#### Step 1:

Connect the Smart Button to the Philips Hue Bridge




- Open the Philips Hue app and start searching for lights.
- Remove the plastic tab to put the Remote Control in pairing mode. The LED on the front will start blinking once per second.
- The LED will rapidly blink twice to confirm it's successfully connected.

#### NOTE:

the Smart Button will not appear in the Philips Hue app.No blinking LED? Press and hold the reset button behind the battery lid for 3 seconds.

#### Step 2:

Connect the Smart Button to the individual lights



- Turn the light off for at least 5 seconds using the wall switch and turn it on again.
- The light is in pairing mode for 1 minute from now.
- Press the Smart Button 3 times in quick succession and hold the third press for 3 seconds.
- The LED on the Smart Button will blink once per second.
- Bring the Smart Button close to the light (< 10cm).
- The light will blink to confirm it's successfully connected.

Repeat Step 2 for all lights that you want to connect to the Smart Button. Successful! You can now control the connected light(s) from the app and with the Smart Button.

## Documents / Resources



[PHILIPS Hue Smart Button Bridge](#) [pdf] Instructions  
Hue Smart Button Bridge

### [Manuals+.](#)

- [home](#)
- [privacy](#)