



PHILIPS SPK6307B Wireless Combo Keyboard User Manual

[Home](#) » [Philips](#) » PHILIPS SPK6307B Wireless Combo Keyboard User Manual 


PHILIPS SPK6307B Wireless Combo Keyboard User Manual




Contents

- 1 [Function overview of the keyboard](#)
- 2 [Connection Guide](#)
- 3 [Packaging contents](#)
- 4 [System requirement](#)
- 5 [Technical specifications](#)
- 6 [Trouble shooting](#)
- 7 [Documents / Resources](#)
 - 7.1 [References](#)
- 8 [Related Posts](#)

Function overview of the keyboard







1. fn+ : Media player
2. fn+ : Volume –
3. fn+ : Volume +
4. fn+ : Mute
5. fn+ : Prev song
6. fn+ : Next song
7. fn+ : Play/Pause
8. fn+ : Stop
9. fn+ : Homepage
10. fn+ : Email
11. fn+ : My computer
12. fn+ : Favorite
13. : Return
14. : Search
15. : Refresh
16. : Calculator
17. : Lock screen
18. Number lock indicator
19. Caps lock indicator
20. Low battery indicator
21. ON/OFF switch
22. Battery door

Connection Guide


1. Push the battery door away




2. Pull off the battery insulating film. Turn on the power switch



3. Take out the receiver and close the battery door



4. Plug the receiver into the USB port of a PC.



Packaging contents

1. Wireless keyboard
2. Wireless receiver
3. User manual and important information
4. 1*AAA battery (inside keyboard)

System requirement

1. 1 x USB port
2. Windows® 7, Windows® 8, Windows® 10 or later, Android 3.2 and above; Mac OS 10.5 or later

Note: Multimedia functions are partially invalid in different OS versions.

Technical specifications

1. Connectivity: 2.4GHz wireless
2. Wireless Effective distance: 15m
3. Keyboard keys lifespan: 10 million keystrokes
4. Power supply: 1*AAA Philips battery
5. Interface: USB wireless receiver
6. Product dimension: 433*136*22mm
7. Product weight: 575g
8. Operating temperature range: 0 ° C to 40 ° C
9. Operating humidity range: 10% – 85%.

Trouble shooting

1. Make sure that the USB wireless receiver of the product is correctly plugged into the USB port of the computer.
2. Make sure the computer meets the minimum system requirement.
3. If the distance between the product and the receiver exceeds an effective range, please reduce the distance for better performance.

If you can't solve the problem, please try to find the solution from Philips website or nearest retailer. Please do not disassemble the product by force.

Attention

1. Please use dry and soft cloth to clean the product.
2. Do not fold or bend the product.
3. Do not disassemble the product by force.
4. Do not get in the rain or in the sun or fire.
5. Do not flush directly with water.

2021 © Top Victory Investments Limited . All rights reserved.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

This product has been manufactured by and is sold under the responsibility of Top Victory Investments Limited , and Top Victory Investments Limited is the warrantor in relation to this product.


Specifications are subject to change without notice

Made in China

Register your product and get support at:
www.philips.com/welcome



Documents / Resources

	<p>PHILIPS SPK6307B Wireless Combo Keyboard [pdf] User Manual SPK6307B, Wireless Combo Keyboard, Combo Keyboard, Wireless Keyboard, Keyboard, SPK 6307B</p>
---	--

References

-  [Product registration | Philips](#)

Manuals+.