




Phomemo D35 Wireless Bluetooth Labels Maker Portable Mini Label Printer Instructions

[Home](#) » [Phomemo](#) » Phomemo D35 Wireless Bluetooth Labels Maker Portable Mini Label Printer Instructions 

Phomemo

D35 Wireless Bluetooth Labels Maker
Portable Mini Label Printer
Instructions




Contents

- 1 D35 Wireless Bluetooth Labels Maker Portable Mini Label Printer
- 2 Packing List
- 3 Product Specifications
- 4 Parts Description Appearance Introduction
- 5 Parts Description Power Button and Indicator Light
- 6 Instructions for use
- 7 App Download Method
- 8 Label Maker Connection
- 9 Confirm the Label Size
- 10 Printing Guide Select Edit Version
- 11 Daily Cleaning
- 12 Solutions for Common Problems
- 13 Product Warranty
- 14 FCC Caution
- 15 Warranty/Maintenance Card
- 16 Documents / Resources
- 17 Related Posts

D35 Wireless Bluetooth Labels Maker Portable Mini Label Printer


Please read this instruction carefully before using this product and keep it properly.

Packing List




Label Maker*1

The number of paper rolls in the list is subject to the actual shipment.




Product instruction*1




Charging line*1

Product Specifications

Product name	Smart Mini Label Maker
Product model	D35
Printing technology	Thermal printing
Consumable width	6-15mm
Effective printing width	12mm
Supported consumables	Pre-cut paper,black mark paper,continuous paper
Printing density	Light, standard, dark
Printing resolution	203dpi
Print head service life	50KM
Communication interface	Bluetooth
Product Size	135*79.6*29.2mm(5.3*3.1*1.15inch)
Power Input	5V  2A
Power supply method	Type-C / Lithium battery
Supported operating system	Android / iOS


Parts Description Appearance Introduction

1. Label Maker display



2. Label paper display

Various labels available for purchase





Gap paper display



Continuous paper display

3. Continuous paper display

Easy to tear line design, easy to tear the bottom paper



Gently bend the label paper along the easy-to-tear line to make it easier to peel the bottom paper from the adhesive.

Parts Description Power Button and Indicator Light









Indicator light

Power button description


Button	Operation method	Functions
Power button	Presse fur 3s	Turn on/off
	Click	Print out the paper
	Double click	Print the content of the self-test paper

Power indicator status


 Green light keeps on	Normal status
 Green light flashes slowly	charging with power on
 Green light flashes quickly	charging with power off
 Red light keeps on	Error (lack of paper, cover opened, high temperature)
 Red light flashes slowly	10% battery
 Red light flashes quickly	5% battery

Instructions for use


1. Open the paper compartment cover of the machine
2. Put the label paper in the paper compartment with the printing side facing left
3. Pull out the label paper by 5mm in length for normal printing



4. Align the upper cover buckle and close the cover
5. Press and hold for 3s to turn on
6. Click the power button to identify the label position




7. Come out a piece of paper, positioning completed
8. After printing, slide the cutter button up to tear off the label



NOTE

- When installing or replacing the label roll for the first time, the label position identification is required; (Step 06).
- If the label position identification is not carried out (Step 06), failures may occur such as first printing missing, not centered, etc.
- The continuous papers do not need to click the power button for positioning, just pull out the position of the paper outlet.

App Download Method



- This product needs to be connected to the printer in the App;
- Due to the requirements of mobile phone system, the Android mobile phone will use the user's geographic location when connecting, so that the user needs to turn on the GPS and confirm the authorization.

Method I: Please use your mobile phone to scan the QR code to download the App




<http://downloadapp.qu-in.com/M110-Print-master/>

Method II: Search and download



Label Maker Connection


1. Turn on GPS(Android mobile phone only)
2. Open the App
3. Click to search **Connect now** for the device
4. Connect immediately



- When connecting device in the App, please make sure that your Label Maker is turned on and Bluetooth of your mobile phone is turned on.
- Due to the requirements of mobile phone system, the Android mobile phone will use the user's geographic location when connecting, so that the user needs to turn on the GPS and confirm the authorization.


Confirm the Label Size

Method I:




Check the antiloosening paste please refer to the actual size used

Method II:




Check the label paper packaging

Method III:



Use a ruler to measure


Method IV:




Check the label paper pads (the old and new versions of label paper are being replaced, Please refer to the actual shipment)

Printing Guide Select Edit Version


Lite Mode: Edit simply, print speedily



Creation Mode: Multifunctional, covers more needs




The user can view more operation tutorials and switch editing versions in the "Home".



Printing Gmde Lite Mode


1. Select "Label Setting"
2. Click to select the corresponding label size Giease refr tothe actualsize sed
3. Click the blank box to enter **text**











NOTE

- If the matching template is not selected, there will be undesirable situations such as centered layout of printed content, uneven layout, etc.

4. Edit function description






Functions	Operation method	Example
	Click to insert text. User can edit the text size, typesetting and select various fonts, etc.	
	Add date	
	Edit specific time point	
	Unit symbol	

5. After editing, click to “Print”


6. After printing, slide the cutter button up to tear off the label

7. **Continuous paper tear off the bottom paper** (Gently bend the label paper along the easy-to-tear line to make it easier to peel the backing paper from the adhesive)



Printing Guide Creation Mode

1. Select “Label Setting”
2. Click to select the corresponding label size (Please refer to the actual size used)
3. Click ” (T)” to input text




NOTE


- If the corresponding size template is not selected correctly, there will be undesirable situations such as centered printing layout and uneven layout, etc.

4. Edit function description


Shortcut keys



Editing function















Editing function




NOTE

- App functions will be updated with new functions in irregular, please refer to the actual function.


Function s	Description	Functions	Description
	Click to insert text. User can edit the text size, typesetting and select various fonts, etc.		Click to insert a one-dimensional code. Enter the information to be edited, then a one-dimensional code can be automatically generated, and the layout can be adjusted.
	Icon function, click to insert all kinds of cute icons.		Click to insert a QR code. Enter the information to be edited, then a QR code can be automatically generated, and the layout can be adjusted.
	Click border function, and choose various cute borders to decorate your label.		Insert a line. User can choose a dashed line or a solid line.
	Click to insert the picture you want to edit and print.		Click to insert round or square shapes.
	Insert date and specific time.		Support table import, therefore quickly generating a list that needs to be printed.
	Click to scan the code to identify. It can quickly identify the text content in the QR code.		Click to recognize text in the picture.

5. After editing, click to "Print"
6. After printing, slide the cutter button up to tear off the label
7. Continuous paper tear off the bottom paper (Gently bend the label paper along the easy-to-tear line to make it easier to peel the backing paper from the adhesive)



Daily Cleaning

1. Turn off the Label Maker
2. Use a cotton swab dipped in a little alcohol
3. Wipe the print head gently
4. Wait for the alcohol to evaporate and then turn it on and double-click the power button to print labels



NOTE

- Do not scratch the print head with hard objects, otherwise the thermal film will be permanently damaged and cannot be repaired).

Solutions for Common Problems

The printer can't close the cover?

Please check Are the buckles of the printer cover aligned?

Please align the upper cover buckle with the holes on the left, and then close the printer cover to the right.

Not centered, misplaced, offset, skipped, etc.


Please check Whether the paper roll is correctly placed in the machine?

Please make sure that the label is placed in the machine with printing side facing left. If it is placed incorrectly (reversed), printing will fail.

Please check Whether to select the corresponding label size and pattern in the App?

Please check the label size and image on the label packaging, and choose the correct template in the App. To do so, select "Label Setting"


Please check After the machine is turned on, whether to click the power button to allow the machine to calibrate and position the label?



When installing or replacing label paper roll for the first time, the user needs to click the power button to print a blank label so that the print head can identify the position of label paper. The continuous papers do not need to click the power button for positioning, just pull out the position of the paper outlet.


Printing blurry

Please check Whether the power of machine is sufficient.

On the “Profile” page, click “Printer” and choose “” to view the specific power level. If the remaining power of printer is less than 10%, you can charge it for at least half an hour before use.

Please check Whether there is foreign matter or glue on the print head?

There is foreign matter or glue on the print head. Please use a cotton swab dip with a little alcohol to gently wipe the dirt on the print head. Do not turn on the machine immediately after wiping. After the alcohol is evaporated and dry, double-click the power button to print the self-check page after turning on the machine to check the effect.




Printer cannot be connected

Please check The status of the printer is on, and the mobile phone bluetooth has been turned on?

Please check Is the device connection performed in App?

This product needs to perform the device connection in App.

Please check Is the mobile phone authorized?



Because of the phone system's requirements, Android phones will use your location when it is connected, and you need to turn on GPS and confirm authorization (other phone systems don't need to turn on this function).

Product Warranty

Thank you for choosing the Smart Mini Label Maker.

1. We will provide customers with reliable *replacement/return" support during the one-year warranty period from the date of purchase;
2. Please keep the warranty card in a safe place so that you can read it when needed.

If you have any problem or need on our product or this user manual, please feel free to contact our customer services. We will do our best to help you.

Note: If the supporting software is updated, it will be compiled into the new version of the manual without notice

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Warranty/Maintenance Card

- ☐ **Replce**
- ☐ **Retum**

User Information	Name:	Gender:	Phone:
	Address:		
Product Information	Date of purchase:		
	Product order number:		
	Product serial number:		
Reason for Return (Replace / Repair / Request Main tenance)	Fault description :		

Thank you for choosing our products!

Phomemo

Documents / Resources


[illegible]




08. Printing Guide Select Edit Version




09. Printing Guide 1. Use Barcode



10. Printing Guide 2. Create New Menu



11. Daily Cleaning



12. Solutions for Common Problems



13. Product Warranty



14. FCC Notice



15. Warranty/Maintenance Card



Thank you for choosing our product!

Phomemo D35 Wireless Bluetooth Labels Maker Portable Mini Label Printer [pdf] Instructions
D35 Wireless Bluetooth Labels Maker Portable Mini Label Printer, D35, Wireless Bluetooth Labels Maker Portable Mini Label Printer, Portable Mini Label Printer