



## PIC-CORP 94412-CHN-1 Mega Bug Zapper Owner's Manual

[Home](#) » [PIC-CORP](#) » PIC-CORP 94412-CHN-1 Mega Bug Zapper Owner's Manual 

**PiC**<sup>®</sup>  
Pest Free Living

# MEGA BUG ZAPPER

Owner's Manual IMPORTANT  
SAFETY INSTRUCTIONS

### Contents

- 1 CORP 94412-CHN-1 Mega Bug Zapper
- 2 OPERATION INSTRUCTIONS:
- 3 DIRECTIONS FOR USE AS A ZAPPER:
- 4 CLEANING:
- 5 Documents / Resources

**CORP 94412-CHN-1 Mega Bug Zapper**



**READ THE ENTIRE PRODUCT LABEL AND OWNER'S MANUAL BEFORE USING,**

#### **ELECTRIC SHOCK RISK-DO NOT TOUCH THE ELECTRIC GRID**

Thank you for choosing the PC Pest Free Living Mega Bug Zapper racket. Please read the instruction manual carefully to ensure use of this product complies with all safety regulations. The product is designed with metal grids built into the racket head. Do not pinch or press the grids together. Do not put objects or fingers through the racket face. Keep away from moisture. Do not use in rain. Safe for indoor and outdoor use. Do not attempt to make repairs on the unit. Call our customer service department at 1-800-799-7302 for assistance. This is not a toy. KEEP AWAY FROM CHILDREN.

#### **OPERATION INSTRUCTIONS:**

The unit requires 2AA batteries, not included in this purchase. Do not mix old and new batteries. Do not mix alkaline, standard, or rechargeable batteries. After inserting batteries, test the power by pushing and holding the button on handle. Holding the button illuminates the red light indicating the electrical grid is activated. Grid shuts off after button is released, however, there may be temporary residual energy remaining. Replace batteries when light no longer turns on.

**NEVER HANDLE THE PRODUCT BY METAL GRIDS.**

#### **DIRECTIONS FOR USE AS A ZAPPER:**

Safely aim the metal grid surface at flying insects while pressing and holding the trigger button to activate the electrical grid and swing. Making contact with the insect should kill the insect on contact. Do not swing next to people or animals. Do not press the power button when using the bottle opener.

#### **CLEANING:**

As bugs make contact, particles may accumulate in the racket face. To clean, remove the batteries and allow the unit to sit for at least 45 minutes to release charge from electric grid. Use vacuum or soft, dry, non-metallic brush to

remove any debris. Frequent cleaning will provide for more efficient use.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**CAUTION — High Voltage, Keep out of Reach of Children.**

**CAUTION – High Voltage, Power off unit before servicing.**

**CAUTION — To reduce the risk of fire, remove insects frequently.**

**CAUTION – Collected insects may be a fire hazard. Clean dead insects from the unit frequently.**

**CAUTION – ELECTRICAL SHOCK HAZARD MAY EXIST IF WATER IS DIRECTED AT UNIT WHILE IN OPERATION.**

**CAUTION – Do not stick foreign objects, metal objects or fingers into the electrical grid.**

**CAUTION – Do not tamper with or modify unit. CAUTION-Do not clean unit while it is powered on.**

**CAUTION – Before cleaning, allow unit to sit for at least 45 minutes to release charge from electric grid.**

**CAUTION – Do not clean or spray the unit with water, cleaning spray, or any other liquid. Do not use or leave in rain.**

**CAUTION – Do not submerge unit in water or any liquid.**

**CAUTION-Do not operate unit near flammable liquids.**

U.S. Patent No. D946,692



## MEGA BUG ZAPPER

### Documents / Resources



[PIC-CORP 94412-CHN-1 Mega Bug Zapper](#) [pdf] Owner's Manual

94412-CHN-1, 94412-CHN-1 Mega Bug Zapper, Mega Bug Zapper, Bug Zapper, Zapper