



PIC Mega Bug Zapper Owner's Manual

[Home](#) » [PIC](#) » PIC Mega Bug Zapper Owner's Manual 

PIC Mega Bug Zapper Owner's Manual

PIC[®] MEGA BUG ZAPPER

Pest Free Living

Owner's Manual IMPORTANT SAFETY INSTRUCTIONS

**READ THE ENTIRE PRODUCT
LABEL AND OWNERS MANUAL
BEFORE USING**



ELECTRIC SHOCK RISK DO NOT TOUCH THE ELECTRIC GRID

Thank you for choosing the PIC[®] Pest Free Living **Mega Bug Zapper** racket. Please read the instruction manual carefully to ensure use of this product complies with all safety regulations.

The product is designed with two safety grids on either side of the zapping device on racket head. Do not pinch or press the grids together. Do not put objects or fingers through the racket face. Keep away from moisture. Do not use in rain. Safe for indoor and outdoor use. Do not attempt to make repairs on the unit. Call our customer service department at **1-800-799-7302** for assistance. This is not a toy. **KEEP AWAY FROM CHILDREN.**

OPERATION INSTRUCTIONS:

The unit requires 2AA batteries (not included). After inserting batteries, test the power by pushing and holding the button on handle. Holding the button illuminates the red light indicating the electrical grid is activated. Grid shuts off after button is released. However, there may be temporary residual energy remaining. Replace batteries when light no longer turns on. DO NOT TOUCH SAFETY GRIDS.

TO USE:

Safely aim the racket grid surface at flying insects while pressing and holding the trigger button to activate the electrical grid and swing. Making contact with the insect should kill the insect on contact. Do not swing next to people or animals. Do not press the power button when using the bottle opener.

CLEANING:

As bugs make contact, particles may accumulate in the racket face. To clean, remove the batteries and use vacuum or soft, dry, non-metallic brush to remove any debris. Frequent cleaning will provide for more efficient use.

CAUTION – High Voltage, Keep out of Reach of Children.

CAUTION – High Voltage, Power off unit before servicing.

CAUTION – To reduce the risk of fire, remove insects frequently.

CAUTION – Collected insects may be a fire hazard. Clean dead insects from the unit frequently.

CAUTION – ELECTRICAL SHOCK HAZARD MAY EXIST IF WATER IS DIRECTED AT UNIT WHILE IN OPERATION.

CAUTION – Do not stick foreign objects, metal objects or fingers into the electrical grid.

CAUTION – Do not tamper with or modify unit.

CAUTION – Do not clean unit while it is powered on.

CAUTION – Before cleaning, allow unit to sit for at least 45 minutes to release charge from electric grid.

CAUTION – Do not clean or spray the unit with water, cleaning spray, or any other liquid. Do not use or leave in rain.

CAUTION – Do not submerge unit in water or any liquid.

CAUTION – Do not operate unit near flammable liquids.

Manufactured For:

PIC® Corporation

1101-1107 W Elizabeth Ave.

Linden, NJ 07036

1-800-799-7302



STOCK# BOT-RAK

MADE IN VIETNAM


EPA Est. No. 93340-VNM-1

v10119

Contents

- 1 Documents / Resources
- 2 Related Posts

Documents / Resources

	<p>PIC Mega Bug Zapper [pdf] Owner's Manual PIC, Mega, Bug, Zapper, Racket</p>
---	--

Manuals+.