



PICHLER Thrust Impeller Brushless User Manual

[Home](#) » [PICHLER](#) » PICHLER Thrust Impeller Brushless User Manual 

Contents

[1 Thrust Impeller
Brushless](#)

[2 Documents / Resources](#)

[3 Related Posts](#)

Thrust Impeller Brushless

THRUST

● EDF ● DUCTED FAN ● IMPELLER



Congratulations for purchasing your new THRUST Brushless EDF! Using the Smartphone QR Code right here, you can access our website and all relative information's and extensive manual.



WARNING Never shorten or lengthen motor wires. Loss of Warranty. Each single motor undergoes many quality checks before shipping. Burned motors do not apply to warranty. Too much load and/or too high battery voltage can result in burning.

Combo Sets /f you bought a combo set, you need to get the suitable battery now. Go to our website www.pichler-modellbau.de

Here you will find plug-ready LEMONRC batteries, perfectly suited to your power unit.

Speed Controller ESC For maximum performance we recommend THRUST brushless ESCs. They are small, powerful and also available in different versions.

Motor connection can be established by soldering the cables or using Gold Plugs.


Installation Mount the power unit to the model using the supplied screws. By swapping 2 of the 3 motor cables you can change the turning direction of the motor.

Propellers are attached with rubber O-Rings.

Battery Choice We do clearly recommend our LEMONRCLiPo batteries. They will unleash the maximum power from your new TRHUST power unit. Please visit our website, to learn which type suits best to your particular need.

PICHLER Modellbau GmbH
84307 Eggenfelden (Germany) fH
www.pichler-modellbau.de

Documents / Resources



[PICHLER Thrust Impeller Brushless](#) [pdf] User Manual

Thrust Impeller Brushless