



Pierre Laurent 82000 Series Heirloom Collection Instructions

[Home](#) » [Pierre Laurent](#) » Pierre Laurent 82000 Series Heirloom Collection Instructions 

Contents

- [1 Pierre Laurent 82000 Series Heirloom](#)
- [2 Operating Instruction For Heirloom Collection 82000 series](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)



Pierre Laurent 82000 Series Heirloom



Operating Instruction For Heirloom Collection 82000 series

Congratulations on owning a Pierre Laurent watch which contains one of the best Swiss Made mechanical movements in the world.

The watch has no electronic parts, no battery or capacitor (which could be expensive to be replaced). With proper maintenance, the watch will last many, many years.

The mechanical automatic movement in a Pierre Laurent timepiece works on your own body energy. When you are wearing the watch, every time you move your wrist, the highly sensitive rotor of the watch will rotate and transmit your body energy into mechanical energy which will be stored by a spring inside a barrel. Usually, it requires a continual wear of at least 6 to 8 hours in order for the watch to save up energy to full capacity with a maximum power reserve of 38 hours.

Under normal wear condition, the watch should be serviced or reconditioned by qualified watch technicians once every 3 to 5 years in order to maintain your watch at the optimal functioning order.

Model – 82000 Series

Movement: Caliber PL 101 / PL 103

Swiss Made mechanical movement, 26 jewels, automatic winding, Incabloc shock resistance.

Case:

45.0 mm diameter, stainless-steel case with front and back sapphire crystals, gold plated models are with 10 microns of 18K gold.

Water resistant to 100 metres.

Water Resistance:

All Pierre Laurent watches are tested under atmospheric pressure to meet international standards. Water resistance is achieved by installing seals between the major parts of the watch case. The watch is fitted with a series of gaskets and a specially designed crown, which together seal the watch and prevent moisture from entering the case. To maintain the integrity of this water-resistant system, periodic maintenance is required. The gaskets and crown are subject to wear and deterioration under conditions of normal use. Therefore, these parts should be inspected and replaced as needed each time the watch is opened for service.

Screw-Down Crown:

The watch is equipped with a screw-down crown, which helps seal the case against water and moisture. Before


There are three crown positions:

The crown is tight against the watch case for maximum water resistance

Unlock the crown to C.1 position by turning anti-clockwise 6 to 8 turns. In this position, you can wind the automatic watch manually by turning the crown clockwise.

Once the crown is unlocked, pull crown gently to position C.2.

Please always remember to screw in the crown tight against the watch case when finished for water resistance purpose.



Documents / Resources

[illegible]

