



JPL24618  
SING & TALK  
GEKKO  
PLUSH



## PJ Masks JPL24618 Sing & Talk Gekko Plush User Manual

[Home](#) » [PJ MASKS](#) » PJ Masks JPL24618 Sing & Talk Gekko Plush User Manual 

### Contents

- [1 PJ Masks JPL24618 Sing & Talk Gekko Plush](#)
- [2 INTRODUCTION](#)
- [3 SPECIFICATIONS](#)
- [4 WHAT'S IN THE BOX](#)
- [5 FEATURES](#)
- [6 SETUP GUIDE](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PROS & CONS](#)
- [10 WARRANTY](#)
- [11 FREQUENTLY ASKED QUESTIONS](#)
- [12 VIDEO – PRODUCT OVERVIEW](#)
- [13 References](#)
- [14 Related Posts](#)



**PJ Masks JPL24618 Sing & Talk Gekko Plush**



## INTRODUCTION

Explore the exciting world of “PJ Masks JPL24618 Sing & Talk Gekko Plush,” a bright and fun toy that brings one of your favorite superheroes to life. This Gekko pet is 14 inches tall and costs \$39.59. It’s made to keep PJ Masks fans interested. The Gekko plush was made by Just Play Products, which is known for making creative and safe toys for kids. It lights up, sings, and talks, so it’s great for hours of fun. This plush toy is great for kids 3 years and up because it lets them act out their favorite PJ Masks scenes or make up their own adventures. The Gekko plush is not only fun to play with, but it can also be used as a comforting nighttime friend thanks to its soft, cuddly exterior and reassuring light feature. It came out in 2023 to the delight of both kids and fans.

## SPECIFICATIONS

Brand Name	PJ Masks
Model Name	PJ Masks Feature Plush Gekko
Model Number	JPL24618
Item Weight	0.37 Kilograms
Size	14 Inch
Item Dimensions (L x W x H)	7.75 L x 4.5 W x 15 H Inches
Unit Count	1.0 Count
Manufacturer Minimum Age	36 months
Number of Batteries	3 LR44 batteries required
Are Batteries Required	Yes
Special Features	Light
Material Type	Plush
Price	\$39.59

## WHAT'S IN THE BOX

- Sing & Talk Gekko Plush
- Battery
- Manual

## FEATURES

- **Size:** Every stuffed animal is 14 inches tall, which is just the right size for playing with and holding.
- **Lights and Sounds:** The Gekko toy has lights and sounds that make play more fun.
- **lines from the Show:** When kids press Gekko's hand, they can hear fun lines from the hit PJ Masks show. This makes the experience even more real.
- **Theme Song:** The soft toy lets kids sing along with the catchy PJ Masks theme song, which makes playing more fun.
- **Hero Amulet:** Turning on the hero amulet on Gekko's chest makes lights appear, giving evening adventures a magical feel.
- **Soft Deluxe Fabrics:** The toys are made with high-quality soft plush materials, so they are soft and comfy.
- **Not heavy:** It only weighs 0.37 kilograms, which makes it easy for kids to move and handle.
- **Collectible Characters:** It's part of a set with Catboy and Owlette, which makes kids want to collect all three.
- **Durability:** Made to last, good for busy play.
- The ideal gift for PJ Masks fans on their birthday, during the holidays, or for any other special event.
- Interactive play puts kids in make-believe situations that help them be more creative.
- **Age Suggestion:** This book is good for kids 3 years and up.
- **Easy to Clean:** To keep things clean, the soft outside can be lightly sanitized.

- Official PJ Masks merchandise is licensed merchandise from the series, so you can be sure it's real.
- **Battery-operated:** needs three LR44 batteries, which are included, and can be used right away after purchase.

## SETUP GUIDE

- **Unbox the Toy:** Carefully take Gekko out of the box, making sure not to damage the toy in the process.
- **Check the Accessories:** Make sure that all of the things that came with the toy, like the instruction booklet and the plush, are there.
- **Insert Batteries:** If you need to, open the battery box (which is usually in the back) and put in three LR44 batteries, making sure they are in the right way around.
- **Close Battery Compartment:** Make sure the battery cover is securely closed so the battery doesn't fall out by chance.
- To turn on the toy, find the power switch and flip it to the "ON" setting if there is one.
- **Activate Sounds:** Press Gekko's hand to make sure the sound features are working right and test them.
- **Play:** Tell kids they can connect with Gekko by pressing on his hand to hear words and singing along with the theme song.
- **Use the Amulet:** Show kids how to use the hero amulet to make amazing light effects while they play.
- **Group Play:** If you have more than one PJ Masks soft toy, play with them as a group to see how they get along.
- **Set up a Play Area:** Make sure there are no hurdles in the play area so that everyone can play safely.
- **Rotate Songs:** Tell kids to press their hand more than once to hear different words.
- Encourage creativity by coming up with story ideas for pretend play, like Gekko and his friends saving the day.
- **Watch Kids Play:** Always watch kids play to make sure they use the toy in a safe and smart way.
- **How to Store It:** Gekko should be kept in a cool, dry place when not in use to keep its quality.
- **Document Play:** Record fun times on video or pictures that you can send to family and friends.



## CARE & MAINTENANCE

- **Regular Care:** Use a wet cloth to wipe down the plush's surface to get rid of dust and dirt.
- **Inspect for Damage:** Check for signs of wear, damage, or broken parts every so often.
- **Maintenance for batteries:** Change them when they die or if the sounds get weak or stop.
- **Avoid Too Much Moisture:** To keep Gekko from getting hurt, keep it away from water and other wet places.
- Gekko should be kept in a safe, dry place out of direct sunlight when not in use.
- **Handling with Care:** Teach kids how to be gentle with Gekko to make it live longer.
- **Quick Repairs:** If any problems happen, like sounds or moves that don't work, they should be fixed right away.
- **Watch Young Children:** For safety's sake, you should always keep an eye on younger children while they play.
- **Take Out the Batteries for Storage:** If you're going to be keeping something for a long time, you might want to take out the batteries to stop leaks.
- **Do Not Put Heavy Things On Gekko:** Do not put heavy things on Gekko to keep the plush from getting crushed or damaged.
- To teach kids responsibility, make them feel like they need to take care of their toys.
- **Rotate Playtime Activities:** To keep toys from wearing out too quickly, encourage different kinds of play.
- **Make Sure the Play Area Is Clean:** Make sure the area where Gekko is played is clean and safe.
- **Enjoy Together:** Make playing a family game to help everyone get to know each other and be creative.

TROUBLESHOOTING

Issue	Solution
Toy does not talk or sing	Check and replace the LR44 batteries.
Sound is distorted	Ensure the speaker is not obstructed or dirty.
Light feature not working	Verify battery installation and replace if necessary.
Toy stops functioning	Reset by turning it off and on; check battery contact points.
Fabric stains	Clean gently with a damp cloth using mild soap; avoid harsh chemicals.
Batteries deplete quickly	Use high-quality batteries for better performance.
Toy falls over	Ensure it's placed on a stable, flat surface during display or play.
Button unresponsive	Clean around the buttons; check for stickiness or obstructions.
Toy emits a burning smell	Remove batteries and discontinue use immediately; contact customer service.
Fabric tears	Sew minor tears; contact manufacturer if under warranty for major issues.
The sound volume is too low	Check if something is blocking the speaker area internally.
Unresponsive to touch	Check if the touch sensors are functioning correctly; may need resetting.
LED malfunction	Inspect LEDs for connection issues or replace batteries.
Faint or intermittent audio	Ensure batteries are fresh and properly aligned.
Toy overheats during use	Stop use, let it cool, and check the battery compartment for damage.

PROS & CONS

PROS:

- 1. **Interactive Features:** Talks and sings, enhancing playtime with engaging sounds.
- 2. **Comforting Companion:** Soft plush material makes it ideal for cuddling and comfort.
- 3. **Inspires Imagination:** Encourages role-playing and storytelling among children.
- 4. **Safety First:** Designed with child-safe materials and battery enclosures.
- 5. **Visual Appeal:** Bright colors and accurate character depiction increase its appeal.

CONS:

- 1. **Battery Dependency:** Requires frequent battery changes for continuous use.
- 2. **Limited Functionality:** Restricted to pre-programmed phrases and songs.
- 3. **Maintenance:** Plush material may gather dust, requiring regular cleaning.
- 4. **Sound Volume:** Non-adjustable volume that might be too loud for some environments.
- 5. **Price Point:** Relatively high cost for a plush toy with basic electronic features.

## WARRANTY

The PJ Masks JPL24618 Sing & Talk Gekko Plush comes with a 90-day warranty from Just Play Products, covering defects in materials and workmanship under normal use. This warranty ensures that any issues with the toy due to manufacturing faults can be addressed directly through customer service, providing assurance of quality and satisfaction.

## FREQUENTLY ASKED QUESTIONS

What is the PJ Masks JPL24618 Sing & Talk Gekko Plush?

The PJ Masks JPL24618 Sing & Talk Gekko Plush is an interactive plush toy designed to engage children with sounds, songs, and light features based on the popular animated series.

What is the price of the PJ Masks JPL24618?

The PJ Masks JPL24618 Sing & Talk Gekko Plush is priced at \$39.59, making it a fun gift for fans of the PJ Masks series.

What are the dimensions of the PJ Masks JPL24618?

The dimensions of the PJ Masks JPL24618 are 7.75 inches in length, 4.5 inches in width, and 15 inches in height.

How much does the PJ Masks JPL24618 weigh?

The PJ Masks JPL24618 weighs 0.37 kilograms (approximately 0.82 pounds), making it lightweight and easy for children to handle.

What is the minimum age recommendation for the PJ Masks JPL24618?

The manufacturer recommends the PJ Masks JPL24618 for children aged 36 months (3 years) and older.

What type of batteries does the PJ Masks JPL24618 require?

The PJ Masks JPL24618 requires 3 LR44 batteries for its sound and light features.

Are batteries included with the PJ Masks JPL24618?

Typically, the batteries are not included with the PJ Masks JPL24618, so you will need to purchase 3 LR44 batteries separately.

What special features does the PJ Masks JPL24618 have?

The PJ Masks JPL24618 features interactive audio and light, allowing it to sing songs and respond to interactions with children.

What types of sounds does the PJ Masks JPL24618 produce?

The PJ Masks JPL24618 typically produces songs and phrases associated with the character Gekko from the PJ Masks series.

How does the sound activation work on the PJ Masks JPL24618?

The sound feature is typically activated by pressing a button on the plush toy, prompting it to play sounds or songs.

What makes the PJ Masks JPL24618 a great gift for children?

The combination of its interactive features, the beloved character Gekko, and soft plush design makes the PJ Masks JPL24618 an exciting and comforting gift for young fans.

Can the PJ Masks JPL24618 be machine washed?

It is generally recommended to spot clean the PJ Masks JPL24618 to preserve its electronic components and plush material.



What educational benefits does the PJ Masks JPL24618 provide?

The PJ Masks JPL24618 helps develop language skills through songs and sounds, promotes imaginative play, and provides comfort and companionship to young children.

Why is my PJ Masks JPL24618 Sing & Talk Gekko Plush not turning on?

Ensure the batteries are inserted correctly and fully charged. If it still doesn't turn on, try replacing the batteries and check that the power switch is set to the on position.

Why is my PJ Masks JPL24618 Sing & Talk Gekko Plush not making any sound?

If the toy isn't producing sound, the batteries might be weak or incorrectly inserted. Replace the batteries with new ones and ensure they are properly aligned.

#### VIDEO – PRODUCT OVERVIEW



[References.plus/wp-content/uploads/2024/10/PJ-Masks-JPL24618-Sing-Talk-Gekko-Plush-User-Manual.mp4](https://www.references.plus/wp-content/uploads/2024/10/PJ-Masks-JPL24618-Sing-Talk-Gekko-Plush-User-Manual.mp4)

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.