



PLIANT TECHNOLOGIES MicroCom 2400M Wireless Intercom User Guide

[Home](#) » [PLIANT TECHNOLOGIES](#) » PLIANT TECHNOLOGIES MicroCom 2400M Wireless Intercom User Guide



PLIANT TECHNOLOGIES Micro Com 2400M Wireless Intercom User Guide



Contents

- [1 Overview](#)
- [2 IN THIS BOX](#)
- [3 ACCESSORIES](#)
- [4 SETUP](#)
- [5 OPERATION](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

Overview



Additional Documentation

This is a quick start guide. For additional details on menu settings, device specifications, and product warranty, view the full Micro Com Operating Manual on our website. (Scan this QR code with your mobile device to navigate there quickly.)



IN THIS BOX

WHAT'S INCLUDED WITH MICROCOM 2400M?

- Holster
- Lanyard
- USB Charging Cable

ACCESSORIES

OPTIONAL ACCESSORIES

- **PAC-USB6-CHG:** MicroCom 6-Port USB Charger
- **PAC-MC-5CASE:** IP67-rated Hard Travel Case
- **PAC-MC-SFTCASE:** MicroCom Soft Travel Case
- Selection of compatible headsets (see Pliant website for more details)

SETUP

1. **Connect a headset to the belt pack.**
2. **Power on.** Press and hold the **Power** button for three (3) seconds, until the screen turns on.
3. **Select a Group.** Press and hold the **Mode** button for 3 seconds until the “GRP” symbol is blinking on the LCD. Then, use the **Volume** +/- buttons to select a group number from 0–51. Short-press **Mode** to save your selection and proceed to ID setting.
IMPORTANT: Beltpacks must have the same group number to communicate.
4. **Select an ID.** When “ID” begins to blink on the LCD, use the **Volume** +/- buttons to select an ID number. Press and hold **Mode** to save your selection and exit the menu.

Figure 1: Group Edit Screen



- a. Pack IDs range from 00–05.
- b. One pack must always use the “00” ID and serve as the master pack for proper system function. “MR” designates the master pack on its LCD.
- c. Listen-only packs must use the “05” ID. You may duplicate ID “05” on multiple beltpacks if setting up listen-only users. (See the MicroCom 2400M Manual for more information about that process.)
- d. Shared Talk beltpacks must use the “Sh” ID. You may duplicate ID “Sh” on multiple beltpacks if setting up shared users. However, the “Sh” ID cannot be used at the same time as the last full-duplex ID (“04”).

Figure 2: ID Edit Screen (Master ID)



OPERATION

- **Talk** – Use the Talk button to enable or disable talk for the device. This button changes with a single, short press. “TK” appears on the LCD when enabled.
 - For full-duplex users, use a single, short press to toggle talk on and off.
 - For Shared Talk users (“Sh”), press and hold while talking to enable it for the device. (Only one Shared Talk user can talk at a time.)
- **Volume Up and Down** – Use the + and – buttons to control the volume. “VOL” and a numerical value from 00–09 appear on the LCD when volume is adjusted.

Multiple MicroCom Systems

Each separate Micro Com system should use the same Group for all belt packs in that system. Pliant recommends that systems operating in proximity to one another set their Groups to be at least 10 values apart. For example, if one system is using Group 03, another system nearby should use Group 13

Battery

- **Battery life:** Approx. 7.5 hours
- **Charge time from empty:** Approx. 3.5 hours
- Charging LED on belt pack will illuminate red while charging and will turn off when charging complete.
- Belt pack may be used while charging, but doing so may lengthen charge time.

Menu Options

To access the menu, press and hold the **Mode** button for 3 seconds. Once you have finished your changes, press and hold **Mode** to save your selection and exit the menu.

| Menu Setting | Default | Options | Description |
|-----------------------|---------|---------|----------------------------|
| Side Tone | S3 | S0 | Off |
| | | S1–S5 | Levels 1–5 |
| Receiving Mode | PO | PO | Rx & Tx Mode |
| | | PF | Rx-Only Mode (Listen-Only) |
| Mic Sensitivity Level | C1 | C1–C5 | Levels 1–5 |
| Audio Output Level | UH | UL | Low |
| | | UH | High |

Recommended Settings by Headset


| Headset Type | Recommended Setting | |
|---------------------------|---------------------|--------------|
| | Mic Sensitivity | Audio Output |
| Headset with boom mic | C1 | UH |
| Headset with lavalier mic | C3 | UH |

For more information **visit**
www.plianttechnologies.com

COPYRIGHT © 2022 Pliant Technologies, LLC. All rights reserved. Pliant®, Micro Com®, and the Pliant “P” logo are registered trademarks of Pliant Technologies, LLC. Any and all other trademark references within this document are property of their respective owners. Document Reference: D0000522_C



Documents / Resources

| | |
|---|--|
|  | PLIANT TECHNOLOGIES MicroCom 2400M Wireless Intercom [pdf] User Guide MicroCom 2400M Wireless Intercom, MicroCom 2400M, Wireless Intercom, Intercom |
|---|--|

References

-  [Pliant Technologies Wireless Intercom Solutions](#)