



## PLT SOLUTIONS PLT-90301 Color Wattage Selectable LED Stairwell Fixture with Sensor Instruction Manual

[Home](#) » [PLT SOLUTIONS](#) » **PLT SOLUTIONS PLT-90301 Color Wattage Selectable LED Stairwell Fixture with Sensor Instruction Manual** 

### PLT SOLUTIONS PLT-90301 Color Wattage Selectable LED Stairwell Fixture with Sensor Instruction Manual



#### **WARNING**

- Before installing, servicing, or performing routine maintenance upon this equipment, follow these general precautions.
- To reduce the risk of death, personal injury, or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards, read all warnings and instructions included with and on the fixture box and all fixture labels.
- Proper grounding is required to ensure safety.
- Power must be turned off at the breaker before installation or maintenance.

- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Wear gloves and eye protection at all times while installing, servicing, or performing maintenance on the luminaire, and avoid direct eye exposure to the light source while it is on.
- Do not install damaged product. Inspect luminaire for damage that may have occurred during transit. If damaged, contact the manufacturer immediately.
- These instructions do not purport to cover all details or variations in equipment nor to provide every possible contingency to meet in connection with installation, operation, or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's or owner's purposes, contact the manufacturer.

## WARNING

- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp surfaces.

## CAUTION

- Do not make or alter any open holes in the fixture.
- Verify that supply voltage is correct by comparing it with the luminaire label information.
- All wiring connections should be capped with UL approved wire connectors.
- Green ground screw provided in proper location. Do not relocate.
- Minimum 90° supply conductors.

### Contents

#### [1 Installation Instructions](#)

##### [1.1 Wall Mounting](#)

#### [2 Wiring Diagram](#)


#### [3 Documents / Resources](#)

#### [4 Related Posts](#)


## Installation Instructions

### Wall Mounting


1. Remove the lens from the housing. & move **RIORWO**




2. Loosen the two screws that hold the light panel.




3. Allow the light panel to lay unsecured.




4. Install anchor bolt. Drill four holes in the corresponding position on the wall using the positioning plate provided by the manufacturer. Insert an anchor bolt into each hole.




5. Screw four mounting screws into each anchor bolt, then connect the AC wires.




6. Push the module board to its original position and secure the module board to the bracket.




7. Install the lens.



8. The installation is complete.



## Wiring Diagram




972-535-0926

[pltsolutions.com](http://pltsolutions.com)

ver 020723





[PLT SOLUTIONS PLT-90301 Color Wattage Selectable LED Stairwell Fixture with Sensor](#) [pdf] Instruction Manual  
PLT-90301, PLT-90301 Color Wattage Selectable LED Stairwell Fixture with Sensor, Color Wattage Selectable LED Stairwell Fixture with Sensor, Selectable LED Stairwell Fixture with Sensor, LED Stairwell Fixture with Sensor, Fixture with Sensor