



PLUSPTT A3280 Wide Coverage With 4G/LTE And Wi-Fi Networks User Manual

[Home](#) » [PLUSPTT](#) » PLUSPTT A3280 Wide Coverage With 4G/LTE And Wi-Fi Networks User Manual 

Contents

- [1 PLUSPTT A3280 Wide Coverage With 4G/LTE And Wi-Fi Networks](#)
- [2 PRODUCT USING INSTRUCTIONS](#)
- [3 SAFETY INFORMATION](#)
- [4 A3280 OVERVIEW](#)
- [5 STANDARD ACCESSORIES](#)
- [6 BUTTON FUNCTIONS](#)
- [7 RECHARGING THE BATTERY](#)
- [8 DISPOSAL](#)
- [9 CONTACT](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)



PLUSPTT A3280 Wide Coverage With 4G/LTE And Wi-Fi Networks



SAFETY AND REGULATORY INFORMATION

- Do not open the device without authorization or alter any of its components. Interventions made without proper technical training violate the Push-to-Talk device's warranty and run the risk of doing irreversible harm.
- Use only original batteries and chargers with your push-to-talk device.
- Turn the device off at fuel stations.
- Do not expose the push-to-talk device to sunlight for a long time.
- Do not leave the push-to-talk device in extremely dusty or humid areas for a long time.
- Charge the battery of the push-to-talk device for 9 uninterrupted hours before using it for the first time.

PRODUCT USING INSTRUCTIONS

BUTTON FUNCTIONS

1. Turning the Device On/Off: The Device is switched on by long pressing the Power Button. The PlusPTT application launches itself and joins the specified channel. The channel's users are listed. Long pressing the Power Button will turn the device off.
2. Adjusting the sound: The sound is adjusted by pressing the Volume +/- buttons.

3. Announce to Channel: After the device is turned on and the users in the channel are listed, the announcement is made by pressing the PTT Button.
4. Private Single Call – Private Group Call: Double-clicking on the touch screen selects users. By pressing the Dial Key, you can initiate a private call. To end the conversation, press the Power Key.
5. Switch Channel: Channel Keys are used to switch channels.
6. Emergency Alarm: SOS Button is pressed to send an SOS signal to the Dispatch Console and other users in the same channel.

RECHARGING THE BATTERY

Please take the following safety measures in order to operate the radio in a healthy and safe manner.

1. To prevent damage and void the warranty, please only use the original charger.
2. Connect the Push-to-Talk device's USB cable after plugging in the power adapter supplied with it.
3. Turn the device off before charging.
4. The indicator led will turn red as soon as the device begins to charge. Charging is finished when the indicator led changes to green.

Warnings

1. Remove the charging cable after the battery has been fully charged. Continuous charging of the device reduces battery life.
2. The charging ambient temperature should be between 5 and 40 degrees Celsius. The battery will not charge fully in temperatures outside of this range.
3. If the usage time of your properly charged device is very short, this indicates that the battery has reached the end of its life. Replace the device's battery with a new one.

RECYCLING OF THE DEVICE

The packaging of the product is produced from recyclable materials in accordance with our National Legislation. Dispose of packaging waste together with domestic or other waste, at packaging collection points designated by the local authority.

Web

- <https://idearge.com.tr>
- <https://plusptt.app>

Dear Customer

Thank you for preferring PlusPTT products. Manufactured with the highest quality and the cutting-edge technology, our product aims to provide you the optimal efficiency. Please read this manual before using this product and keep it to serve you as further reference. This Manual has been drawn up for informational purposes only. The entire information presented herein is subject to amendments without further notice. İdearge is not responsible for any amendments, direct or indirect damages arising from or related to the use of this manual. PlusPTT and PlusPTT logo are the trademarks of İDE İnovasyon Arge Yatırım Danışmanlık San. Tic. A.Ş.

SAFETY INFORMATION

SAFETY AND REGULATORY INFORMATION

- Do not open the device without authorization or alter any of its components. Interventions made without proper technical training violate the Push-to-Talk device's warranty and run the risk of doing irreversible harm.
- Use only original batteries and chargers with your push-to-talk device.
- Turn the device off at fuel stations.
- Do not expose the push-to-talk device to sunlight for a long time.
- Do not leave the push-to-talk device in extremely dusty or humid areas for a long time.
- Charge the battery of the push-to-talk device for 9 uninterrupted hours before using it for the first time.

A3280 OVERVIEW



STANDARD ACCESSORIES



Belt Clips



Power Adapter



Type-C Cable

BUTTON FUNCTIONS

1. **Turning the Device On/Off:** The Device is switched on by long pressing the Power Button. The PlusPTT application launches itself and joins the specified channel. The channel's users are listed. Long pressing the Power Button will turn the device off.
2. **Adjusting the sound:** The sound is adjusted by pressing the Volume +/- buttons.
3. **Announce to Channel:** After the device is turned on and the users in the channel are listed, the announcement is made by pressing the PTT Button.
4. **Private Single Call – Private Group Call:** Double-clicking on the touch screen selects users. By pressing the Dial Key, you can initiate a private call. To end the conversation, press the Power Key.
5. **Switch Channel:** Channel Keys are used to switch channels.
6. **Emergency Alarm:** SOS Button is pressed to send an SOS signal to the Dispatch Console and other users in the same channel.

RECHARGING THE BATTERY

Please take the following safety measures in order to operate the radio in a healthy and safe manner.

1. To prevent damage and void the warranty, please only use the original charger.
2. Connect the Push-to-Talk device's USB cable after plugging in the power adapter supplied with it.
3. Turn the device off before charging.

4. The indicator led will turn red as soon as the device begins to charge. Charging is finished when the indicator led changes to green.

Warnings

1. Remove the charging cable after the battery has been fully charged. Continuous charging of the device reduces battery life.
2. The charging ambient temperature should be between 5 and 40 degrees Celsius. The battery will not charge fully in temperatures outside of this range.
3. If the usage time of your properly charged device is very short, this indicates that the battery has reached the end of its life. Replace the device's battery with a new one.

DISPOSAL

RECYCLING OF THE DEVICE

This symbol on the product or its packaging indicates that the product is required not be handled as a domestic waste. This product is manufactured by using high quality parts and materials that can be recycled and reused. Therefore, do not dispose the product with the domestic or other waste at the end of its service life. Dispose it at a dedicated waste collection point for the recycle of electrical or electronic equipment. Consult your local government on these collection points. Please help preserving the environment and natural resources by recycling used products.

PACKAGING INFORMATION

The packaging of the product is produced from recyclable materials in accordance with our National Legislation. Dispose of packaging waste together with domestic or other waste, at packaging collection points designated by the local authority.

CONTACT

MANUFACTURER/AUTHORIZED SERVICE

- İDE İNOVASYON ARGE YATIRIM DANIŞMANLIK SANAYİ TİC A.Ş.
- Üniversiteler Mah. 1596. Cad. Hacettepe Teknokent No:6A/34 Beytepe Çankaya ANKARA
- **Tel:** +90 312 227 0128
- **Web:** <https://idearge.com.tr>
- <https://plusptt.app>

<p>PLUSPTT A3280</p> <p>USER MANUAL</p>	<p>PLUSPTT A3280 Wide Coverage With 4G/LTE And Wi-Fi Networks [pdf] User Manual A3280 Wide Coverage With 4G LTE And Wi-Fi Networks, A3280, Wide Coverage With 4G LTE And Wi-Fi Networks, Coverage With 4G LTE And Wi-Fi Networks, 4G LTE And Wi-Fi Networks, And Wi-Fi Networks, Wi-Fi Networks</p>
---	---

References

- [İdearge Prolupus – Anasayfa](#)
- [PlusPTT Baş Konuş GSM/Wifi tabanlı telsizler](#)