



pmd Clean Pro Smart Facial Cleansing Device User Guide

[Home](#) » [pmd](#) » pmd Clean Pro Smart Facial Cleansing Device User Guide 

Contents

- [1 pmd Clean Pro Smart Facial Cleansing Device](#)
- [2 Product Usage Instructions](#)
- [3 GETTING STARTED](#)
- [4 HOW TO USE](#)
- [5 INCLUDES](#)
- [6 FAQ's](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



pmd Clean Pro Smart Facial Cleansing Device



Product Information

The PMD Clean Pro is a smart facial cleansing device that offers two modes for cleansing and two modes for massaging. It is designed to provide effective cleansing and help improve the overall appearance of the skin. The device is equipped with ActiveWarmth™ technology that enhances the absorption of skincare products. The PMD Clean Pro features a silicone brush head that is odor-resistant, antibacterial, hypoallergenic, and waterproof. The brush head does not need to be replaced, making it hassle-free and cost-effective. The device comes with a charging cord and a storage case. It has a battery life of 150-180 minutes, allowing for multiple uses before needing to be recharged. The PMD Clean Pro is also waterproof, making it safe to use in the shower. The product is backed by a One-Year Limited Manufacturer Warranty.

Product Usage Instructions

Cleansing

1. Rinse your face with warm water and gently rub in your preferred cleanser.
2. Rinse the PMD Clean Pro under water and power on the device.
3. For optimum cleansing results, we recommend using modes 1 or 2.
4. Move the brush head in circular motions, cleansing your entire face. You can spend more time in areas that require extra attention.
5. Use the device once or twice per day.

Massaging

1. Apply your desired skincare products.
2. Use the back side of the PMD Clean Pro on mode 3 or 4 for gentle massaging.
3. To enhance the effectiveness of serums, power on ActiveWarmth™ on the device.
4. We recommend using modes 3 or 4 for massaging.
5. The PMD Clean Pro helps lift, firm, and tone the skin through its pulsations. It also stimulates blood flow and increases collagen production.

Charging

Charge the device for 2-3 hours before its first use.

Care Instructions

Wash the PMD Clean Pro with soap and warm water. Pat dry with a clean towel and let it air dry.

FAQ's

- **Does the brush head need to be replaced?**

No, the silicone brush is odor-resistant, antibacterial, hypoallergenic, and waterproof. It does not need to be replaced.

- **How long should I use the massager?**

We suggest using the massager for one minute per area daily.

- **How long does the PMD Clean Pro battery last?**

The battery lasts for 150-180 minutes.

- **Can I use this in the shower?**

Yes, the PMD Clean Pro is waterproof and safe to use anywhere.

- **Can I use my own soap?**

Yes, the PMD Clean Pro works with all liquid cleansers.

BRILLIANTCONFIDENCE

To learn more about the PMD Clean Pro, visit eu.pmdbeauty.com/clean-pro

FOLLOW US

- Youtube: pm beauty
- Instagram: pm beauty
- Pinterest: pm beauty

CAUTION: Please read this manual carefully before using

GETTING STARTED

Cleansing

- Mode 1: Gentle Vibration
- Mode 2: Intense Vibration

Massaging

- Mode 1: Gentle Pulsation
- Mode 2: Intense Pulsation

HOW TO USE

Cleansing

Instructions: Rinse face with warm water and gently rub in cleanser. Rinse PMD Clean Pro under water and power on the device, we recommend modes 1 and 2 for optimum cleansing results. Move the brush head in circular motions, cleansing the entire face, it is safe to spend more time in areas that may be of personal concern. Cleanse once or twice per day.

Massaging

Instructions: Apply skincare products and use the back side of the PMD Clean Pro on mode 3 or 4 to gently massage, by powering on ActiveWarmth™ on the PMD Clean Pro, serums will be more effective and absorb deeper into the skin. We recommend using mode 3 or 4 for massaging. By operating at a perfect frequency, the PMD Clean Pro lifts, firms and tones the skin, through the pulsations of the device, blood flow is stimulated and collagen production is increased

Charging


Charge the device for 2-3 hours before first use.

Care Instructions

Wash with soap and warm water, pat dry with a clean towel, and let it air dry.

INCLUDES

- PMD Clean Pro
- Charging Cord
- Storage Case



The PMD Clean Pro comes with a One-Year Limited Manufacturer Warranty.

FAQ's

Does the brush head need to be replaced?

No, our silicone brush is odor-resistant, antibacterial, hypoallergenic, and waterproof. The brush head is hassle-free and never needs replacing.

How long should I use the massager?

We suggest using the massager for one minute per area daily.

How long does the PMD Clean Pro battery last?

150-180 minutes.

Can I use this in the shower?

Absolutely! The PMD Clean Pro is waterproof and safe to use anywhere.

Can I use my own soap?

Yes! The PMD Clean Pro works with all liquid cleansers.

Caution and Warnings

Use only as directed. Not following instructions may lead to rash, redness, itching, or even injury. If this occurs, discontinue use and consult a medical professional. The product is intended for external use only. Avoid sensitive areas, including any area with broken, irritated, or itching skin. Keep product out of reach of children. PMD is not responsible for malfunction or injury if the product is not used as intended. Not intended for clinical or commercial use. The effects of the PMD Clean are not always immediately visible and results may vary. If you have any questions regarding the application, please reach out to our experts at 888-445-4532.

#BRILLIANTCONFIDENCE

To learn more visit: eu.pmdbeauty.com/clean-pro

Documents / Resources

pmd.
Quick Start Guide
pmd. | clean pro
SMART FACIAL CLEANSING DEVICE

CAUTION: Please read this manual carefully before using.

GETTING STARTED

Cleaning	Warning
Step 1: Initial Use	Step 1: Initial Use
Step 2: Daily Use	Step 2: Daily Use

HOW TO USE

Cleaning

1. Turn on the device by pressing the power button. The device will vibrate and the screen will display "CLEANING".

2. Gently massage the device over your face in circular motions. Avoid the eyes and mouth.

3. The device will automatically stop after 30 seconds.

4. Rinse your face with water.

Warning

Do not use the device on broken, irritated, or itchy skin. Do not use the device on your neck or chest. Do not use the device on your face if you are pregnant or breastfeeding. Do not use the device if you are allergic to any of the ingredients. Do not use the device if you are using any other facial treatment products.

Charging

1. Plug the device into the charging cable.

2. The device will charge for 2 hours.

Care Instructions

1. Clean the device with a soft cloth.

2. Do not use the device if it is damaged.

INCLUDED

1. PMD Clean Pro Smart Facial Cleansing Device

2. Charging Cable

3. User Manual

The PMD Clean Pro Smart Facial Cleansing Device is a registered trademark of PMD Beauty, Inc. © 2020 PMD Beauty, Inc. All rights reserved.

[pmd Clean Pro Smart Facial Cleansing Device \[pdf\] User Guide](#)

Clean Pro Smart Facial Cleansing Device, Clean Pro, Smart Facial Cleansing Device, Facial Cl
eansing Device, Cleansing Device