

PMD Clean Smart Facial Cleansing Device User Guide

Home » pmd » PMD Clean Smart Facial Cleansing Device User Guide The Company of the PMD Clean Smart Facial Cleansing Device User Guide The Company of the PMD Clean Smart Facial Cleansing Device User Guide The PMD Clean Smart Facial Cleansing Device User Guide The PMD Clean Smart Facial Clean Smart

Contents

- 1 PMD Clean Smart Facial Cleansing
- Device
- **2 Product Usage Instructions**
- **3 SMART FACIAL CLEANSING DEVICE**
- **4 GETTING STARTED**
- **5 HOW-TO USE**
- **6 INCLUDES**
- 7 FAQ's
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



PMD Clean Smart Facial Cleansing Device



Specifications

Product Name: clean TM SMART FACIAL CLEANSING DEVICE

• Modes: Cleansing - Gentle Vibration, Intense Vibration; Massaging - Gentle Pulsation, Intense Pulsation

• Power Source: AA Battery

• Warranty: One-Year Limited Manufacturer Warranty

Material: SiliconeWaterproof: Yes

Product Usage Instructions

Cleansing:

- 1. Rinse your face with warm water and apply a cleanser.
- 2. Rinse the PMD Clean under water and power on the device.
- 3. Select mode 1 or 2 for cleansing.
- 4. Move the brush head in circular motions, covering the entire face.
- 5. You can spend more time on areas that require extra attention.
- 6. Recommended usage: once or twice per day.

Massaging:

- 1. Apply skincare products to your face.
- 2. Use the back side of the PMD Clean on mode 3 or 4 for massaging.
- 3. The device's pulsations help lift, firm, and tone the skin.

4. Stimulate blood flow and increase collagen production with gentle massages.

Care Instructions:

Wash the PMD Clean with soap and warm water after each use. Pat dry with a clean towel and allow it to air dry.

FAQs:

Does the brush head need to be replaced?

No, our silicone brush is odor-resistant, antibacterial, hypoallergenic, and waterproof. The brush head is hassle-free and never needs replacing.

How long should I use the massager?

We recommend using the massager for one minute per area daily.

· How long does the PMD Clean battery last?

If used once a day, the battery should last up to two months.

• Can I use this in the shower?

Absolutely! The PMD Clean is waterproof and safe to use in the shower.

Can I use my own soap?

Yes! The PMD Clean is compatible with all liquid cleansers.

SMART FACIAL CLEANSING DEVICE

CAUTION: Please read this manual carefully before using

GETTING STARTED

Cleansing:

• Mode 1: Gentle Vibration

• Mode 2: Intense Vibration

Massaging:

• Mode 1: Gentle Pulsation

• Mode 2: Intense Pulsation

HOW-TO USE

Cleansing:

Instructions: Rinse face with warm water and gently rub in cleanser. Rinse PMD Clean under water and power on the device, we recommend modes 1 and 2 for optimum cleansing results. Move the brush head in circular motions, cleansing the entire face, it is safe to spend more time in areas that may be of personal concern. Cleanse once or twice per day.

Massaging:

Instructions: Apply skincare products and use the back side of the PMD Clean on mode 3 or 4 to gently massage. By operating at a perfect frequency, the PMD Clean lifts, firms and tones the skin, through the pulsations of the device, blood flow is stimulated and collagen production is increased

Care Instructions:

Wash with soap and warm water, pat dry with a clean towel, and let it air dry.

INCLUDES

- PMD Clean
- · AA Battery
- Stand



The PMD Clean comes with a One-Year Limited Manufacturer Warranty.

FAQ's

· Does the brush head need to be replaced?

No, our silicone brush is odor-resistant, antibacterial, hypoallergenic, and waterproof. The brush head is hassle-free and never needs replacing.

· How long should I use the massager?

We suggest using the massager for one minute per area daily.

· How long does the PMD Clean battery last?

If you use the device once a day, the battery should last up to two months.

· Can I use this in the shower?

Absolutely! The PMD Clean is waterproof and safe to use anywhere.

· Can I use my soap?

Yes! The PMD Clean works with all liquid cleansers.

Caution and Warnings:

Use only as directed. Not following instructions may lead to rash, redness, itching or even injury. If this occurs, discontinue use and consult a medical professional. The product is intended for external use only. Avoid sensitive areas, including any area with broken, irritated, or itching skin. Keep product out of reach of children. PMD is not responsible for malfunction or injury if the product is not used as intended. Not intended for clinical or commercial use. The effects of the PMD Clean are not always immediately visible and results may vary. If you have any questions regarding the application, please reach out to our experts at 888-445-4532.

#BRILLIANTCONFIDENCE

To learn more visit: pmdbeauty.com/collections/pmd-clean

FOLLOW US

- · Youtube @pmd
- Instagram @pmdbeauty
- · Pinterest @pmdbeauty

Documents / Resources



PMD PMD Clean Smart Facial Cleansing Device [pdf] User Guide

PMD Clean Smart Facial Cleansing Device, PMD Clean, Smart Facial Cleansing Device, Facial Cleansing Device, Cleansing Device

References

- PMD Clean PMD Beauty
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.