

Polaris H0690100 Suction-Side Pool Cleaners User Guide


[Home](#) » [Polaris](#) » Polaris H0690100 Suction-Side Pool Cleaners User Guide 

Contents

- [1 Polaris H0690100 Suction-Side Pool Cleaners](#)
- [2 Unpack](#)
- [3 Check Cleaner Flow](#)
- [4 Storage](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)




Polaris H0690100 Suction-Side Pool Cleaners



WARNING:

RISK OF SUCTION ENTRAPMENT HAZARD, WHICH IF NOT AVOIDED, CAN RESULT IN SERIOUS INJURY OR DEATH. READ THIS MANUAL IN ITS ENTIRETY BEFORE INSTALLING AND OPERATING THE CLEANER. Ensure that the vacuum suction fittings installed in your pool for connection of your suction-side pool cleaner are certified compliant with applicable safety standards, such as IAPMO SPS 4. Do not block the suction fittings in the pool, the suction opening on this product, or the cleaner hoses with any part of your body. Do not expose your hair, loose clothing, jewelry, etc. to any suction outlet fittings in the pool/spa, on this product, or on the cleaner. Do not operate the cleaner outside of the pool. Do not let children play with cleaner.


Unpack



To avoid serious injury, turn off the pool filter pump during installation.


1. Clean pool filter, pump basket and skimmer basket.
2. Close the main drain to the pool.
3. Aim the return line fittings down.

Connect to a skimmer




OR

A Dedicated Suction Line




Required Length of Hose =
Farthest point across pool +1 (Leader Hose) (c).
Start at skimmer or dedicated suction line

Required Length of Hose =
Farthest point across pool +1
(Leader Hose) (c).
Start at skimmer
or dedicated suction line




1. Submerge hose and flood with water (no bubbles visible).
2. Submerge cleaner and flood with water (no bubbles visible).
3. Connect cleaner head to hose.
4. Turn on pool filter pump.



Check Cleaner Flow

Watch the indicator. Use a stopwatch to time 10 wheel rotations.


*If wheels change direction during timing, start over.



10 rotations within **20 seconds** = Good Flow
tours
rotaciones


Adjust flow if necessary

10 rotations	>	25 seconds	Poor Performance	Increase Flow	+
10 rotations	<	20 seconds	Possible Damage	Decrease Flow	-



Storage


Store the cleaner out of the water on its side. Unlock hoses and store straight or standing up.



For complete operating instructions, please download the manual from the website, call the customer service number or submit a written request to

©2021 Zodiac Pool Systems LLC. All rights reserved. Polaris® and the Polaris 3-wheeled cleaner design are registered trademarks of Zodiac Pool Systems LLC. All other trademarks referenced herein are the property of their respective owners.

Documents / Resources



[Polaris H0690100 Suction-Side Pool Cleaners](#) [pdf] User Guide
H0690100 Suction-Side Pool Cleaners, H0690100, Suction-Side Pool Cleaners, Pool Cleaners, Cleaners

References

- [Home | Polaris Pool](#)
- [Home | Polaris Pool](#)