

**Polaris H0832100 PIXEL Compact Cordless Robotic Cleaner**



# Polaris H0832100 PIXEL Compact Cordless Robotic Cleaner User Guide

[Home](#) » [Polaris](#) » Polaris H0832100 PIXEL Compact Cordless Robotic Cleaner User Guide 

## Contents

- [1 Polaris H0832100 PIXEL Compact Cordless Robotic Cleaner](#)
- [2 Product Usage Instructions](#)
- [3 What's In The Box](#)
- [4 Status LED](#)
- [5 Setup and Charging](#)
- [6 Start Cleaning](#)
- [7 Remove from Pool](#)
- [8 Cleaning and Storage](#)
- [9 Contact Information](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)



**Polaris H0832100 PIXEL Compact Cordless Robotic Cleaner**



### Specifications:

- **Model:** TYPE ET37–
- **Cable Length:** 11.5 ft (3.5 m)

## Product Usage Instructions

### Before You Start

This Quick Start Guide contains essential installation and startup instructions. Read the complete manual and all safety warnings before commencing installation.

### While Charging

- **Solid Green:** Fully Charged
- **Blinking Green:** Ready to run a full cycle (1 h 30 min)
- **Blinking Orange:** Low Battery, charging
- **Blinking Red:** Error

### Ready to Start (unplugged)

- **Solid Green:** Ready to immerse
- **Solid Orange:** Low Battery
- **Blinking Orange:** Very low battery, cannot run
- **Blinking Red:** Error

### During Cycle

- **Solid Green:** In progress
- **Solid Orange:** Low Battery
- **Blinking Red:** Error
- **Off:** Cycle complete

Fully charge the cleaner before the first cleaning.

## Start Cleaning

1. Start the cleaner. Slide the power switch down and release.
2. Submerge the cleaner. Wait for the bubbles to stop completely, then let the cleaner sink to the bottom of the pool. The cleaning cycle will start as soon as the cleaner detects the pool floor.

## Retirar de la piscina – Usar el gancho o la correa flotante

## FAQ

- **Q: How long does it take to fully charge the cleaner?**  
A: The cleaner takes approximately 3 hours to fully charge.
- **Q: What should I do if the cleaner shows a blinking red light?**  
A: A blinking red light indicates an error. Refer to the owner's manual for troubleshooting steps.

For complete instructions and troubleshooting steps, please read the owner's manual.

## Zodiac Pool Systems LLC

2882 Whiptail Loop #100 Carlsbad, CA 92010, USA [PolarisPool.com](http://PolarisPool.com) | 1.800.822.7933


## Zodiac Pool Systems Canada, Inc.

2-3365 Mainway Burlington, ON L7M 1A6, Canada [PolarisPool.ca](http://PolarisPool.ca) | 1.800.822.7933

## Before You Start

This Quick Start Guide contains essential installation and startup instructions. Read the complete manual and all safety warnings before commencing installation.

## What's In The Box



---

## Status LED



### While Charging

- **Solid Green:** Fully Charged
- **Blinking Green:** Ready to run a full cycle (1 h 30 min)
- **Blinking Orange:** Low Battery, charging
- **Blinking Red:** Error

### Ready to Start (unplugged)

- **Solid Green:** Ready to immerse
- **Solid Orange:** Low Battery
- **Blinking Orange:** Very low battery, cannot run
- **Blinking Red:** Error

### During Cycle

- **Solid Green:** In progress
- **Solid Orange:** Low Battery
- **Blinking Red:** Error
- **Off:** Cycle complete


After 8 days of inactivity, the cleaner enters Deep Sleep Mode. Plug in again to wake up.

## Setup and Charging

**Fully charge the cleaner before the first cleaning.**


- Open protective cap covering the charging port
- Ensure the charging port is dry
- Connect to an indoor GFCI outlet
- Only use the charger supplied
- Charging Temperature Range: 40°F – 109°F (5°C – 43°C)

**WARNING:** Do not use an extension cord.



**OPTIONAL:**

Attach the floating leash to the handle to assist with removal of the cleaner from aboveground pools.





**Start Cleaning**

- GREEN Blinking (< 3h) = Ready to run full cycle
- GREEN Solid = Fully Charged





- **(a)** Replace the protective cap over the charging port.
- **(b)** Start the cleaner. Slide the power switch down and release.
- **(c)** Submerge the cleaner.
- **(d)** Wait for bubbles to stop completely, then let the cleaner sink to the bottom of the pool. The cleaning cycle will start as soon as the cleaner detects the pool floor.



## Remove from Pool


### Using the Hook or Floating Leash

- Attach the hook provided to a standard pool pole (not included).
- Secure the hook to the cleaner handle and lift it to the surface.
- Grab the handle to remove it from the water.




- Grab the floating ring and pull cleaner toward the surface

- Remove the cleaner from the water by the handle




## Cleaning and Storage

Remove the filter canister and rinse.



- **IMPORTANT:** Dry the cleaner before charging.
- Charge after each use and store out of direct sunlight.
- Replace the protective cap when the cleaner is not charging
- Fully charge cleaner before winterizing. Do not leave cleaner drained of charge for excessive periods.



For complete instructions and troubleshooting steps, please read the owner's manual.

## Contact Information

### Zodiac Pool Systems LLC

- 2882 Whiptail Loop # 100 Carlsbad, CA 92010, USA
- [PolarisPool.com](https://www.polarispool.com)
- 1.800.822.7933


### Zodiac Pool Systems Canada, Inc.

- 2-3365 Mainway Burlington, ON L7M 1A6, Canada
- [PolarisPool.ca](https://www.polarispool.ca)
- 1.800.822.7933

## A Fluidra Brand



©2024 Zodiac Pool Systems LLC. All rights reserved. ZODIAC® is a registered trademark of Zodiac International, S.A.S.U., used under license. All other trademarks are the property of their respective owners.

## Documents / Resources

 <p><b>Polaris</b></p> <p>PIXEL™ Compact Cordless Robotic Cleaner Robot nettoyeur sans fil compact Robot limpiador inalámbrico compacto</p>	<p><a href="#">Polaris H0832100 PIXEL Compact Cordless Robotic Cleaner</a> [pdf] User Guide</p> <p>H0832100 PIXEL Compact Cordless Robotic Cleaner, H0832100, PIXEL Compact Cordless Robotic Cleaner, Compact Cordless Robotic Cleaner, Cordless Robotic Cleaner, Robotic Cleaner, Cleaner</p>
--	--

## References



-  [Home | Polaris Pool](#)
-  [Home | Polaris Pool](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.