




## polaroid I-2 Instant Camera User Guide

[Home](#) » [Polaroid](#) » polaroid I-2 Instant Camera User Guide 

### Contents

- [1 polaroid I-2 Instant Camera](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 LOAD FILM](#)
- [5 TAKE A SHOT](#)
- [6 ADJUST EXPOSURE](#)
- [7 Menu navigation](#)
- [8 Documents / Resources](#)

**Polaroid**  


**polaroid I-2 Instant Camera**



## Product Information

The Polaroid I-2 is an instant camera that allows you to capture photos and print them instantly. It also offers additional features and greater control over your photography when used in conjunction with the Polaroid App.

The camera has various shooting modes including Auto mode, Aperture priority, Shutter priority, Manual mode, and Self-timer. It features an autofocus system with a focus point in the center of the viewfinder. The camera has a built-in flash that fires automatically when taking a shot. It works with film and has a filmshield to protect the ejected photo.

The camera has an exposure adjustment feature that allows you to adjust the brightness of your photos. It also has a menu navigation system for accessing different settings and options.

## Product Usage Instructions

1. Set up the camera by downloading the Polaroid App and connecting it to the camera.
2. To load film, follow these steps:
  - Open the film compartment.
  - Insert the film pack.
  - Close the film compartment.
3. **To take a photo, follow these steps:**
  - For portrait shots, frame your subject within the designated area of the viewfinder. For landscape shots, frame your subject within the whole viewfinder.
  - Press the shutter button. The flash will fire automatically.
  - The photo covered by the film shield will eject.
  - Do not shake the photo. Place it in a dark place or face down on a flat surface.
4. **To adjust exposure, follow these steps:**
  - Use the aperture and shutter speed settings to adjust the exposure.
  - For a darker photo, decrease the aperture value or increase the shutter speed value.

- For a brighter photo, increase the aperture value or decrease the shutter speed value.
5. For additional information and detailed instructions, refer to the Quick Start Guide and complete User Manual provided.


If you have any problems or questions, you can contact the Customer Support Team or visit [polaroid.com/help](http://polaroid.com/help) for assistance.

For more information specific to your region, you can visit [polaroid.com/i2-manual](http://polaroid.com/i2-manual) or contact the appropriate customer service email or phone number provided.

## SET UP



## Select language




**Download Polaroid App and connect\* to the camera**




The camera will not appear in your phone's Bluetooth® device list as the app connects automatically.

## **LOAD FILM**



## TAKE A SHOT



Press the shutter button. The flash will fire automatically




The photo covered by the film shield will eject




Don't shake the photo! Place it in a dark place or face down on a flat surface.




Attach handle



## ADJUST EXPOSURE



- A Flash
- B Shutter Button C Film Shield
- D Camera Lens
- E LIDAR Ranging F Viewfinder Front
- G Film Door Latch
- H Film Door
- I Tripod MountJ Selection Dial




## Menu navigation





## Displays


1. Mode
2. Selection Dial Indicator
3. Aperture
4. Shutter Speed
5. Exposure Meter
6. Battery Level
7. Film Count
8. Focus Distance
9. Auto Exposure-Focus Lock
10. Flash On|Off
11. App Connected
12. Tripod Recommended



## Focus distance


Aim the center of the autofocus frame at your subject. When you half-press the shutter button, the focus / subject distance is shown on the inner and outer displays.





## Polaroid App

While the Polaroid I-2 works as a standalone instant camera, you can download the Polaroid App to access more features and gain even greater control over your photography



## Focus – Exposure lock


Half-pressing the shutter button will also lock exposure and focus on the subject.



For an in-focus, off-center subject: keep the button half-pressed, re-aim the autofocus frame, and shoot



## Subject Framing



The whole viewfinder represents a photo framed at  $\infty$ . When a subject is closer than 8m, you may want to ensure your subject is centered within the frame by 1. locking focus and 2. adjusting your framing.



## Exposure meter




In Manual mode the exposure meter helps to find the right exposure (0) on the inner and outer displays.



If the meter points to the right, your photo will be overexposed. Try a faster shutter speed or a higher  $f$ /number.



In all other modes the camera will try to automatically select the correct exposure (0). However, if you have used the EV dial to compensate the exposure, the displays will reflect this.



Quick Start Guide and complete User Manual

- [polaroid.com/i2-manual](https://polaroid.com/i2-manual)

Have a problem or question?

Contact our Customer Support Team or visit [polaroid.com/help](https://polaroid.com/help)

- **USA/Canada**
- [usa@polaroid.com](mailto:usa@polaroid.com)
- +1-212-219-3254
- **EU/Rest of World**
- [service@polaroid.com](mailto:service@polaroid.com)
- 00800 5770 1500

## Documents / Resources

	<a href="#">polaroid I-2 Instant Camera</a> [pdf] User Guide I-2 Instant Camera, Instant Camera, Camera
--	------------------------------------------------------------------------------------------------------------