



Polaroid Go Instant Camera User Manual

[Home](#) » [Polaroid](#) » Polaroid Go Instant Camera User Manual 



Contents

- [1 Go Instant Camera](#)
- [2 Documents / Resources](#)
- [2.1 References](#)

Go Instant Camera



A	Shutter Button
B	Lens
C	Viewfinder & Selfie Mirror
D	Flash Self-timer Double Exposure Button
E	Film Door Button
F	Flash
G	ON OFF Button
H	Film Counter Display
I	Wrist Strap Loop
J	Photo Eject Slot
K	USB-C™ Charging Port & Battery Level Indicator



This camera works with
POLAROID GO FLIM
Photography: Harriet Browse
Styling: Agnes Montecinos Muñoz

Polaroid Go Instant Camera Generation 2

Quick Start Guide



1. Turn on the Polaroid Go camera by pressing the ON/OFF button. The film counter display will show you how many photos you have left.
2. Slide the film door button across and pull the door open.
3. Match the arrows on the film cassette with the arrows indicated in the camera. Slide the thick end of the cassette in first and let it drop into place. Leave the pull tab on as you will need that later to remove the empty film pack.
4. Close the film door until it clicks. The darkslide covered by the film shield will eject.
5. Remove the darkslide and allow the film shield to roll back in.
6. Aim at your subject and press the shutter button. The flash will trigger automatically. Be careful you don't cover the flash with your finger.
7. Try a selfie. The viewfinder has its own reflective selfie mirror. Place yourself in the middle of it then take the photo.
8. The photo will eject underneath the film shield. Leave it there for 5 seconds. Then gently lift the film shield and let it roll back in. Remove the photo.
9. Don't shake the photo! Place your photo in a dark place or face down on a flat surface to shield it from light.

Follow the development time on the film pack.

Download the complete Polaroid Go camera manual.> polaroid.com/go-manual



www.polaroid.com/go-quickstart

Have a problem or question?

Contact our Customer Support Team

USA/Canada

usa@polaroid.com

+1-212-219-3254

EU/Rest of World

service@polaroid.com

00800 5770 1500

or visit polaroid.com/help

Made in China for, and distributed by, Polaroid International B.V. 1013 AP, Amsterdam, The Netherlands. POLAROID, the Color Spectrum, and the Classic Border Logo are protected trademarks of Polaroid.

©2023 Polaroid. All rights reserved.

Documents / Resources



[Polaroid Polaroid Go Instant Camera](#) [pdf] User Manual
9097, 9098, 9096

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.