

## polk 34685990 Audio React Sound Bar Instructions

[Home](#) » [polk](#) » polk 34685990 Audio React Sound Bar Instructions 

### polk 34685990 Audio React Sound Bar Instructions



#### Contents

- [1 Safety Instructions](#)
- [2 PRECAUTIONS SAFETY](#)
- [3 IMPORTANT SAFETY INSTRUCTIONS](#)
- [4 Caution On Installation](#)
- [5 CAUTIONS ON USING BATTERIES](#)
- [6 Notes On Radio](#)
- [7 COMPLIANCE INFORMATION](#)
- [8 IMPORTANT NOTICE:](#)
- [9 IMPORTANT](#)
- [10 RF Exposure Information](#)
- [11 Documents / Resources](#)
- [12 Related Posts](#)

### Safety Instructions

( Read these safety instruction before operating the unit.)

### PRECAUTIONS SAFETY



Caution



Risk of Electric Shock DO not open

**CAUTION:**

**TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.**



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

**WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.**

## **IMPORTANT SAFETY INSTRUCTIONS**

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer’s instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized plug. A polarized plug has two blades with one wider than the other. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus.

When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into

the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

15. Batteries shall not be exposed to excessive heat such as sunshine, fire or the like.

## **WARNINGS**

## **NOTES ON USE**

- Avoid high temperatures. Allow for sufficient heat dispersion when installed in a rack.
- Handle the power cord carefully. Hold the plug when unplugging the cord.
- Keep the unit free from moisture, water, and dust.
- Unplug the power cord when not using the unit for long periods of time.
- Do not obstruct the ventilation holes.
- Do not let foreign objects into the unit.
- Do not let insecticides, benzene, and thinner come in contact with the unit.
- Never disassemble or modify the unit in any way.
- Ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, tablecloths or curtains.
- Naked flame sources such as lighted candles should not be placed on the unit.
- Observe and follow local regulations regarding battery disposal.
- Do not expose the unit to dripping or splashing fluids.
- Do not place objects filled with liquids, such as vases, on the unit.
- Do not handle the mains cord with wet hands.
- When the switch is in the OFF (STANDBY) position, the equipment is not completely switched off from MAINS.
- The equipment shall be installed near the power supply so that the power supply is easily accessible.
- Do not keep the battery in a place exposed to direct sunlight or in places with extremely high temperatures, such as near a heater.
- Do not bend forcibly the plug on the equipment or the connection between the connector and micro USB/USB cable.

**(Only amplifier)**



Hot Surface mark

**CAUTION:**  
**HOT SURFACE. DO NOT TOUCH.**

The top surface over the internal heat sink may become hot when operating this product continuously. Do not touch hot areas, especially around the “Hot surface mark” and the top panel.

**CAUTION:**

To completely disconnect this product from the mains, disconnect the plug from the wall socket outlet. The mains plug is used to completely interrupt the power supply to the unit and must be within easy access by the user.

**CAUTION:**

To prevent electric shock hazard, do not connect to mains power supply while grille is removed.

## DECLARATION OF CONFORMITY

Hereby, !Sound United, LLCI declares that our product is in compliance with following EU/EC Directives. The full text of the EU declaration of conformity is available at the following intercom address:



**ErP:** EC regulation 1275/2008 and its frame work directive 200W125/EC including amendment 801/2013



**RoHS:**

2011/65/W, and amendment directive (EU) 2015/863



**RE:** 2014/53/EU

## A NOTE ABOUT RECYCLING:

This product's packaging materials are recyclable and can be reused. Please dispose of any materials in accordance with the local recycling regulations. When discarding the unit, comply with local rules or regulations. Batteries should never be thrown away or incinerated but disposed of in accordance with the local regulations concerning battery disposal.

This product and the supplied accessories, excluding the batteries, constitute the applicable product according to the WEEE directive.

<EU declaration of conformity URL: <https://www.polkaudio.com/dedarations-of-conformity>>

Sound United, LLC

I Veer Way Vista, CA 92081 USA

EU: Sound United Europe, A divisin of D&M Europe B.V.

Beamed street 11, 565 MA Eindhoven, The Netherlands

## Cautions on installation

For proper heat dispersal, do not install this unit in a confined space, such as a bookcase or similar enclosure.


- Amplifier: 0.3 m or more
- Other units: 0.1 m or more

## Caution On Installation

### When mounting the speakers on a wall

- The speakers can be mounted on a wall using the keyhole hook on its rear panel.
- When you mount the speakers, be sure to install them properly and securely.

1. Screw in one self-tapping screw (commercially available, 0.20 inch / 5 mm to 0.24 inch / 6 mm diameter) into a wall that has sufficient strength to support the weight of the speaker, or into reinforcing material on the wall.





2. Hook the keyhole hook on the back of the speaker onto the head of the self-tapping screw.

- Check that the head of the self-tapping screw hooks securely into the keyhole hook hole.
- Do not attempt to install this product onto a wall made of material that may crumble easily, such as mortar or decorative plywood. Doing so may result in the screw pulling out and speaker falling, causing damage to the speaker or injury.
- Do not install the speaker using other methods such as nails or double-sided tape. The nails may become loose due to vibration or the double-sided tape may peel off due to prolonged use, causing the speaker to fall.
- Be sure to fix the cables in place so that they cannot be pulled or tripped over by accident.
- Be sure to check that the product is safe after installation. Please note that we cannot accept any liability for accidents, etc. that occur as a result of where or how this product is installed. If you are unsure of how to install this product safely, request a professional contractor do the installation work.

## CAUTIONS ON USING BATTERIES

There is possibility of smoke, fire , explosion from the battery . Please note as following.

- Insert the specified batteries in the remote control unit.
- Replace the batteries with new ones if the set does not operate even
- when the remote control unit is operated close to the unit. (The supplied batteries are only for verifying operation. Replace them with new batteries at an early date.)
- When inserting the batteries, be sure to do so in the proper direction, following the  and  marks in the battery compartment. To prevent damage or leakage of battery fluid:
- Do not use a new battery together with an old one.
- Do not use two different types of batteries.
- Do not attempt to charge dry batteries.
- Do not short-circuit, disassemble, heat or dispose of batteries in flames.
- Do not keep the battery in a place exposed to direct sunlight or in places with extremely high temperatures, such as near a heater.

- If the battery fluid should leak, carefully wipe the fluid off the inside of the battery compartment and insert new batteries.
- Remove the batteries from the remote control unit if it will not be in use for long periods.
- Used batteries should be disposed of in accordance with the local regulations regarding battery disposal.
- The remote control unit may function improperly if rechargeable batteries are used.

## **Notes On Radio**

### **CANADA USA**

#### **FCC Information (For US customers)**

### **COMPLIANCE INFORMATION**

- Product Name: Sound Bar
- Model Number: POLK REACT
- THIS PRODUCT'S

**FCC ID:** WLQREACT This product complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This product may not cause harmful interference, and
2. This product must accept any interference received, including interference that may cause undesired operation.

### **Sound United, LLC**

1 Viper Way Vista, CA 92081  
**Tel.** (800) 377-7655

### **IMPORTANT NOTICE:**

#### **DO NOT MODIFY THIS PRODUCT**

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modification not expressly approved by Polk may void your authority, granted by the FCC, to use the product.

### **IMPORTANT**

#### **(For Network)**

When connecting this product to network hub or router, use only a shielded STP or ScTP LAN cable which is available at retailer. Follow all installation instructions. Failure to follow instructions could void your authority, granted by the FCC, to use the product.

#### **CAUTION (For Bluetooth/VVi-Fi)**

- To comply with FCC RF exposure compliance requirement, separation distance of at least 20 cm must be maintained between this product and all persons.
- This product and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.
- 5.15-5.25 GHz band is restricted to indoor operations only.

## NOTE

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the product OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the local retailer authorized to distribute this type of product or an experienced radio/TV technician for help.

## RF Exposure Information

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65 and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that are deemed to comply without testing of specific absorption ratio (SAR). This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

## DECLARATION OF CONFORMITY

Hereby, [Sound United, LLC] declares that our product

**[Product Name:** Sound Bar,

**Model Number:** POLK REACT] is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

<https://www.polkaudio.com/declarations-of-conformity>

## IMPORTANT NOTICE: DO NOT MODIFY THIS PRODUCT

This product, when installed as indicated in the instructions contained in this manual, meets RE directive requirements. Modification of the product could result in hazardous Radio and EMC radiation.

## CAUTION

Separation distance of at least 20 cm must be maintained between this product and all persons. This product and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

**EU declaration of conformity URL:**

### Radio Specification for Europe model


Type	Frequency Range	Max. RF Power
Bluetooth	2,402 – 2,480 MHz	20 dBm
WLAN (2.4GHz)	2,400 – 2,483.5 MHz	20 dBm
WLAN (5GHz/VV52)	5,150 – 5,250 MHz	23 dBm
WLAN (5GHz/VV53)	5,250 – 5,350 MHz	23 dBm
WLAN (5GHz/W56)	5,470 – 5,725 MHz	30 dBm
Wireless Module (BAR/SUB/SURRO UNDS)	2,400 – 2,483.5 MHz	20 dBm

**Note:** The above specification is based on the RE Directive. There is a possibility to varies by countries.



only use indoor to restricted is MHz 350,5 – 150,5

### Documents / Resources

	<p><a href="#">polk 34685990 Audio React Sound Bar</a> [pdf] Instructions REACT, WLQREACT, 34685990, Audio React Sound Bar, React Sound Bar, 34685990, Sound Bar</p>
---	--