

# Poly G7500 Wireless 4K Codec Presentation System User Guide

Home » Poly » Poly G7500 Wireless 4K Codec Presentation System User Guide 🔁

## Contents 1 Poly G750

- 1 Poly G7500 Wireless 4K Codec Presentation
- o you in
- 2 Maintenance Instructions
- 3 Hardware
- 4 Instructions for Use
- **5 Specifications**
- **6 LED Status Indicators**
- **7 CONTACT**
- 8 Documents / Resources
  - 8.1 References



## Poly G7500 Wireless 4K Codec Presentation System



## **Maintenance Instructions**

Poly recommends that you regularly clean displays located in high-use spaces, such as conference rooms and lobbies, especially if the displays have touch capabilities.

- 1. Unplug all cables from the display.
- Dampen a dry microfiber cloth with a medicinal isopropyl alcohol and water solution of 70:30.
   To avoid damage, do not apply the solution directly to the touch display.
- 3. Wipe the screen in a circular motion.

- 4. With a dry area of the cloth, dry off the screen and avoid getting moisture beneath the bezels.
- 5. Let the display air-dry completely before reconnecting any cables.

## **Hardware**

## Poly G7500 Hardware

- 1. Reset button
- 2. LED indicator
- 3. Remote control pairing button
- 4. Restart button




#### **Ports**

- 1. 3.5 mm audio line out
- 2. 3.5 mm audio line in
- 3. Security lock
- 4. Mini-DIN/RS-232 serial port

**NOTE:** The serial port is occasionally used by third-party control system devices for automation.

- 5. USB-A ports
- 6. USB-C port
- 7. HDCI input for Poly cameras
- 8. HDMI input for sharing content (for example, from a laptop)
- 9. HDMI output for the primary monitor
- 10. HDMI output for the secondary monitor
- 11. LAN connection for the system
- 12. Link-local network (LLN) connections for IP-based peripheral devices
- 13. Power cord port



## **Instructions for Use**

#### Place a Call

You can place an audio or video call to a contact.

- 1. Go to Place a Call.
- 2. On the Dialpad screen, move the slider to Audio or Video.
- 3. Enter a number on the dialpad or select Keyboard to enter characters.
- 4. Select Call.

#### **End a Call**

When your call is complete, hang up the call. If you have content such as blackboards, whiteboards, or snapshots, the system asks if you want to keep them.

In a call, do one of the following:

- On your remote control, press Hang Up
- On the screen, select Menu == > Hang Up.

## **Specifications**

## **Poly G7500 Product Specifications**

• Power: 65BTU h

Camera resolution: 2160p, 4K UHD (3840 x 2160)

• Video frame rate: 5 – 60fps

• Video standards: H.264 AVC; H.264 High Profile; H.265

• Operating temperature: 32 to 104° F

• Minimum dimensions: 13.75 x 1.5 x 5.5 in

## **LED Status Indicators**

- Blinking white Powering on
- Solid white Working normally
- Solid green In a call
- Blinking amber Update in progress
- Solid amber Sleeping
- Blinking red Error preventing normal operation
- Solid red Muted microphone

## **CONTACT**

- · Registration Number at
- Ministry of Trade: IMKG.205.01.2024
- Importer: PT. Hewlett-Packard Indonesia
- Address: Prudential Center Office Building. Kota Kasablanka Floor 9, JL.
- Casablanca Cav. 88 Menteng Dalam, Tebet .12870 South Jakarta, Indonesia
- support.hp.com/poly.

Poly G7500





© 2024 Poly. All trademarks are the property of their respective owners.



## **Documents / Resources**



Poly G7500 Wireless 4K Codec Presentation System [pdf] User Guide G7500 Wireless 4K Codec Presentation System, Wireless 4K Codec Presentation System, Cod ec Presentation System, Presentation System, System

## References

• User Manual

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.