



poly R30 Studio with Display Clamp User Guide

[Home](#) » [Poly](#) » poly R30 Studio with Display Clamp User Guide 



QUICK START
POLY STUDIO R30
(NO RADIO) WITH
DISPLAY CLAMP



<http://www.poly.com/support/studio-r30>

Contents

- [1 MANAGEMENT SOFTWARE](#)
- [2 DEFAULT PASSWORD](#)
- [3 CONTENTS](#)
- [4 Documents / Resources](#)

MANAGEMENT SOFTWARE



POLY LENS

poly.com/lens


DEFAULT PASSWORD

poly12#\$


CONTENTS




1




3



5



6



poly.com/support/studio-r30



Recyclable Where facilities
UKCA

UK: HP Inc UK Ltd, Regulatory Enquiries, Earley West, 300 Thames Valley Park Drive, Reading, RG6 1 PT
© 2023 Poly. All trademarks are the property of their respective owners.



1725-69352-001A 04.23

Documents / Resources



[poly R30 Studio with Display Clamp](#) [pdf] User Guide
R30, R30 Studio with Display Clamp, Studio with Display Clamp, Display Clamp