



POTTER CFG-5000 Configuration Tool for DACT Owner's Manual

[Home](#) » [POTTER](#) » POTTER CFG-5000 Configuration Tool for DACT Owner's Manual 

POTTER CFG-5000 Configuration Tool for DACT



Contents

- [1 Introduction](#)
- [2 Description](#)
- [3 Customer Support](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

Introduction

- Rugged metal construction
- Configures both DACT-5000 and UDACT-9000
- Large LCD screen
- Simplistic operation
- Directly powered from DACT
- Required to program DACT Stock number: 3002110

Description

The CFG-5000 DACT Configuration Tool is used to configure both the DACT-5000 and the UDACT-9000. The CFG-5000 is in a rugged metal enclosure and utilizes a number pad with a large LCD screen. A ribbon cable from the CFG-5000 plugs into the DACT for power and communication, no external power is required.

The CFG-5000 has two levels of access for an operator and an installer. The operator is level one and the installer is level two. The installer level can configure any of the options available. The operator level (Level 1) cannot change any of the account or reporting numbers.

Customer Support

Potter Electric Signal Company
2081 Craig Road, St. Louis, MO, 63146-4161
Phone: 800-325-3936/Canada 888-882-1833
www.pottersignal.com



Documents / Resources

	POTTER CFG-5000 Configuration Tool for DACT [pdf] Owner's Manual CFG-5000 Configuration Tool for DACT, CFG-5000, Configuration Tool for DACT, Tool for DACT
---	--

References

-  [Fire Alarm Resources | Download fire alarm documents](#)
-  [Potter Electric: Fire Alarms & Fire Sprinkler Systems](#)

Manuals+.