

PowerLocus B091363MMN Multi-Function 4 in 1 Wireless Stereo Headphones User Manual

Home » PowerLocus » PowerLocus B091363MMN Multi-Function 4 in 1 Wireless Stereo Headphones User Manual ™






USER'S MANUAL PowerLocus Multi-function/4in1 Wireless Stereo Headphones

Contents

- 1 Product indication
- 2 Power on/off the headset
- 3 Pair to your mobile phone or other products
- 4 MP3/FM
- 5 answer/end calls, reject call, last number redial (In the bluetooth mode)
- 6 Charging the headset
- 7 Wired headphone function
- **8 Precautions**
- 9 Documents / Resources
- **10 Related Posts**

Product indication



- 1. U Power on /off
- 2. M/C play/pause, answer/end calls, reject call, last number redial
- 3. + Volume up(Long Press)/Next song(Short Press)
- 4. Volume down(Long Press)/Last song(Short Press)
- 5. Multi-function button(pairing, auto search radio)
- 6. Headset jack
- 7. LED indicator
- 8. Micro USB charging port
- 9. Microphone
- 10. Micro SD/TF card slot

Power on/off the headset

- Power on: Slide the switch right and the blue and red indicator light will flash(the headset said: the wireless is ready to pair).
- Power off: Slide the switch left and blue indicator light will go off.

Pair to your mobile phone or other products

- Slide the switch right and the blue and red indicator light will flash(the headset said: the wireless is ready to pair).
- Turn on the bluetooth function of your phone or other products.
- Search for the bluetooth devices and select 'JH-812'. (Enter the code `0000' if needed)
- If paring is successful, the blue light indicator starts flashing(the headset said: the wireless is connected successfully).
- Please make sure the headphone is working before pairing.
- It will connect to the pre-set phone automatically when turns on(Please make sure the bluetooth function of

your phone is working)

• If the pairing is not successful, please switch off headset firstly, and then re-pair again.

MP3/FM

- In power-on mode, insert the TF card, short press $\,^{\,\,\,\,\,\,\,\,\,}$ button,MP3 will play automatically. If have not TF card, short press $\,^{\,\,\,\,\,\,\,\,\,\,}$ button, FM radio will play automatically.
- In power-on mode, short press button, FM radio will play automatically. Long press the button to auto search all radio station, wait for a moment, then short press or , you will listening to any radio station you like..
- If you are listening to FM radio, short press M button, it will be converted to the bluetooth mode. And auto connected to your phone or other products.

answer/end calls, reject call, last number redial (In the bluetooth mode)

- When there is a call, short press button can answer the call. After the call, press button can hang up. If the other side hang up, no need to press the button.
- reject call: long press H/C button about 2-3seconds
- last number redial: press fast button 2 times
- When the phone call out or answer the call, if the bluetooth headphone are playing the music, the music will pause automatically and enter the waiting state. After hang up, the music will continue to play automatically.

Charging the headset

- Insert USB charging cable into USB port which have support 5V power (such as AC/DC USB adapter or PC USB port). When the red light is on, the headset is in charging. When the red light will be off, the headset is fully charged. It takes about 2-2.5 hours to charge the headset fully.
- The battery is rechargeable. Low-Voltage alert: When the alert tone `low battery' sounds and the indicator turns into red indicate that the battery has run out, need to be charged as soon as possible. First time charging : please be sure the battery has been charged fully before use.

Wired headphone function

For any mode of headphone, you can connect one side of 3.5 stereo sound supply extension line to headphone audio jack, the another side connect to Audio jack(such as mobile phone, computer, lpad etc). Then you will hear songs from other devices.

Precautions

- 1. Please be gentle when using headphone. The Maximum tolerance of the button is 250g.Excessive force or be stroked by something all will damage buttons.
- 2. Please do align the USB port when plug or pull USB cable in case that damages the USB cable fail to charge the headphone.

- 3. When encounter something similar to interference, please first delete the Bluetooth devices that connected with headphone before, then restart your phone, at last please repair with the Bluetooth headphone.
- 4. If long time without using headset, it is recommended to turn off the headset, in case that the battery is in a low voltage state, causing the charging problems.
- 5. Please don't put the headset in hot temperature area.
- 6. Please don't vibrate or shock the headset violently, and do not let it fall down from high place.
- 7. If there is no response of the headset, Pls insert headphone plug hole to reset by tool.

Facebook: @PowerLocus
Email: powerdirect155@gmail.com
Whatsapp: +31 633242189
US Phone Support: 646-844-2665
UK Phone Support: +44 203608580

Documents / Resources



PowerLocus B091363MMN Multi-Function 4 in 1 Wireless Stereo Headphones [pdf] User Manual

B091363MMN, Multi-Function 4 in 1 Wireless Stereo Headphones, B091363MMN Multi-Function 4 in 1 Wireless Stereo Headphones, Wireless Stereo Headphones, Stereo Headphones, Headphones

Manuals+,