



**ClearPad Glow
Light Up Reusable
Memo Pad**



Powerstick ClearPad Glow Light Up Reusable Memo Pad User Manual

[Home](#) » [POWERSTICK](#) » Powerstick ClearPad Glow Light Up Reusable Memo Pad User Manual



Contents

- [1 Powerstick ClearPad Glow Light Up Reusable Memo Pad](#)
- [2 Product Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Frequently Asked Questions](#)
- [5 INSTALL AND USE](#)
- [6 TURNING ON/OFF GLOW](#)
- [7 ADJUSTING BRIGHTNESS](#)
- [8 BUILT-IN BATTERY](#)
- [9 CHARGING CLEARPAD GLOW](#)
- [10 CLEANING INSTRUCTIONS](#)
- [11 FCC Statement](#)
- [12 Documents / Resources](#)
 - [12.1 References](#)



Powerstick ClearPad Glow Light Up Reusable Memo Pad



Product Specifications

- **Name:** ClearPad Glow
- **Dimensions:** 90mm x 90mm x 150mm
- **Placement:** Front and Inside

Product Usage Instructions

Front Placement:

To use the ClearPad Glow on the front, ensure that the device is placed securely on a flat surface. Activate the device and interact with the touch-sensitive area to navigate through menus or use specific functions.

Inside Placement:

When using the ClearPad Glow inside a device, make sure to follow the installation instructions provided by the manufacturer. The touchpad can be used for various input actions based on the device's functionality. Refer to the device manual for specific details.

Frequently Asked Questions

Q: How do I activate the touchpad?


A: The touchpad is typically activated by powering on the device it is integrated into. Ensure that the device settings allow for touch input.

Q: Can I adjust sensitivity settings?

A: The sensitivity settings of the ClearPad Glow may vary depending on the device it is used in. Check the device settings or consult the manufacturer's manual for information on adjusting sensitivity.

INSTALL AND USE

- Peel off the protective film.
- Insert the writing panel into the notch of the base.



- You can write while it is standing up or take it off and place it on a flat surface as well.
- Only for use with Chalk Markers.

TURNING ON/OFF GLOW

Use the included cable to plug ClearPad Glow into a USB power source (laptop, USB adapter, powerbank, etc.) Press the button to turn on and off ClearPad Glow.

ADJUSTING BRIGHTNESS

Press and hold to adjust the brightness of the glow. The brightness will cycle back to bright after reaching the lowest setting.

BUILT-IN BATTERY

ClearPad Glow has a battery built in that will allow 2 hours of glow time. ClearPad Glow will blink 3 times and turn off when it is time to charge.

CHARGING CLEARPAD GLOW

Use the included charging cable to keep ClearPad Glow always on or to charge up the battery.

CLEANING INSTRUCTIONS

Use a clean, dry cloth or tissue to simply wipe the chalk marker off. Do not use any abrasive or household cleaners.

FCC Statement

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.


Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

Documents / Resources

	<p>Powerstick ClearPad Glow Light Up Reusable Memo Pad [pdf] User Manual 2AITN-CLRPADGLOW, 2AITNCLRPADGLOW, ClearPad Glow Light Up Reusable Memo Pad, ClearPad Glow, Light Up Reusable Memo Pad, Up Reusable Memo Pad, Reusable Memo Pad, Memo Pad, Pad</p>
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.