



[Home](#) » [PrimeZone](#) » **PrimeZone B09XDHF8T5 C Shaped Side Table User Guide** 

Contents [[hide](#)]

- [1 PrimeZone B09XDHF8T5 C Shaped Side Table](#)
- [2 Product Usage Instructions](#)
- [3 Before You Start](#)
- [4 PART LIST](#)
- [5 HARDWARE](#)
- [6 ASSEMBLY INSTRUCTION](#)
- [7 Return / Damage Claim Instructions](#)
- [8 FAQ \(Frequently Asked Questions\)](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)

PrimeZone

PrimeZone B09XDHF8T5 C Shaped Side Table



Product Usage Instructions

Before You Start:

Before beginning the assembly process, please ensure you have read the instructions carefully in your preferred language. Keep the instructions for reference and make sure all parts are accounted for and the set is complete. Familiarize yourself with the assembly method and follow the instructions step by step. It is recommended to assemble the product as close as possible to its final location to avoid unnecessary movement. Place the product on a flat and stable surface. Keep packaging materials and product components out of reach of children.

Assembly Steps:

1. Start by identifying and sorting all components according to the provided instructions.
2. Follow the step-by-step assembly guide, ensuring each part is securely attached.
3. Use the provided tools, if any, to aid in the assembly process.
4. Double-check all connections and fastenings to ensure stability and safety.

Care and Maintenance:


After assembly, regularly check the product for any loose parts or signs of wear. Clean

the product using a mild detergent and a soft cloth. Avoid using abrasive cleaners that may damage the surface.


Before You Start

- Please read all instructions carefully.
- Retain instructions for future reference.
- Separate and count all parts and hardware.
- Read through each step carefully and follow the proper order.
- We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- Always place the product on a flat, steady and stable surface.
- Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.


PART LIST




A × 1



B × 1



C × 1



D × 1



E × 1



F × 1



G x 1

I x 2



J x 2



HARDWARE

W2



x 8

M6 x 26mm

W3



x 8

M6 x 35mm

T



x 4

Y2



x 4

N



x 1

H



x 1

K1



x 1

K2



x 1


K3




x 1

ASSEMBLY INSTRUCTION


1



2




3




W3  × 4

4




W2  × 4

5




Y2  x 4

6






W2  x 4

7



8





Return / Damage Claim Instructions

- **DO NOT discard the box / original packaging.**

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

- **Take a photo of the box markings.**

A photo of the markings (text) on the side of the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

- **Take a photo of the damaged part (if applicable).**

A photo of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

- **Send us an email with the images requested.**

Email us directly from marketplace where your item was purchased with the attached images and a description of your claim.

FAQ (Frequently Asked Questions)


- **What should I do if I need to return or claim damage?**

Do not discard the original packaging. If a return is necessary, ensure the item is returned in its original box. Take photos of the box markings and any damaged parts, if applicable. Contact us via email with the required images and a description of your claim.

- **How can I ensure I receive the correct replacement parts?**

Providing photos of the box markings and damaged parts helps our staff identify your product number accurately, ensuring you receive the correct replacement parts promptly.

Documents / Resources

	PrimeZone B09XDHF8T5 C Shaped Side Table [pdf] User Guide B09XDHF8T5 C Shaped Side Table, B09XDHF8T5, C Shaped Side Table , Side Table, Table
---	---

References

- [User Manual](#)

Related Posts



[COSTWAY X8 Side Table Installation Guide](#)

COSTWAY X8 Side Table INSTALLATION GUIDE



[IKEA TANEbro Side Table User Guide](#)

IKEA TANEbro Side Table Specifications: Product
Model: AA-2544040-1 Maximum Load Capacity: 10 kg

(22 lb) Material: Delicate Dimensions:...



[nomon Puntero Side Table Installation Guide](#)

nomon Puntero Side Table Assembly Instructions Step 1

1.a Use 3 screws (x3) Use 1 Allen key (x1)...

[Her Texhaus Opulent Side Table Installation Guide](#)



Her Texhaus Opulent Side Table GENERAL

INSTRUCTIONS Minor assembly required Estimated

time: 10 minutes Requires one person for...

 PrimeZone B09XDHF8T5, B09XDHF8T5 C Shaped Side Table, C Shaped Side Table, PrimeZone, SIDE TABLE, table

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.