

Pro-Ject T2 W Audio Systems User Guide

Home » Pro-Ject » Pro-Ject T2 W Audio Systems User Guide 🖺



AUDIO SYSTEMS T2 W Audio Systems User Guide

Contents


1 T2 W Audio Systems 2 Documents / Resources 2.1 References

T2 W Audio Systems



T2 W Setup Guide Getting started:

- Make sure to have enough space to unpack your turntable.
- Always unpack and set up in a clean environment.
- Please Do NOT throw away the packaging! If you need service or want to return your product, please send it in the original packaging including all inserts. In case of damage due to alternative packaging your dealer cannot guarantee a full refund.
- Full manual: www.project-audio.com/en/product/t2w
- 1. Unpack all items from the accessories bag.
 - a) Single adapter
 - b) Drive belt
 - c) Connect it E cable
 - d) Gauge
 - e) Alignment tool



2. Remove the dustcover.



3. Remove the turntable from the box.



4. Unpack the power supply unit.



5. Unpack glass-platter and felt mat from the bottom of the carton.



6. Remove the protective cloth.



7. Put the drive belt over the sub-platter.



8. Put the felt mat on the platter.



9. Remove cartridge cap.




10. Remove tonearm and counterweight protection inlays.






11. Remove the red tonearm security tape.






12. Connect to your stereo system. T2 W wireless setup on the back of this paper.



13. Select the playback speed.



14. Have fun with music!



T2 W Wi-Fi Quick Setup

Connect to your Wi-Fi and start streaming.

Visit www.project-audio.com/en/product/t2w for FAQ's and full manual

1. Install Pro-Jest Control App from Apple App Store or Google Play Store.



2. WiFi Connection:

Check Red LED light blinking



Initial Wi-Fi setup works via Bluetooth, please make sure Bluetooth is turned on on your phone and the Project Control App has Bluetooth access. Open the App, wait a few seconds until the App has scanned for your T2 W and tap Wi-Fi Setup.



After Wi-Fi setup is complete, the Wi-Fi Control LED will light up green. You will now see the the T2 W in the home screen.




Start streaming records by choosing your network streaming device. Active streams are indicated with a blue outline. Stop streaming by tapping the device again and the blue outline disappears. Stream to as many devices as you like.

Wi-Fi Control Button

Press for 2 seconds: Turns Wi-Fi on or off

Short press: When turned on, start streaming to the previously selected streaming device



Red static: Wi-Fi module starting up

Red blinking: Module started up, no ethernet or Wi-Fi connection established

Green static: Connected to ethernet or Wi-Fi network

Blue static: Streaming audio

Blue blinking: Previous streaming receiver unavailable

Need help?

Feel free to contact us. We have experienced partners all over the world. Find your dealer here: www.project-audio.com/en/find-a-dealer/

Service

Should you encounter a problem which you are not able to alleviate or identify despite the above information,

please contact your dealer further advice. Only when the problem cannot be resolved there should the unit be sent to the responsible distributor in your country.

Warranty repairs will only be affected if the unit is returned correctly packaged. For this reason we recommend keeping the original packaging.

Never return a record player without making sure that is it safely disassembled and correctly packaged in the original packaging according to the diagrams on the last page of this user guide. Please remove these parts and pack them separately: lid, counterweight, anti-skating weight and belt.

Fit the cartridge protection cap and the transport lock for the tonearm tube, prior to carefully packaging the record player.

Warranty

The manufacturer accepts no responsibility for damage caused by not adhering to these instructions for use and/or by transportation without the original packaging. Modification or change to any part of the product by unauthorized persons, release the manufacturer from any liability over and above the lawful rights of the customer.

Warranty: Terms and Conditions

- A warranty is valid only for products purchased from an authorized Project Audio Systems retailer or dealer.
- This warranty offer is limited to the repair of the equipment (which could be a repair or replacement at our discretion, neither of which affects your original warranty).
- Neither transportation or any other costs, nor any risk for removal, transportation and installation of products is covered by this warranty.
- A warranty is only valid for the original owner. It is not transferable.
- To validate your warranty, you will need to provide the original sales invoice or other proof of ownership and date of purchase.
- Warranty must be claimed within two years of purchase from an authorized dealer. After this period of time, the warranty will expire.
- The legal warranty obligation exists in addition to this warranty and is not limited by this warranty.
- A Pro-Jest Audio Systems warranty relates to claims of defects in materials and/or workmanship at the time of purchase. It does not cover:
- Deterioration of component parts, the nature of which is to become worn or depleted with use, such as batteries and headphone ear pads, drive belts and cartridges.
- Damages caused by incorrect installation, connection or packing.
- Damages caused by any use other than the correct use described in the user manual, negligence, modifications, or use of parts that are not made or authorized by Pro-Ject Audio Systems.
- Damages caused by faulty or unsuitable ancillary equipment.
- Damages caused by accidents, lightning, water, fire heat, war, public disturbances or any other cause beyond the reasonable control of Pro-Ject Audio Systems and its appointed distributors.
- Products where the serial number has been altered, deleted, removed or made illegible.
- Repairs or modifications that have been executed by an unauthorized person.

Commercial Use

Faults caused due to using domestic products in commercial environments or on commercial scales are not covered by warranty. This turntable is intended for domestic use only. Using them for business applications are done so at your own risk.

Pro-Jest Audio Systems is a Registered Trademark of H. Lichtenberger.

This guide was produced by: Pro-Jest Audio Systems

Copyright © 2023. All rights reserved.

The information, pictures and figures were correct at the time of going to press. The manufacturer reserves the

right to make changes to the technical specification without prior notice as deemed necessary to uphold the ongoing process of technical development.

Contains FCC ID: 2AJYB-S1955



Documents / Resources



<u>Pro-Ject T2 W Audio Systems</u> [pdf] User Guide
T2 W Audio Systems, T2 W, Audio Systems, Systems

References

- P Find A Dealer Pro-Ject Audio Systems
- User Manual

Manuals+, Privacy Policy